Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine Replacement Remote Control for Samsung LCD LED HDTV TVs

JustFine Replacement Remote Control User Manual

For Samsung LCD LED HDTV TVs (Compatible Models: UN55D6450UF, UN46D6500, UN55D6450, UN55D6450UFXZA, UN46D7500)

Brand: JustFine | Model: Replacement Remote Control

1. Introduction and Overview

This manual provides comprehensive instructions for the JustFine Replacement Remote Control. This remote is designed to function as a direct replacement for the original remote controls of various Samsung LCD LED HDTV models. It is pre-programmed and requires no additional setup beyond battery installation.

Compatible Samsung TV Models:

- UN55D6450UF
- UN46D6500
- UN55D6450
- UN55D6450UFXZA
- UN46D7500
- And other similar Samsung LCD LED HDTV models.

2. Product Features

- Direct replacement remote for specified Samsung LCD LED HDTV TVs.
- Pre-programmed for immediate use; no additional programming required.
- Ergonomic design for comfortable handling.
- Infrared connectivity technology.

3. Setup: Battery Installation

The remote control operates on batteries, which are not included in the package. Please follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.



Figure 1: Back view of the remote control showing the battery compartment.

4. Operating Instructions

Once batteries are installed, the remote control is ready for use with your compatible Samsung TV. Point the remote directly at the TV's infrared sensor.



Figure 2: Front view of the remote control with button layout.

Common Button Functions:

- **POWER (Red Button):** Turns the TV on or off.
- **ON/OFF (Yellow Button):** Turns the TV on or off. (Some models may use this instead of the red power button)
- **SOURCE:** Selects the input source (e.g., HDMI 1, AV, Component).

- **Number Buttons (0-9):** Directly enter channel numbers.
- **PRE-CH:** Returns to the previously viewed channel.
- **VOL (+/-):** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the TV sound.
- **CH (Up/Down):** Changes channels sequentially.
- **MENU:** Displays the TV's main menu.
- **SMART HUB:** Accesses the Samsung Smart Hub for apps and online content.
- **TOOLS:** Provides quick access to common functions or settings.
- **INFO:** Displays information about the current program or input.
- **EXIT:** Exits the current menu or function.
- **RETURN:** Returns to the previous screen or menu.
- **Directional Pad (Up/Down/Left/Right) & ENTER:** Navigates through menus and confirms selections.
- **PLAY/PAUSE/STOP/FF/REW:** Controls media playback.
- **P.SIZE:** Adjusts the picture size/aspect ratio.
- **CC:** Activates or deactivates Closed Captions.
- **E-MANUAL:** Accesses the TV's electronic manual (if supported by the TV).

Note: Specific button functions may vary slightly depending on your Samsung TV model.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance diminishes. Always replace both batteries with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage.

6. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new ones.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within the effective range of the remote control (typically within 20 feet).
- **TV Sensor:** Verify that the TV's infrared sensor is not blocked or dirty.
- **Interference:** Strong light sources or other infrared devices might interfere with the remote's signal. Try using the remote in a different environment.

Specific Buttons Not Working:

- This remote is pre-programmed for the listed Samsung TV models. If a specific button does not work, it might be that your TV model does not support that particular function, or the button on the remote is faulty.
- Ensure the remote is pointed directly at the TV.

7. Specifications

Brand	JustFine

Compatible Devices	Samsung LCD LED HDTV Televisions
Connectivity Technology	Infrared
Special Feature	Ergonomic Design
Max Number of Supported Devices	1 (One Television)
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.72 ounces
ASIN	B01LXPI91C
Date First Available	September 30, 2016

8. Warranty and Support

This JustFine Replacement Remote Control comes with a**30-day quality warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended.
For any problems, questions, or support inquiries regarding your remote control, please contact us via email. Our customer service team is available to assist you with troubleshooting and warranty claims.
Please note that the warranty does not cover damage caused by misuse, accidents, or unauthorized modifications.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LXPI91C

More documents and user manuals: **https://manuals.plus/**