JustFine AA5900580A

JustFine Replacement Remote Control User Manual

Compatible with Samsung Smart TV Models: UN40ES6150F, AA5900580A, UN39EH5300FXZA, UN50EH5300, UN55EH6050FXZA

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your JustFine Replacement Remote Control. This remote is designed to be compatible with various Samsung LCD LED HDTV Smart TV models, including UN40ES6150F, AA5900580A, UN39EH5300FXZA, UN50EH5300, and UN55EH6050FXZA. Please read this manual thoroughly before use to ensure proper functionality.

Product Overview

The JustFine Replacement Remote Control is a pre-programmed device designed to replicate the functions of your original Samsung TV remote. It features a standard layout for easy navigation and control of your television.



Figure 1: Front view of the JustFine Replacement Remote Control. This image displays the remote's buttons, including power, source, number pad, volume, channel, menu, and navigation controls.



Figure 2: Back view of the JustFine Replacement Remote Control. This image shows the ergonomic design and the battery compartment cover on the rear of the remote.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.
5. The remote is now ready for use. No programming is required.

Operating Instructions

This replacement remote control is pre-programmed and ready to operate your compatible Samsung Smart TV directly after battery installation. Point the remote control directly at your television's infrared receiver.

Key Functions:

- **Power (●):** Turns the television on or off.
- **Source:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **Number Pad (0-9):** Directly selects channels.
- **Volume (+/-):** Adjusts the audio volume.
- **Mute:** Silences the television audio.
- **Channel (CH List, CH +/-):** Changes channels or displays the channel list.
- **Menu:** Accesses the television's main menu.
- **Tools:** Opens a quick menu for common functions.
- **Info:** Displays information about the current program or input.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate menus and select options.

- **Return:** Goes back to the previous screen or menu.
- **Exit:** Closes the current menu or application.
- **Color Buttons (A, B, C, D):** Used for specific functions within certain applications or menus, as indicated on screen.
- **Smart Hub (Cube Icon):** Accesses the Samsung Smart Hub for apps and online content.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Make sure there are no obstructions between the remote and the TV's infrared sensor.
  - Confirm the remote is pointed directly at the TV.
- **Specific buttons not working:**
  - This remote is pre-programmed and cannot be reprogrammed. If a specific button is not functioning, ensure your TV model is listed as compatible.
  - Clean the remote surface, as dirt or debris might interfere with button presses.

Specifications

Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.72 ounces
Connectivity Technology	Infrared
Compatible Devices	Television (Samsung Smart TV models: UN40ES6150F, AA5900580A, UN39EH5300FXZA, UN50EH5300, UN55EH6050FXZA)
Max Number of Supported Devices	1

Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty, ensuring a hassle-free return process if issues arise. For any problems or inquiries, please contact the seller directly via email.
Note: Batteries and a printed manual are not included with the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question