Linke EGH-372

LINKE Hi-Light Portable Electric Stove

Model: EGH-372 AC220V

Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the appliance is connected to a 220V AC power supply. Do not use with incompatible voltage.
- Do not touch hot surfaces. Always use oven mitts or pot holders. The heating element and surrounding areas remain hot for a period after use.
- To protect against electrical hazards, do not immerse the cord, plugs, or the appliance itself in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- Do not use outdoors. This appliance is for indoor household use only.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always place the appliance on a stable, level, heat-resistant surface.
- Do not use the appliance for anything other than its intended use.
- Ensure adequate ventilation around the appliance during use. Do not block air vents.

Product Overview

The LINKE Hi-Light Portable Electric Stove EGH-372 is a single radiant hot plate designed for efficient cooking. It features a durable glass surface and an intuitive touch control panel.



A top-down view of the LINKE Hi-Light Portable Electric Stove, showing its black glass surface, red radiant heating element, and touch control panel.



A detailed view of the touch control panel, showing buttons for Timer, On/Off, power adjustment (+/-), and indicator lights for time settings and high temperature.

The control panel includes an On/Off button, Timer function, and '+' / '-' buttons for adjusting heat levels. Indicator lights provide feedback on selected settings and appliance status.

Setup

1. **Unpack:** Carefully remove the electric stove from its packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Placement:** Place the stove on a flat, stable, heat-resistant, and dry surface. Ensure there is sufficient space around the unit for proper ventilation (at least 10-15 cm from walls or other appliances). Avoid placing it near water sources or flammable materials.
4. **Power Connection:** Plug the power cord into a grounded 220V AC electrical outlet. Ensure the outlet matches the appliance's voltage requirements.
5. **Initial Cleaning:** Before first use, wipe the glass surface with a damp cloth to remove any dust or residue from manufacturing. Ensure the surface is completely dry before plugging in.

Operating Instructions

This radiant hot plate is compatible with all types of cookware suitable for electric radiant heat, including stainless steel, cast iron, ceramic, and glass pots and pans.



The LINKE Hi-Light Portable Electric Stove demonstrated with different types of cookware, indicating its compatibility with various pot materials suitable for radiant heat.

1. **Power On:** Place your cookware, filled with food or liquid, onto the center of the heating element. Press the**On**/**Off** button on the control panel. The power indicator light will illuminate.
2. **Adjust Heat:** Use the **+** and **-** buttons to increase or decrease the heating power level. The current power level will be indicated by the illuminated LEDs.
3. **Timer Function:** To set a cooking time, press the **Timer** button. Use the **+** and **-** buttons to adjust the desired cooking duration. The timer indicator lights (15min, 30min, 60min, 90min, 120min) will show the selected time. Once the set time expires, the stove will automatically turn off.
4. **High Temperature Indicator:** The 'High Temp' LED will illuminate when the cooking surface is hot, even after the unit has

been turned off. Exercise caution.

5. **Power Off:** To turn off the stove manually, press the **On/Off** button again. The power indicator light will turn off, but the 'High Temp' light may remain on until the surface cools.

Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and safe operation of your electric stove.

- Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
- Wipe the glass cooking surface with a soft, damp cloth and a mild detergent. For stubborn stains, a non-abrasive glass cooktop cleaner can be used.
- Do not use abrasive pads, harsh chemicals, or scouring agents, as these can scratch or damage the glass surface.
- Wipe the control panel and exterior housing with a soft, damp cloth. Ensure no water enters the internal components.
- Never immerse the appliance in water or any other liquid.
- Ensure all parts are thoroughly dry before plugging the appliance back in or storing it.
- Store the appliance in a cool, dry place when not in use.

Troubleshooting

If you encounter issues with your LINKE Hi-Light Portable Electric Stove, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power outage.	Ensure the power cord is securely plugged into a working 220V AC outlet. Check your circuit breaker.
Heating element not heating.	Unit is on but heat setting is too low; internal safety mechanism activated.	Increase the heat setting using the '+' button. If the unit still doesn't heat, unplug and allow it to cool for 30 minutes before trying again.
'High Temp' light remains on.	Surface is still hot after use.	This is normal. The light will turn off once the surface has cooled to a safe temperature. Do not touch the surface while the light is on.
Unusual odors during first use.	Protective coatings burning off.	This is normal for the first few uses. Ensure good ventilation. The odor will dissipate.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Technical details for the LINKE Hi-Light Portable Electric Stove Model EGH-372:

Feature	Detail
Model Number	EGH-372

Feature	Detail
Power Source	AC 220V
Wattage	2000 watts
Heating Elements	1
Burner Type	Radiant
Material	Glass
Item Weight	5.5 Pounds (approx. 2.5 kg)
Dimensions (L x W x H)	365mm x 280mm x 60mm



An angled view of the LINKE Hi-Light Portable Electric Stove with key dimensions labeled: 365mm length, 280mm width, and 60mm height.

Warranty and Support

This product is covered by a manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact the retailer.
For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact the seller or manufacturer directly. Keep your purchase receipt and model number (EGH-372) handy when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question