JustFine 8541714151

JustFine Replacement Remote Control User Manual

For Samsung LED HDTV Plasma TVs

Model: 8541714151

1. Introduction

This manual provides instructions for the JustFine Replacement Remote Control, designed for use with various Samsung LED HDTV and Plasma TV models. This remote is pre-programmed and requires no additional setup for compatible televisions. Please read this manual thoroughly before use.

2. Product Overview

The JustFine Replacement Remote Control is a direct replacement for original Samsung TV remotes, offering full functionality for compatible models. It is designed for ease of use with a standard button layout.



Figure 1: Front view of the remote control, displaying the button layout for various functions.



Figure 2: Back view of the remote control, indicating the location of the battery compartment.

2.1 Compatible TV Models

- Samsung PN60E530A3F
- Samsung LT28D310NHZA
- Samsung PN60F5300BF
- Samsung UN32EH4050F
- Samsung UN46EH5000
- Samsung UN55EH6000F
- And other compatible Samsung LED HDTV and Plasma TV models.

3. Setup

3.1 Battery Installation

This remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote is ready for use. No programming is required.

4. Operation

The JustFine Replacement Remote Control is pre-programmed to work with compatible Samsung TV models. Simply point the remote at your television and press the desired button.

4.1 Basic Functions

- **Power Button (Power Symbol):** Turns the TV on or off.
- **Number Pad (0-9):** Directly selects channels.
- **Volume Up/Down (VOL +/-):** Adjusts the sound volume.
- **Channel Up/Down (CH +/-):** Changes the TV channel.
- **Source Button (SOURCE):** Selects input sources (e.g., HDMI, AV).
- **Menu Button (MENU):** Accesses the TV's main menu.
- **Directional Pad (Up/Down/Left/Right) and Enter:** Navigates through menus and confirms selections.

- **Return/Exit Buttons:** Navigates back or exits current menus.

5. Maintenance

5.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote's performance diminishes or it stops responding. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries according to local regulations.

6. Troubleshooting

- **Remote is not responding:**
  - Ensure fresh batteries are correctly installed.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Point the remote directly at the TV.
- **Some buttons do not work:**
  - Verify that your TV model is listed as compatible.
  - Ensure the batteries have sufficient power.

If you continue to experience issues, please refer to the Support section for contact information.

7. Specifications

Feature	Detail
Product Dimensions	8 x 2 x 0.5 inches
Item Weight	2.72 ounces
Connectivity Technology	Infrared
Special Feature	Ergonomic design
Max Number of Supported Devices	1 (Television)
Compatible Devices	Samsung LED HDTV and Plasma TVs
Model Number	8541714151

8. Warranty and Support

8.1 Warranty Information

This product comes with a 30-day quality warranty and a money-back guarantee, ensuring a hassle-free return process if you encounter any issues within this period.

8.2 Customer Support

For any problems, questions, or support needs regarding your JustFine Replacement Remote Control, please contact us via email. Refer to your purchase documentation for specific contact details.