Kidzlane KL-0566

Kidzlane Laser Tag Guns Instruction Manual

Model: KL-0566

Introduction

Welcome to your Kidzlane Laser Tag Set. This manual provides essential information for setting up, operating, and maintaining your infrared laser blasters for an engaging multiplayer experience. Please read these instructions carefully before use.

Safety Information

For external use only. This toy is certified safe for children of all ages with a Child Safety Infrared Signal Emission that is less than 1mW. Always ensure a safe play environment, free from obstacles and hazards.

Package Contents

- Laser Tag Guns Set of 4



Image: The complete set of four Kidzlane laser tag guns, each in a distinct color, ready for play.

Setup

1. **Battery Installation:** Each laser tag gun requires 4 AAA batteries (not included). Locate the battery compartment, typically on the handle, open it, insert the batteries according to polarity, and close the compartment securely.
2. **Power On:** Locate the On/Off Switch on the side of the blaster and slide it to the 'On' position. The blaster will emit a startup sound and lights will illuminate.



Image: A detailed diagram highlighting the various components of the laser tag gun, including the On/Off switch and other controls.

Operating Instructions

1. **Team Selection:** After powering on, press the 'Team Select Button' (usually a circular button on the side) to cycle through the four available team colors: Red, Green, Blue, or White. The indicator light on your blaster will change to reflect your chosen team. Players on the same team cannot hit each other.
2. **Gun Mode Selection:** Press the 'Gun Mode Select Button' (often located near the trigger) to choose from four different weapon types: Pistol, Shotgun, Submachine Gun, and Rocket. Each mode features unique sound effects, varying damage output (life bars deducted per hit), and different ammunition capacities before requiring a reload.
3. **Shooting:** Aim your blaster at the Infrared Target Area on an opponent's gun. Pull the 'Trigger' to fire. The blaster will light up and vibrate, accompanied by realistic shooting sounds.
4. **Reloading:** When your ammunition runs out, you will hear a sound indicating the need to reload. Press the 'Reload Button' (located at the bottom of the handle, like a magazine release) to replenish your ammo.
5. **Life Indicator:** The 'Life Bar Indicator' (a series of lights on the side of the blaster) displays your remaining lives. Each time you are hit by an opponent, one or more lights will turn off, and your blaster will vibrate. When all lights are off, you are out of the game.



Image: An illustration detailing the different gun modes and team color options available for gameplay.

Your browser does not support the video tag.

Video: An official product video demonstrating the Kidzlane Laser Tag guns in action, showcasing gameplay and features.

Features

- **4 Team Action:** Organize battles with up to four teams (Green, Red, Blue, White).
- **4 Gun Settings:** Select from Pistol, Shotgun, Submachine Gun, and Rocket modes, each with unique effects.
- **Realistic Sounds & Vibration:** Blasters light up and vibrate with ultra-realistic shooting sounds for an immersive experience.
- **Extended Range:** Enjoy a shooting range of up to 130 feet.
- **Child Safety Infrared:** Features a Child Safety Infrared Signal Emission of less than 1mW, ensuring safe play.



Image: A child actively engaged in laser tag, demonstrating the outdoor play capability of the product.

Maintenance

- **Cleaning:** Wipe the blasters with a dry, soft cloth. Do not use harsh chemicals or immerse in water.
- **Storage:** Store the blasters in a cool, dry place away from direct sunlight when not in use. Remove batteries if storing for extended periods to prevent leakage.

Troubleshooting

- **No Power/Not Responding:** Ensure batteries are correctly installed and are fresh. Replace all batteries if necessary.
- **Difficulty Hitting Opponents:** Ensure there is a clear line of sight between your blaster and the opponent's Infrared Target Area. Obstructions can block the infrared signal.
- **Incorrect Team Color:** Press the 'Team Select Button' repeatedly until the desired team color is displayed.

Specifications

- **Product Dimensions:** 12.5 x 7.5 x 7.25 inches
- **Item Weight:** 12.3 ounces
- **Item Model Number:** KL-0566
- **Manufacturer Recommended Age:** 8 - 12 years
- **Batteries:** 4 AAA batteries required per gun (not included)



Image: The dimensions of a single Kidzlane laser tag gun are clearly indicated on the image.

Warranty & Support

For any questions, concerns, or support needs regarding your Kidzlane Laser Tag Guns, please contact Kidzlane customer support. Refer to the product packaging or the official Kidzlane website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question