Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine LYSB01LZ68I73-ELECTRNCS

JustFine Replacement Remote Control User Manual

Compatible with Samsung LED HDTV Models: UN60ES7100F, PN60E6500, UN55ES6500F, UN55ES8000, UN55ES8000FXZA

1. Introduction

This document provides instructions for the JustFine replacement remote control, designed for use with specific Samsung LED HDTV models. This remote is pre-programmed and requires no additional setup for basic functionality.



This image displays the JustFine replacement remote control. It is a sleek, black, elongated device with a central circular button, designed for ergonomic handling.

2. Setup

To begin using your replacement remote control, follow these simple steps for battery installation:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or press the cover to open the compartment.
3. Insert two (2) AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

The remote is now ready for operation. No programming is required.

3. Operating Instructions

This replacement remote control is pre-programmed for immediate use with compatible Samsung LED HDTV models. Simply point the remote control towards your television and press the desired function button.

- **Power Button:** Turns the television on or off.
- **Volume Up/Down:** Adjusts the television's volume level.
- **Channel Up/Down:** Changes the television channel.
- **Number Buttons:** Directly input channel numbers.
- **Menu/Settings:** Accesses the television's on-screen menu.
- *Other buttons:* Utilize other buttons as labeled for their respective functions (e.g., Source, Mute, Guide, etc.).

4. Maintenance

Proper care and maintenance will extend the life of your remote control:

- **Cleaning:** Use a soft, dry cloth to clean the remote's surface. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance diminishes or it stops responding. Always replace both batteries at the same time with new ones.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

If you encounter issues with your remote control, consider the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the television's infrared sensor.
  - Ensure you are within the effective range of the television's IR receiver.
- **Specific Buttons Not Working:**
  - Clean the remote's surface, especially around the problematic buttons, to remove any debris.
  - If only certain buttons fail, it might indicate internal damage.
- **Interference:** Strong light sources or other electronic devices can sometimes interfere with infrared signals. Try operating the remote in a different environment.

If problems persist after attempting these steps, please refer to the Warranty and Support section.

6. Specifications

Brand	JustFine

Model Number	LYSB01LZ68I73-ELECTRNCS
Product Dimensions	8 x 2 x 0.5 inches
Item Weight	2.72 ounces
Compatible Devices	Television (Samsung LED HDTVs)
Connectivity Technology	Infrared
Special Feature	Ergonomic
Max Number of Supported Devices	1

7. Warranty and Support

This replacement remote control comes with a 30-day quality warranty and a money-back guarantee for hassle-free returns.
For any problems or inquiries regarding your remote control, please contact the seller directly. Provide your purchase details and a clear description of the issue to receive prompt assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LZ68I73

More documents and user manuals: **https://manuals.plus/**