Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine SG_B01LZSIQPH_US

JustFine Replacement Remote Control Instruction Manual

For Samsung DVD and Blu-Ray Disc Players

1. Introduction

This manual provides comprehensive instructions for the JustFine Replacement Remote Control. This remote is designed to be compatible with various Samsung DVD and Blu-Ray Disc Player models, offering a seamless replacement for your original remote. It comes pre-programmed and requires no additional setup, allowing for immediate use upon battery installation.

2. Setup

2.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control.



Figure 1: Battery compartment on the back of the remote control.

Video 1: Demonstration of battery installation and basic remote overview.

3. Operating Instructions

The JustFine Replacement Remote Control is pre-programmed to work with compatible Samsung DVD and Blu-Ray Disc Players. No additional programming is required.

3.1. Basic Functions

- **Power (Red Button):** Turns the connected device on or off.
- **Source:** Cycles through available input sources (e.g., HDMI 1, HDMI 2, TV).
- **Volume (+/-):** Adjusts the audio volume.
- **Channel (CH Up/Down):** Changes channels (for TV mode) or navigates menus.
- **Mute:** Silences the audio output.

3.2. Playback Controls

- **Play (►):** Starts playback of media.
- **Pause ( ):** Pauses playback.
- **Stop (■):** Stops playback.
- **Fast Forward ( ):** Advances media quickly.
- **Rewind ( ):** Rewinds media quickly.
- **Skip (/):** Skips to the next or previous track/chapter.

3.3. Menu Navigation and Special Functions

- **Directional Pad (Up, Down, Left, Right):** Navigates through on-screen menus and options.
- **Enter (Center Button):** Confirms selections.
- **Menu:** Accesses the main menu of the device.
- **Return:** Goes back to the previous screen or menu.
- **Exit:** Exits the current menu or function.
- **Subtitle:** Toggles subtitle options.
- **Audio:** Selects audio tracks or modes.
- **Colored Buttons (A, B, C, D):** These buttons typically correspond to specific functions within menus or interactive content, as indicated on-screen.



Figure 2: Front view of the remote control with all functional buttons.

Video 2: Demonstration of various button functions on the remote control.

Video 3: Overview of the remote control's features and functionality.

4. Compatible Models

This JustFine Replacement Remote Control is compatible with the following Samsung DVD and Blu-Ray Disc Player models:

- Samsung BDF5700M
- Samsung AK5900177A
- Samsung AK5900177B
- Samsung BD-HM57C
- Samsung BDF6700

It may also be compatible with other Samsung DVD/Blu-Ray Player models not explicitly listed. Please refer to your device's original manual for remote compatibility if your model is not listed above.

5. Product Specifications

Feature	Specification
Brand	JustFine
Model Number	SG_B01LZSIQPH_US
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.39 ounces
Connectivity Technology	Infrared
Max Number of Supported Devices	1
Special Feature	Ergonomic

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** Store the remote in a dry place away from direct sunlight and extreme temperatures. If not in use for an extended period, remove the batteries to prevent leakage.

7. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed and not depleted. Replace if necessary.
  - Check for any obstructions between the remote and the device's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the device.
- **Specific buttons not working:**
  - Some buttons may be specific to certain device models or functions. Refer to your device's original manual for specific button functionalities.

- Clean the remote's surface and buttons to ensure no debris is interfering with button presses.

- **Interference:**
  - Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with infrared signals. Try operating the remote in different lighting conditions.

8. Warranty and Support

This JustFine Replacement Remote Control is sold with a 30-day quality warranty and hassle-free return policy. If you encounter any problems or have questions regarding the remote control, please contact the seller directly for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question