Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

B&I 2166573

Hayden SuperValve with 110V and Small Door-Almond

INSTRUCTION MANUAL

Product Overview

The Hayden SuperValve is a specialized valve designed for various applications, featuring a compact design with an almond finish. This unit operates on 110V power and is manufactured by Hayden, known for genuine and reliable components. This manual provides essential information for the proper installation, operation, and maintenance of your SuperValve.



This image displays the Hayden SuperValve, featuring its almond-colored faceplate designed for a small door application. The white housing, which contains the electrical components, is visible behind the faceplate, with black and white electrical wires extending from the top. The unit is designed for 110V operation.

Safety Information

Please read all safety instructions carefully before installing or operating the Hayden SuperValve. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect power before installing, servicing, or cleaning the unit.
- Installation should be performed by a qualified electrician or technician in accordance with all local and national electrical codes.
- Do not operate the valve if it appears damaged.
- Ensure proper grounding to prevent electrical hazards.
- Keep away from water and moisture. This device is not designed for outdoor or wet environments unless specifically rated.

Installation and Setup

The Hayden SuperValve is designed for straightforward installation, but professional assistance is recommended for electrical connections.

1. **Preparation:** Ensure the power supply to the installation area is turned off at the circuit breaker. Gather necessary tools, including screwdrivers, wire strippers, and electrical tape.
2. **Mounting:** Secure the SuperValve unit to a stable surface or junction box using appropriate fasteners. Ensure the unit is level and securely mounted.
3. **Electrical Connection:** Connect the 110V power supply wires to the corresponding wires on the SuperValve. Typically, this involves connecting the live (black), neutral (white), and ground (green/bare copper) wires. Refer to local electrical codes for specific wiring requirements.
4. **Testing:** Once all connections are secure and insulated, restore power to the circuit. Test the valve's functionality according to the operating instructions.

Note: If you are unsure about any step of the installation process, consult a licensed electrician.

Operation

The Hayden SuperValve is designed for simple operation. Specific operational details may vary based on the system it is integrated into.

- **Activation:** The valve typically activates or deactivates based on an external signal or switch connected to its 110V control circuit.
- **Indicator:** If equipped, an indicator light or audible click may confirm the valve's operational status (open/closed).
- **Manual Override:** Some installations may include a manual override feature. Consult your system's specific setup for details.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Hayden SuperValve.

- **Cleaning:** Periodically wipe the exterior of the valve with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Inspection:** Annually inspect all electrical connections for tightness and signs of wear or corrosion. Check the valve for any physical damage.
- **Professional Check:** For critical applications, consider having the unit inspected by a qualified technician every few years.

Troubleshooting

If you encounter issues with your Hayden SuperValve, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Valve not responding	No power, loose wiring, faulty control signal.	Check power supply, inspect wiring connections, verify control signal.
Unusual noise during operation	Internal obstruction, worn components.	Disconnect power and inspect for obstructions. If noise persists, contact support.
Intermittent operation	Loose connections, fluctuating power.	Secure all electrical connections. Ensure stable 110V power supply.

If the problem persists after attempting these solutions, please contact customer support. Do not attempt to repair internal components unless you are a qualified technician.

Specifications

Attribute	Detail
Manufacturer	Hayden
Part Number	2166573
Item Weight	9.3 ounces
Package Dimensions	7.17 x 5.83 x 3.46 inches
Color	Almond
Item Package Quantity	1
UPC	759119310561, 745332166573
ASIN	B01M03D28O
Voltage	110V

Warranty Information

For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact Hayden directly. Warranty coverage typically includes defects in materials and workmanship for a specified period from the date of purchase.

Customer Support

If you require further assistance, have questions about installation, or need to report a defect, please contact the manufacturer, Hayden, or your authorized distributor. Have your model number (2166573) and purchase details ready when contacting support.
For general inquiries, you may also refer to the official Hayden website or contact the seller from whom you purchased the product.

© 2024 Hayden. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M03D28O

More documents and user manuals: **https://manuals.plus/**