Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine RMYD026

JustFine Replacement Remote Control User Manual for Sony TVs (RMYD026)

This manual provides comprehensive instructions for the setup, operation, and maintenance of your JustFine replacement remote control, compatible with various Sony television models.

1. Introduction

The JustFine RMYD026 is a pre-programmed replacement remote control designed for seamless compatibility with a wide range of Sony PLASMA, LCD, LED, BRAVIA, and XBR HDTV television models. This remote is ready for use upon battery installation, requiring no additional programming.
Before using, please ensure that the buttons on this replacement remote align with the functions you require for your specific Sony TV model.

2. Package Contents

- 1 x JustFine Replacement Remote Control (RMYD026)
- *Note: Batteries and instruction manual are not included in the package.*

3. Setup: Battery Installation

To begin using your remote control, you must install batteries. This remote requires two AAA batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

The remote is now ready for operation with your compatible Sony TV.

4. Operating Instructions

This JustFine replacement remote control is pre-programmed for various Sony TV models. No additional programming steps are required. Simply point the remote at your television and press the desired function button.
Ensure there are no obstructions between the remote control and the TV's infrared sensor. For optimal performance, maintain a clear line of sight.

5. Button Functions Overview

Below is an illustration of the remote control with a description of its primary buttons and their functions.



An image showing the full layout of the JustFine replacement remote control, featuring various buttons for power, channel, volume, navigation, and specific Sony TV functions like BRAVIA Sync and Home.

Button	Function Description
POWER	Turns the TV on or off.
DISPLAY	Displays on-screen information such as channel number, time, and program details.
SLEEP	Sets the sleep timer for automatic TV shutdown.
BRAVIA Sync	Accesses BRAVIA Sync menu for controlling compatible HDMI-connected devices.

Button	Function Description
PLAY (►), PAUSE ( ), STOP ( ), REWIND ( ), FAST FORWARD ( )	Controls playback of media (e.g., from connected devices or USB).
THEATER	Activates or deactivates Theater mode for optimized audio/video settings.
SYNC MENU	Opens the BRAVIA Sync menu.
CC (Closed Caption)	Toggles closed captions on or off.
FAVORITES	Accesses favorite channels or content.
FREEZE	Pauses the current image on screen.
AUDIO	Selects audio tracks or modes.
GUIDE	Opens the electronic program guide (EPG).
INPUT	Cycles through available input sources (HDMI, AV, etc.).
Navigation Pad (Up, Down, Left, Right, Enter)	Navigates through menus and confirms selections.
RETURN	Goes back to the previous menu or screen.
OPTIONS	Displays context-sensitive options for the current screen.
MENU	Opens the main TV menu.
HOME	Accesses the TV's Home screen or Smart TV portal.
DIGITAL/ANALOG	Switches between digital and analog TV channels.
PICTURE	Adjusts picture settings.
WIDE	Changes the screen aspect ratio.
Number Buttons (0-9)	Directly selects channels or enters numerical values.
VOL +/- (Volume)	Increases or decreases the TV volume.
CH +/- (Channel)	Changes the TV channel up or down.
MUTING	Mutes or unmutes the TV audio.
JUMP	Switches between the current and previously viewed channel.
TV	Switches to TV mode.

6. Maintenance and Care

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environment:** Avoid exposing the remote to extreme temperatures, direct sunlight, moisture, or dust.

7. Troubleshooting

Problem	Solution
Remote control is not working.	◦ Check if the batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old batteries with new AAA batteries. ◦ Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Point the remote directly at the TV's sensor.
Some buttons do not function.	◦ Verify that your TV model is compatible with all functions of this replacement remote. Some advanced or specific functions might not be supported by all Sony TV models. ◦ Clean the remote's surface and buttons to ensure no debris is interfering with button presses.
Remote works intermittently.	◦ This often indicates low battery power. Replace the batteries. ◦ Ensure a clear line of sight to the TV.

8. Product Specifications

- **Brand:** JustFine
- **Model:** RMYD026 (Replacement Remote Control)
- **Compatible Devices:** Sony Televisions (PLASMA, LCD, LED, BRAVIA, XBR HDTV)
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** 4.53 x 1.57 x 1.38 inches
- **Item Weight:** 2.72 ounces
- **Special Feature:** Ergonomic design

9. Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty, ensuring a hassle-free return process if issues arise.
For any problems, questions, or support needs regarding your JustFine replacement remote control, please contact the seller directly via email. Refer to your purchase documentation for contact information.

© 2025 JustFine. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M0FEUOE

More documents and user manuals: **https://manuals.plus/**