Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine RM-YD065

JustFine Replacement Remote Control for Sony TVs

Brand: JustFine | **Model:** RM-YD065 Compatible

1. Introduction

This manual provides instructions for the JustFine replacement remote control, designed for use with various Sony television models. This remote is pre-programmed and requires no additional setup for compatible Sony TVs. Please read this manual thoroughly to ensure proper operation and longevity of your remote control.

Compatibility: This remote is compatible with numerous Sony TV models, including but not limited to: KDL-40V2500, KDL-32SL130, KLV-52V410A, RM-YD065, KDL-40SL150, KDL-32FA500, KDLV32XBR2, KDL32S3000/W, KLV46W410A, KDL40BX420B, and KDL40S51009.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Dispose of used batteries according to local regulations.

3. Package Contents

- 1 x JustFine Replacement Remote Control

Note: Batteries and additional instructions are not included in the package.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly. For this remote, the positive (+) side of the batteries should face downwards towards the spring contact.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Back view of the remote control with the battery compartment.

4.2 Initial Use

This replacement remote control is pre-programmed and does not require any additional programming or pairing with your Sony TV. Once batteries are installed, it should function immediately with compatible models.

5. Operating Instructions

The remote control features a standard layout for easy navigation and control of your Sony television. Refer to the image below for button identification.



Figure 2: Front view of the remote control with button layout.

5.1 Button Functions

- **POWER (Green Button):** Turns the TV on or off.
- **DISPLAY:** Shows on-screen information.
- **SLEEP:** Sets the TV sleep timer.
- **BRAVIA Sync** / **PLAY** / **PAUSE:**Controls BRAVIA Sync compatible devices and media playback.
- **SYNC MENU:** Accesses the BRAVIA Sync menu.
- **CC (Closed Caption):** Toggles closed captions.
- **GUIDE:** Displays the electronic program guide.
- **FAVORITES:** Accesses favorite channels.
- **FREEZE:** Freezes the current picture.
- **AUDIO:** Adjusts audio settings or selects audio tracks.
- **THEATER:** Activates Theater mode.
- **INPUT:** Selects input sources (HDMI, AV, etc.).
- **RETURN:** Returns to the previous screen or menu.
- **Navigation Pad (Up, Down, Left, Right, ENTER):**Navigates menus and confirms selections.
- **HOME:** Accesses the TV's main home menu.
- **MENU:** Opens the TV's main menu.
- **OPTIONS:** Displays context-sensitive options.
- **DM+** / **PICTURE WIDE** / **DIGITAL ANALOG:**Multi-function buttons, their exact function may vary by TV model.
- **Number Pad (0-9):** Direct channel entry.
- **VOL (+/-):** Adjusts volume up or down.
- **CH (+/-):** Changes channels up or down.
- **MUTE:** Mutes or unmutes the TV audio.
- **JUMP:** Switches between the current and previously viewed channel.
- **TV:** Switches to TV input.

6. Troubleshooting

- **Remote not responding:**
  - Ensure fresh batteries are correctly installed with the correct polarity (+/-).
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV.
- **Buttons feel sticky or unresponsive:**
  - This can sometimes occur with replacement remotes. Gently press the button multiple times to see if it loosens.
  - Ensure the remote is clean and free of debris.
- **Remote controls some functions but not others:**
  - While this remote is broadly compatible, some advanced or specific functions may not be supported by all Sony TV models.
  - Verify your TV model is listed in the compatibility section.

7. Specifications

Feature	Detail

Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	1.44 ounces
Color	Black
Compatible Devices	Television (Various Sony models)
Max Number of Supported Devices	1
Special Feature	Ergonomic design

8. Warranty and Support

This product comes with a**30-day quality warranty** from the date of purchase.

For any issues, questions, or support needs regarding your JustFine replacement remote control, please contact the seller directly. Provide your purchase details for efficient assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M0FLKKE

More documents and user manuals: **https://manuals.plus/**