Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine LYSB01M0RNRCB

JustFine Replacement Remote Control User Manual

For Samsung BD Blu-Ray DVD Disc Players

1. Introduction

Thank you for choosing the JustFine Replacement Remote Control. This remote is designed to provide seamless control for your compatible Samsung BD Blu-Ray DVD Disc Player. It is pre-programmed and ready to use with no additional setup required beyond battery installation.

2. Product Overview

This replacement remote control is specifically designed to be compatible with the following Samsung BD Blu-Ray DVD Disc Player models:

- BD-EM59C
- BDE5700
- BD-E6500
- BD-ES6000/ZA
- BD-FM59C

The remote features an ergonomic design for comfortable handling and operates using infrared technology.



Figure 1: JustFine Replacement Remote Control. This image shows the black, ergonomic remote control with its primary navigation and playback buttons visible on the top surface, and the battery compartment cover on the underside.

3. Setup

3.1 Battery Installation

The remote control requires alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two new alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Important: This remote control is pre-programmed and does not require any additional programming steps. Simply insert the batteries, and it is ready for use with your compatible Samsung Blu-Ray DVD Disc Player.

4. Operating Instructions

Point the remote control directly at your Samsung Blu-Ray DVD Disc Player. The maximum operating range is approximately 10 meters (33 feet).

4.1 Basic Functions

The remote provides essential controls for your disc player. While specific button layouts may vary slightly, common functions include:

- **Power Button:** Turns the disc player on or off.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate menus and select options.
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind):** Manages disc playback.
- **Volume Controls:** Adjusts the audio output volume.
- **Menu/Home Button:** Accesses the player's main menu or home screen.

Refer to your Samsung Blu-Ray DVD Disc Player's original manual for detailed information on specific functions and menu navigation.

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new alkaline batteries.
  - Check for any obstructions between the remote and the disc player's infrared sensor.
  - Ensure you are within the maximum operating range (10 meters).
- **Specific Buttons Not Working:**
  - Clean the remote's surface, especially around the unresponsive buttons, to remove any debris.
  - Confirm that the function you are trying to use is supported by your specific Samsung Blu-Ray DVD Disc Player model.

If problems persist after trying these steps, please contact customer support.

7. Specifications

Feature	Detail
Brand	JustFine
Model Number	LYSB01M0RNRCB-ELECTRNCS
Compatible Devices	Samsung BD Blu-Ray DVD Disc Players
Connectivity Technology	Infrared (IR)
Maximum Range	10 Meters (approx. 33 feet)
Battery Type	Alkaline (2x AAA, not included)
Color	Black
Special Feature	Ergonomic Design
Item Weight	0.17 Pounds (approx. 77 grams)

8. Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty. For any problems or inquiries, please contact us directly via email. We offer hassle-free returns.
For support, please refer to the contact information provided at the point of purchase or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M0RNRCB

More documents and user manuals: **https://manuals.plus/**