vhbw BW800106836

vhbw Charger Instruction Manual

Model: BW800106836

Introduction

This manual provides instructions for the safe and efficient use of your vhbw charger, designed for various digital camera, camcorder, DSLR, and action camera batteries. Please read this manual carefully before use and retain it for future reference.

Package Contents

- 1 x vhbw Charger Unit
- 1 x European 220V Power Plug Cable
- 1 x 12V Car Adapter Cable



This image displays the vhbw charger unit, featuring a slot for a camera battery, an LED charge indicator, and the model number BW800106836. Also shown are the included power cables: a European 220V plug cable and a 12V car adapter cable.

Setup

1. **Connect to Power:**
   a. For home use, connect the European 220V power plug cable to the charger unit, then plug it into a standard wall outlet.
   b. For car use, connect the 12V car adapter cable to the charger unit, then plug it into your vehicle's 12V accessory socket (cigarette lighter).
2. **Insert Battery:** Carefully insert the compatible camera battery into the designated slot on the charger unit. Ensure the battery is correctly oriented according to the markings on the charger.

Operating Instructions

1. **Charging Indication:** Once the battery is correctly inserted and the charger is connected to a power source, the LED indicator on the charger will illuminate to show the charging status.
2. **Charging Process:** The charger will automatically begin rapid charging the battery.
3. **Completion of Charge:** Upon completion of the charging cycle, the charger will automatically switch to a maintenance charge mode to prevent overcharging and prolong battery life. The LED indicator will change to reflect the full charge status.
4. **Remove Battery:** Once fully charged, carefully remove the battery from the charger. Disconnect the charger from the power source when not in use.

Maintenance

- Keep the charger clean and dry. Use a soft, dry cloth to wipe the surface.
- Avoid exposing the charger to extreme temperatures, direct sunlight, or high humidity.
- Do not attempt to disassemble or modify the charger. This may void any potential warranty and pose a safety risk.
- Store the charger in a cool, dry place when not in use.

Troubleshooting

- **Charger not working:**
  a. Ensure all cables are securely connected to the charger and the power source.
  b. Verify that the power outlet or car accessory socket is functional.
- **Battery not charging:**
  a. Confirm the battery is correctly inserted into the charger slot.
  b. Check if the battery itself is damaged or at the end of its lifespan.

If issues persist after performing these checks, please contact vhbw customer support for further assistance.

Specifications

Feature	Specification
Model Number	BW800106836
Input AC	220 V, 12 V
Output Voltage	DC 4.2 V
Output Current	DC 0.6 A
Number of Battery Slots	1
Color	Black
Total Cable Length (approx.)	88.5 cm
Compatible Devices	Digital Cameras, Camcorders, DSLRs, Action Cams

Warranty and Support

For information regarding warranty terms and conditions, please refer to the documentation provided at the time of purchase or visit the official vhbw website.

For technical support, troubleshooting assistance, or any other inquiries, please contact vhbw customer service through their official channels.