Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

havit HV-G92

Havit HV-G92 Game Pad User Manual

Model: HV-G92 | Brand: Havit

1. Introduction

Thank you for purchasing the Havit HV-G92 Game Pad. This wired controller is designed for an immersive gaming experience on PC, offering precise control and comfortable ergonomics. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

2. Safety Information

- Keep the device away from water, moisture, and extreme temperatures.
- Do not attempt to disassemble or repair the game pad yourself. Refer all servicing to qualified personnel.
- Avoid dropping or subjecting the game pad to strong impacts.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure proper ventilation around the device during prolonged use.

3. Package Contents

The Havit HV-G92 Game Pad package includes:

- 1 x Havit HV-G92 Game Pad (Blue)
- 1 x Software CD (for drivers, if needed)



Figure 3.1: Havit HV-G92 Game Pad in its retail packaging. The image shows the blue transparent gamepad inside a clear plastic and cardboard box, with the Havit logo and "GAMEPAD" text visible.

4. Product Overview

The Havit HV-G92 Game Pad features a classic controller layout with ergonomic grips for comfortable extended play sessions. It includes essential controls for various gaming genres.



Figure 4.1: Front view of the Havit HV-G92 Game Pad. The blue transparent gamepad is shown with its wired USB connection. Key features visible include the D-pad on the left, four action buttons (1, 2, 3, 4) on the right, two analog sticks, and central function buttons

(Mode, Turbo, Clear, Auto).

4.1. Controls and Buttons

Component	Description
D-Pad (Directional Pad)	8-direction input for precise movement or menu navigation.
Action Buttons (1, 2, 3, 4)	Primary action inputs, typically mapped to in-game actions.
Analog Sticks (2)	For 360-degree movement and camera control in games.
Shoulder Buttons (L1, L2, R1, R2)	Additional action buttons located on the top of the gamepad.
MODE Button	Switches between digital and analog modes for the D-pad and left analog stick.
TURBO Button	Activates rapid-fire function for selected buttons.
CLEAR Button	Deactivates the TURBO function.
AUTO Button	Enables automatic rapid-fire for selected buttons without holding them down.
SELECT/BACK Button	Typically used for menu selection or in-game functions.
START Button	Initiates games or pauses gameplay.

5. Setup

5.1. Connecting to PC

1. Locate an available USB port on your computer.
2. Plug the USB connector of the Havit HV-G92 Game Pad into the USB port.
3. Your operating system (e.g., Windows) should automatically detect and install the necessary drivers. This is a plug-and-play device.
4. If automatic installation fails, insert the provided software CD into your computer's CD/DVD drive and follow the on-screen instructions to install the drivers manually.
5. Once drivers are installed, the game pad is ready for use.

6. Operating Instructions

6.1. Basic Operation

- After connecting, launch your desired game. Most modern games will automatically recognize the gamepad.
- If the game does not recognize the gamepad, check the game's control settings and configure them for a gamepad.

6.2. TURBO Function

The TURBO function allows for rapid, continuous input of a button press without repeatedly pressing the button.

1. Press and hold the button you wish to set to TURBO (e.g., Action Button 1).
2. While holding the action button, press the **TURBO** button once.
3. Release both buttons. The selected action button will now function in TURBO mode.

6.3. AUTO Function

The AUTO function enables automatic rapid-fire without needing to hold down the button.

1. Press and hold the button you wish to set to AUTO (e.g., Action Button 2).
2. While holding the action button, press the **AUTO** button once.
3. Release both buttons. The selected action button will now automatically rapid-fire.

6.4. CLEAR Function

To deactivate the TURBO or AUTO function for a specific button:

1. Press and hold the button for which you want to clear the TURBO/AUTO setting.
2. While holding the action button, press the **CLEAR** button once.
3. Release both buttons. The TURBO/AUTO function for that button will be deactivated.

To clear all TURBO/AUTO settings, press and hold the **CLEAR** button for approximately 3 seconds.

6.5. Vibration Feedback

The Havit HV-G92 Game Pad features built-in motors for dual vibration feedback, providing a more immersive gaming experience. This feature is automatically activated in games that support vibration feedback.

7. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the surface of the game pad. For stubborn dirt, slightly dampen the cloth with water. Do not use alcohol, benzene, thinners, or other chemical cleaners, as they may damage the surface.
- **Storage:** When not in use, store the game pad in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tangling the USB cable.
- **Cable Care:** Do not pull on the cable to disconnect the game pad from the computer. Always grasp the USB plug firmly. Avoid bending or crimping the cable excessively.

8. Troubleshooting

Problem	Possible Cause / Solution
Game pad not recognized by PC.	◦ Ensure the USB cable is securely plugged into a working USB port. Try a different USB port. ◦ Restart your computer. ◦ Install drivers from the provided CD if automatic installation failed. ◦ Check Device Manager in Windows to see if the device is listed and if there are any driver issues.

Problem	Possible Cause / Solution
Buttons or analog sticks are unresponsive.	◦ Ensure the game pad is properly connected. ◦ Check in-game control settings to ensure the gamepad is selected and configured correctly. ◦ Test the gamepad using a Windows Game Controller setup (search "Set up USB game controllers" in Windows). ◦ Some games may require specific controller emulation software.
Vibration feedback is not working.	◦ Verify that the game you are playing supports vibration feedback. ◦ Check the game's audio/vibration settings to ensure vibration is enabled. ◦ Ensure drivers are correctly installed.

9. Specifications

Feature	Detail
Model	HV-G92
Brand	Havit
Controller Type	Wired Gamepad
Connectivity	USB Plug and Play
Compatibility	PC (Windows)
Number of Buttons	12 Action Buttons + 8-direction D-Pad
Analog Sticks	2
Special Functions	Turbo, Clear, Auto, Dual Vibration
Ergonomics	Ergonomic shape with rubberized grips
Color	Blue
Item Weight	300 g
Package Dimensions	17.8 x 16.8 x 7.4 cm

10. Warranty and Support

10.1. Warranty Information

The Havit HV-G92 Game Pad comes with a**1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects and faulty workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.
Please retain your purchase receipt as proof of purchase for warranty claims.

10.2. Customer Support

For technical support, warranty claims, or further inquiries, please contact Havit customer service through their official website or the contact information provided with your product packaging.
You may also refer to the official Havit website for updated drivers or FAQswww.havit.com

© 2024 Havit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M7MRNNX

More documents and user manuals: **https://manuals.plus/**