Ariete 00P414602AR0

Ariete XVapor Deluxe 4146 Steam Cleaner User Manual

Model: 00P414602AR0

Introduction

This manual provides essential information for the safe and efficient operation of your Ariete XVapor Deluxe 4146 Steam Cleaner. Please read it thoroughly before first use and keep it for future reference.
The Ariete XVapor Deluxe 4146 is a powerful steam cleaner designed to sanitize and clean various household surfaces using only the natural force of steam, eliminating the need for chemical detergents. Its integrated accessory compartment ensures convenience and accessibility of tools for comprehensive cleaning tasks.

Safety Instructions

- Always unplug the appliance from the power outlet before filling, emptying, or cleaning.
- Do not leave the appliance unattended when plugged in.
- Keep out of reach of children and pets.
- Do not direct steam at people, animals, or electrical appliances.
- Use only distilled or demineralized water to prevent limescale buildup.
- Ensure the cap is securely tightened before operating.
- Do not open the water tank cap while the appliance is under pressure.
- Always allow the appliance to cool down completely before storing.

Product Overview

The Ariete XVapor Deluxe 4146 is a mobile steam cleaner with a robust design and a convenient integrated accessory compartment. It features a 1.6-liter water tank and operates at 1500 Watts, providing 5 bars of pressure for effective cleaning.



Image: The Ariete XVapor Deluxe 4146 Steam Cleaner, showing its compact design and integrated hose.



Image: Key features of the Ariete XVapor Deluxe 4146, including 1500W power, 1.6L capacity, removable tank cap, and steam regulation control.

Components Included:

- Main Steam Unit
- Flexible Hose with Steam Gun
- Floor Brush
- Window Cleaning Tool
- Large Round Brush
- Small Round Brush
- 90° Nozzle
- Fabric Brush with Cap
- Microfiber Cloth
- Measuring Cup

- Funnel
- Extension Tubes (2)



Image: The Ariete XVapor Deluxe 4146 with its integrated accessory compartment open, showcasing the convenient storage for various cleaning tools.



Image: A comprehensive view of all included accessories for the Ariete XVapor Deluxe 4146, including brushes, nozzles, extension tubes, and cloths.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Water Filling:** Unscrew the safety cap of the water tank. Using the provided measuring cup and funnel, fill the tank with up to 1.6 liters of distilled or demineralized water. Do not overfill. Securely tighten the safety cap.
3. **Accessory Attachment:** Select the appropriate accessory for your cleaning task. Attach it firmly to the steam gun or extension tubes as required.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

1. **Heating Up:** Once plugged in, the indicator light will illuminate, signaling that the unit is heating. The steam cleaner will be ready for use in a few moments (approximately 8 minutes). The indicator light will turn off when optimal pressure is reached.
2. **Steam Release:** Press the steam activation button on the steam gun to release steam. For continuous steam, engage the lock switch on the handle.
3. **Steam Regulation:** Use the steam regulation control knob on the main unit to adjust the intensity of the steam output.
4. **Cleaning Surfaces:**
    - **Floors:** Attach the floor brush with a microfiber cloth. Move the brush slowly over the surface to allow steam to penetrate and clean.
    - **Windows/Glass:** Use the window cleaning tool. Apply steam and wipe with a clean cloth for streak-free results.



Image: A hand holding the steam gun with the window cleaning attachment, demonstrating its use on a window.

- **Tiles/Grout:** Use the small round brush or 90° nozzle for targeted cleaning of grout lines and stubborn spots.



Image: A hand holding the steam gun with a nozzle attachment, directing steam onto a tiled surface for deep cleaning.

- **Kitchen Surfaces (e.g., stovetops):** The 90° nozzle or small round brush can be effective for grease and grime.



Image: A hand holding the steam gun with a nozzle attachment, applying steam to a stovetop burner for cleaning.

- **Fabrics/Upholstery:** Use the fabric brush with a microfiber cloth. Test on an inconspicuous area first.



Image: A hand holding the steam gun with a fabric brush attachment, cleaning a blue upholstered sofa.

5. **Refilling:** If the steam output decreases or stops, the water tank may be empty. Unplug the unit and allow it to cool down for at least 10 minutes before carefully unscrewing the safety cap and refilling.
6. **Shutting Down:** When finished, release any remaining steam pressure by pressing the steam button until no more steam is emitted. Unplug the unit from the power outlet.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Emptying Water Tank:** After each use, once the unit has cooled down and depressurized, carefully empty any remaining water from the tank.
- **Cleaning Accessories:** Wash all accessories with warm, soapy water and rinse thoroughly. Allow them to air dry completely before storing.
- **Descaling:** If you notice reduced steam output or mineral buildup, descale the unit. Consult a qualified technician or refer to specific descaling instructions if provided by the manufacturer. Using distilled water significantly reduces the need for descaling.
- **Exterior Cleaning:** Wipe the exterior of the unit with a damp cloth. Do not use abrasive cleaners or solvents.

- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, ideally in its original packaging or the integrated accessory compartment.

Troubleshooting

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty. Unit not heated sufficiently. Limescale buildup.	Refill water tank (after cooling). Wait for indicator light to turn off. Descale the unit.
Water leaking from accessories.	Accessories not properly attached. Unit not fully heated.	Ensure accessories are securely fastened. Wait for the unit to reach full operating temperature.
Unit not turning on.	Not plugged in. Power outlet issue.	Check power cord connection. Test outlet with another appliance.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	00P414602AR0
Brand	Ariete
Power	1500 Watts
Voltage	230V
Steam Pressure	5 bars
Water Tank Capacity	1.6 Liters
Autonomy	Up to 55 minutes
Product Dimensions (L x W x H)	30 x 33 x 50 cm
Weight	6.5 Kilograms
Material	Stainless Steel

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Ariete website. Keep your proof of purchase for warranty claims.
Return Policy: 30 days (from Amazon, if applicable).
Availability of Spare Parts: Information unavailable on spare parts.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question