Schock SFN5458N

Schock New England F605 SFN5458N Multifunction Oven

User Manual

1. Introduction and Safety Information

Thank you for choosing the Schock New England F605 SFN5458N Multifunction Oven. This manual provides essential information for the safe and efficient use of your appliance. Please read all instructions carefully before installation and operation, and retain this manual for future reference.

General Safety Warnings:

- Ensure the oven is installed by a qualified technician in accordance with local regulations.
- Do not allow children to operate the oven unsupervised.
- The oven surfaces become hot during operation. Use oven mitts when handling hot dishes or internal components.
- Do not use abrasive cleaners or sharp metal scrapers to clean the oven door glass, as they can scratch the surface and lead to shattering.
- This appliance is equipped with a **Triple Vitro cold door**, which helps to keep the outer glass cooler during operation, enhancing safety.
- Always disconnect the appliance from the power supply before performing any maintenance or cleaning.

2. Product Overview

The Schock New England F605 SFN5458N is a 60 cm built-in multifunction oven designed for versatile cooking. It features a spacious 64-liter extra-large cavity and an analog programmer for precise control over cooking times.



Figure 1: Front view of the Schock New England F605 SFN5458N Multifunction Oven. This image displays the oven's oat color finish, the antique metal handles and control knobs, and the full glass inner door.

Key Features:

- Multifunction oven with 5 cooking functions.
- Large 64-liter oven cavity.
- Analog programmer for setting cooking start and end times.
- Durable metal dashboard and door.
- Antique metal handles and knobs for a classic aesthetic.
- Removable full glass inner door for easy cleaning.
- Titanium easy-to-clean enamel interior.
- Equipped with 1 grill rack and 1 baking tray.
- Internal oven light for visibility.
- Lateral chromed guides for racks.
- Tangential cooling ventilation system.

- Energy efficiency class A.

3. Installation

The Schock New England F605 SFN5458N is designed for built-in installation. Proper installation is crucial for the oven's performance and safety. It is recommended that installation be carried out by a qualified professional.

Installation Requirements:

- **Dimensions:** The oven measures 54 x 60 x 59 cm (width x height x depth). Ensure the cabinet opening matches these dimensions.
- **Ventilation:** Ensure adequate ventilation around the appliance as per the installation diagram provided with the packaging. The tangential cooling ventilation system requires proper airflow.
- **Electrical Connection:** Connect the oven to a suitable electrical supply as specified on the rating plate. Ensure the power supply is disconnected before making any connections.
- **Door Opening:** The oven door opens to the left. Ensure sufficient space for full door opening.
- **Leveling:** The oven must be level once installed to ensure even cooking and proper door function.

4. Operation

Your Schock oven offers 5 distinct cooking functions to suit various culinary needs. Familiarize yourself with the control knobs and the analog programmer before first use.

Control Panel:

The control panel consists of function selector knobs, a temperature control knob, and an analog programmer. Refer to the diagrams in the full instruction manual for specific knob identification.

Cooking Functions:

The oven features 5 multifunction settings, typically including:

- **Conventional Heating:** For traditional baking and roasting.
- **Fan-Assisted Heating (Convection):** For even cooking and faster results, ideal for multiple dishes.
- **Grill:** For browning and toasting.
- **Bottom Heating:** For crisping bases.
- **Defrosting:** Utilizes automatic defrosting for gentle thawing of food.

Setting the Analog Programmer:

The analog programmer allows you to set the duration of cooking or to program a delayed start and end time. Consult the detailed instructions in the complete manual for specific programming steps.

First Use:

Before cooking food, heat the empty oven at maximum temperature for approximately 30 minutes to burn off any manufacturing residues. Ensure the kitchen is well-ventilated during this process.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your oven.

Interior Cleaning:

- The oven interior features a **titanium easy-to-clean enamel**. Clean the interior after each use once the oven has

cooled down.

- Use a soft cloth with warm soapy water or a specialized oven cleaner (ensure it is suitable for enamel surfaces).
- Avoid abrasive sponges or harsh chemicals that could damage the enamel.

Exterior Cleaning:

- Clean the exterior surfaces, including the metal dashboard and door, with a soft cloth and mild detergent.
- For the antique metal handles and knobs, use a damp cloth and dry thoroughly. Avoid harsh cleaners that may tarnish the finish.

Removable Full Glass Inner Door:

The inner glass panel of the oven door is removable for thorough cleaning. Refer to the full instruction manual for detailed steps on how to safely remove and re-install the glass panel.

Replacing the Oven Light:

Ensure the oven is disconnected from the power supply. Unscrew the protective cover, replace the bulb with one of the same specifications (check the full manual for bulb type), and re-attach the cover.

6. Troubleshooting

Before contacting customer service, please consult the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; oven not switched on; timer not set correctly.	Check power connection and circuit breaker. Ensure oven is switched on and the analog programmer is set to manual or a cooking time.
Oven light not working.	Light bulb is faulty.	Replace the oven light bulb (refer to Maintenance section).
Fan is noisy or humidity accumulates.	Possible fan obstruction or ventilation issue.	Ensure the oven's ventilation outlets are not blocked. If the issue persists, contact qualified service personnel.
Food not cooking evenly.	Incorrect temperature or function selected; food placed incorrectly.	Verify temperature and function settings. Ensure food is placed centrally and not overcrowding the oven. Use convection function for more even results.

7. Specifications

Detailed technical specifications for the Schock New England F605 SFN5458N oven.

- **Model Name:** New England F605
- **Model Number:** SFN5458N
- **Type:** Multifunction Built-in Oven
- **Dimensions (W x H x D):** 54 x 60 x 59 cm (543 x 597 x 590 mm)
- **Oven Capacity:** 64 Liters (Extra Large Cavity)
- **Number of Functions:** 5
- **Heating Method:** Convection
- **Control Type:** Analog Programmer

- **Material:** Metal (dashboard and door), Glass (inner door)
- **Finish Color:** Oat
- **Special Features:** Triple Vitro cold door, Easy-to-clean titanium enamel, Tangential cooling ventilation
- **Door Opening Direction:** Left
- **Defrosting:** Automatic defrosting
- **Item Weight:** 33 Kilograms
- **Country of Origin:** Italy
- **GTIN (Global Trade Identification Number):** 08052745126240

8. Warranty and Support

Your Schock New England F605 SFN5458N Multifunction Oven is covered by a**2-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and faulty materials under normal domestic use.

To claim warranty service:

- Retain your proof of purchase (receipt or invoice).
- Contact Schock customer support or your retailer for assistance.

Exclusions:

The warranty does not cover damage caused by improper installation, misuse, accidental damage, unauthorized repairs, or normal wear and tear.

Customer Support:

For further assistance, technical support, or to schedule a service appointment, please refer to the contact information provided in your purchase documentation or visit the official Schock website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question