Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine LYSB01MCWBL0M-ELECTRNCS

JustFine Replacement Remote Control Instruction Manual

Compatible with Insignia LED LCD HDTV Models

Introduction

Welcome to your new JustFine replacement remote control. This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your remote. This remote is pre-programmed and designed to work seamlessly with various Insignia LED LCD HDTV models, including NS-39D310NA15, NS46D400NA14, NS-48D510NA15, NS50L440NA14, and NS-50L440NA14.

Setup

Battery Installation

Your remote control requires two AAA batteries, which are not included. Please follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the latch and slide the cover off to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image showing the rear of the remote control with the battery compartment cover open, indicating where to insert batteries.

Operating Instructions

This remote control is pre-programmed and ready for immediate use with compatible Insignia LED LCD HDTV models. For optimal performance, point the remote directly at your television's infrared receiver.

- **Power Button:** Turns the television on or off.
- **Channel Up/Down:** Navigates through television channels.
- **Volume Up/Down:** Adjusts the television's audio volume.

- **Mute Button:** Silences or restores the television audio.
- **Input/Source Button:** Cycles through available input sources (e.g., HDMI, AV, Component).
- **Number Buttons (0-9):** Allows direct entry of channel numbers.
- **Menu Button:** Accesses the television's on-screen menu system.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate through menus and confirm selections.

Maintenance

- **Cleaning:** To clean the remote control, use a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries simultaneously with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight, high humidity, and extreme temperatures, to prolong its lifespan.

Troubleshooting

Problem	Solution
Remote is not working.	• Ensure batteries are installed correctly with the proper positive (+) and negative (-) polarity. • Replace old batteries with new ones. • Verify there are no physical obstructions between the remote control and the TV's infrared sensor. • Point the remote directly at the television's sensor. • Confirm the remote is compatible with your specific Insignia TV model.
Remote works intermittently.	• Batteries may be low; replace them with new ones. • Clean the remote's infrared emitter and the TV's sensor to ensure a clear signal path.
Some buttons do not respond.	• Check for any debris or stickiness around the unresponsive buttons. • Replace the batteries, as low power can affect button functionality. • If the issue persists after these steps, the remote control may be faulty.

Specifications

- **Model Number:** LYSB01MCWBL0M-ELECTRNCS
- **Brand:** JustFine
- **Compatible Devices:** Insignia LED LCD HDTVs (NS-39D310NA15, NS46D400NA14, NS-48D510NA15, NS50L440NA14, NS-50L440NA14)
- **Connectivity Technology:** Infrared (IR)
- **Special Feature:** Ergonomic design
- **Max Number of Supported Devices:** 1
- **Dimensions:** 4.53 x 1.57 x 1.38 inches (11.5 x 4.0 x 3.5 cm)
- **Weight:** 2.39 ounces (67.7 grams)

- **Power Source:** 2 x AAA Batteries (not included)

Warranty and Support

This JustFine replacement remote control is offered with a 30-day quality warranty and a money-back guarantee. For any product-specific issues, questions, or further assistance regarding this remote control, please contact the seller directly through your purchase platform.

For general product support related to Insignia televisions (not this replacement remote itself), you may visit the official Insignia product support website:

www.insigniaproducts.com

Alternatively, you can call Insignia product support at:

- **US & Canada Market:** 1-877-467-4289
- **Mexico Market:** 01-800-926-3000

Note: These contact details are for Insignia brand products and not for direct support of the JustFine replacement remote control. For remote control specific support, please contact your seller.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MCWBL0M

More documents and user manuals: **https://manuals.plus/**