Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 4330960620

Instruction Manual

Replacement Remote Control for Sony Home Theater Systems

Product Overview

This manual provides instructions for the use and care of your JustFine Replacement Remote Control, compatible with various Sony Home Theater Audio/Video Receiver AV Systems.

Model: 4330960620

Compatible Sony Models: HT-IS100, RM-AAU060, STRDH100, HT-FS3, SAWFS3



Figure 1: Front view of the JustFine Replacement Remote Control. This image shows the layout of all buttons, including power, input selection, volume, channel, navigation, and numeric keys, designed to mimic the original Sony remote.



Figure 2: Back view of the JustFine Replacement Remote Control. This image highlights the battery compartment cover, indicating where batteries should be inserted for operation.

Setup

The JustFine Replacement Remote Control is designed for immediate use with compatible Sony Home Theater Audio/Video Receiver AV Systems without the need for complex programming.

1. **Unpack the Remote:** Carefully remove the remote control from its packaging.
2. **Install Batteries:**
   - Locate the battery compartment on the back of the remote control (refer to Figure 2).
   - Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
   - Insert two (2) AAA batteries (*not included*) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
   - Close the battery compartment cover by sliding it back into place until it clicks securely.
3. **Initial Test:** Point the remote control towards your Sony Home Theater System and press the Power button. The system should respond. If not, verify battery installation and ensure the remote is within range and line of sight of the system's IR receiver.

Note: *This remote is pre-programmed and cannot be reprogrammed. It is intended as a direct replacement for the specified Sony models.*

Operating Instructions

The remote control functions are designed to replicate the original Sony remote. Familiarize yourself with the button layout (refer to Figure 1) to operate your home theater system effectively.

- **Power On/Off:** Press the **POWER** button (usually located at the top right) to turn the system on or off.
- **Input Selection:** Use the input buttons (e.g., **TV**, **BD**, **DVD**, **DIGITAL 1/2**) to switch between connected audio/video sources.
- **Volume Control:** Use the **VOL +** and **VOL -** buttons to adjust the master volume level.
- **Mute:** Press the **MUTE** button to temporarily silence the audio output. Press again to restore sound.
- **Navigation and Menu:** Use the directional arrow buttons (**UP**, **DOWN**, **LEFT**, **RIGHT**) and the **ENTER** button to navigate through on-screen menus. The **MENU/HOME** button accesses the main system menu, and **RETURN/EXIT** allows you to go back or exit menus.
- **Numeric Keypad:** Use the numeric buttons (0-9) for direct channel input or other functions requiring numerical entry.
- **Playback Controls:** Buttons such as **PLAY**, **PAUSE**, **STOP**, **REWIND**, and **FAST FORWARD** control media playback on compatible devices.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, direct sunlight, or moisture. Keep it away from strong magnetic fields.

Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote not working at all.	Dead or incorrectly inserted batteries. Obstruction between remote and device.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions. Ensure line of sight to the system's IR receiver.
Remote works intermittently.	Low battery power. Weak IR signal due to distance or angle.	Replace batteries. Move closer to the system and ensure direct line of sight.
Certain buttons do not respond.	Button stuck or dirty. Remote not compatible with specific function.	Clean around the unresponsive button. Verify compatibility with your specific Sony model and its functions.
System does not respond to remote.	System's IR receiver is blocked or faulty. Remote is not compatible with your specific system model.	Ensure the system's IR receiver is clear. Double-check the compatibility list (HT-IS100, RM-AAU060, STRDH100, HT-FS3, SAWFS3).

If troubleshooting steps do not resolve the issue, please contact customer support.

Specifications

- **Model Number:** 4330960620
- **Brand:** JustFine
- **Compatible Devices:** Sony HT-IS100, RM-AAU060, STRDH100, HT-FS3, SAWFS3 Home Theater Audio/Video Receiver AV Systems
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (*not included*)
- **Product Dimensions:** 5.31 x 1.97 x 1.18 inches (approximately)
- **Item Weight:** 3.04 ounces (approximately, without batteries)
- **Special Feature:** Ergonomic design
- **Max Number of Supported Devices:** 1 (specific Sony system)

Warranty and Support

This product is sold with a money-back guarantee and hassle-free return policy.

- **Quality Warranty:** 30 days from the date of purchase.
- **Returns:** Hassle-Free return policy.
- **Customer Support:** For any problems or inquiries, please contact us via email. Refer to your purchase documentation for specific contact details.

Please note that batteries and a printed manual are not included with the product.

© 2024 JustFine. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MFCOIZL

More documents and user manuals: **https://manuals.plus/**