EasySMX BDS-939MG-R

EasySMX KOTION EACH GS600 Pro 4-in-1 Stereo Gaming Headset

INSTRUCTION MANUAL

Introduction

Thank you for purchasing the EasySMX KOTION EACH GS600 Pro 4-in-1 Stereo Gaming Headset. This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance and an immersive gaming experience. Please read this manual thoroughly before use and retain it for future reference.

Package Contents

Please check the package contents to ensure all items are present:

- 1 x EasySMX KOTION EACH GS600 Pro Gaming Headset
- 1 x Plug-in Microphone
- 1 x 2.5mm to 3.5mm Adapter Cable for Xbox One
- 1 x 2 RCA to 3.5mm Audio Adapter Cable for TV
- 1 x User Manual

Product Features

- **Multi-Platform Compatibility:** Designed for Xbox 360, PS3, PS4, PC, Laptops, and mobile phones. Xbox One requires an additional adapter (not included).
- **High-Quality Audio:** Features 40mm neodymium drivers for powerful bass and clear sound.
- **Separate Game & Chat Volume Controls:** Easily adjust audio levels for game sound and chat independently.
- **Microphone Mute Function:** A dedicated button allows for quick microphone mute/unmute.
- **Comfortable Design:** Padded, extensible headband and soft over-ear earcups ensure comfort during extended gaming sessions.
- **Noise Cancellation:** Advanced noise cancellation technology and over-ear design help block external noise for focused gameplay.
- **Durable Construction:** Built with high-quality ABS material for longevity.

Setup

Follow these steps to connect your EasySMX KOTION EACH GS600 Pro headset to your desired platform.

1. Attaching the Microphone

Gently insert the plug-in microphone into the designated port on the left earcup of the headset until it clicks into place. Ensure it is securely connected.

2. Connecting to PC/Laptop

- Connect the USB plug of the headset cable to an available USB port on your PC or laptop.
- Connect the 3.5mm audio jack (if applicable, for older PCs) to the audio output port and the 3.5mm microphone jack to the microphone input port on your PC. For most modern PCs, the USB connection handles both audio and microphone.
- Adjust sound settings in your operating system to select the headset as the default audio input and output device.

3. Connecting to PS3/PS4

- Connect the USB plug of the headset cable to an available USB port on your PlayStation console.
- For PS4, connect the 3.5mm jack to the controller's headset port.
- Navigate to the console's audio settings to ensure the headset is selected for both audio output and microphone input.

4. Connecting to Xbox 360

- Connect the USB plug of the headset cable to an available USB port on your Xbox 360 console.
- Connect the 2.5mm jack from the headset to the 2.5mm port on your Xbox 360 controller.

5. Connecting to Xbox One (Adapter Required)

- An official Microsoft Xbox One Stereo Headset Adapter (not included) is required for full functionality.
- Connect the 2.5mm to 3.5mm adapter cable (included) to the headset's 2.5mm port.
- Plug the 3.5mm end of the adapter cable into the Xbox One Stereo Headset Adapter, which is then connected to your Xbox One controller.
- Connect the USB plug of the headset cable to an available USB port on your Xbox One console.

6. Connecting to Mobile Phones

- Connect the 3.5mm audio jack of the headset directly to your mobile phone's 3.5mm audio port.
- Ensure the microphone is attached if you intend to use it for calls or voice chat.

7. Connecting to TV (for Audio Output)

- Use the included 2 RCA to 3.5mm Audio Adapter Cable.
- Connect the red and white RCA plugs to the corresponding audio output ports on your TV.
- Plug the 3.5mm end of the adapter cable into the headset's 3.5mm audio input.
- Note: This connection is typically for receiving game audio from the TV, not for microphone input to a console.

Operating Instructions

1. Wearing the Headset

Adjust the extensible headband to fit comfortably over your head. Position the earcups so they fully cover your ears, ensuring a snug fit for optimal sound isolation and comfort.

2. Adjusting Volume

The headset features an in-line control unit on the cable. Use the dedicated dials or buttons to adjust:

- **Game Volume:** Controls the overall audio level of your game.
- **Chat Volume:** Controls the volume of voice chat from other players.

3. Microphone Mute Function

Locate the mute button on the in-line control unit. Press it once to mute the microphone (your voice will not be transmitted). Press it again to unmute the microphone.

Maintenance

1. Cleaning

Wipe the headset and earcups with a soft, dry cloth. Do not use abrasive cleaners or solvents. Avoid getting moisture into the speaker grilles or microphone.

2. Storage

Store the headset in a clean, dry place away from extreme temperatures and direct sunlight. Avoid tangling the cables to prevent damage.

3. Cable Care

Do not pull on the cables forcefully. Always grasp the plug when disconnecting. Avoid sharp bends or kinks in the cables.

Troubleshooting

If you encounter issues with your headset, please refer to the following common solutions:

1. No Sound or Low Volume

- Check all cable connections to ensure they are secure.
- Verify that the game and chat volume controls on the in-line unit are turned up.
- Ensure the headset is selected as the default audio output device in your console or PC settings.
- Test the headset with another device to rule out a device-specific issue.

2. Microphone Not Working

- Ensure the microphone is securely plugged into the headset.
- Check that the microphone mute button on the in-line control is not activated.
- Verify that the headset is selected as the default microphone input device in your console or PC settings.
- Adjust microphone sensitivity settings on your device if available.

3. Sound Distortion or Static

- Ensure all cables are fully inserted and not damaged.
- Try connecting the headset to a different port or device to check if the issue persists.

- Reduce the volume if it is set too high, as this can sometimes cause distortion.

4. Xbox One Compatibility Issue

Remember that an official Microsoft Xbox One Stereo Headset Adapter is required for full functionality with Xbox One. Without this adapter, certain features or audio/microphone input may not work correctly.

Specifications

Feature	Detail
Speaker Diameter	Φ 40mm
Speaker Impedance	32Ω
Speaker Frequency Response	20 Hz - 20 KHz
Speaker Sensitivity	102 dB
Microphone Dimensions	6.0 x 2.7 mm
Microphone Sensitivity	-52 dB
Microphone Direction	Omni-directional
Microphone Impedance	≤ 2.2KΩ
Microphone Frequency Response	50 Hz - 15 KHz
Cable Length (Main)	3.6 meters
Cable Length (Xbox Controller)	0.5 meters
Connector Type	USB/RCA/Φ2.5mm
Model Number	BDS-939MG-R

Warranty Information

EasySMX products are designed and manufactured to the highest quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official EasySMX website. Keep your proof of purchase for any warranty claims.

Support

If you require further assistance or have questions not covered in this manual, please contact EasySMX customer support. Contact information can typically be found on the EasySMX official website or on the product packaging.

Website: www.easysmx.com (Example link, please verify official website)