VIKTOR JURGEN VJ016

VIKTOR JURGEN Handheld Back Massager Instruction Manual

Model: VJ016

Product Overview

The VIKTOR JURGEN Handheld Back Massager is a double-head electric percussion massager designed for deep tissue massage across various body parts including the head, neck, shoulders, back, legs, and feet. It features a powerful motor delivering up to 3,350 pulses per minute and customizable speed settings for adjustable intensity.

Key Features:

- **Double Head Design:** Equipped with two massage heads for effective coverage.
- **Interchangeable Massage Heads:** Comes with 3 sets of removable massage heads to suit different massage needs and body areas.
- **Powerful Percussion:** Delivers up to 3,350 pulses per minute for deep tissue relief.
- **Customizable Speed Settings:** Adjust the intensity and power of the massage.
- **Ergonomic Design:** Features a non-slip and comfortable grip for ease of use.
- **Long Power Cord:** 71-inch cord for flexible use.



The VIKTOR JURGEN Handheld Back Massager, shown with its main body and three sets of interchangeable massage heads, designed for versatile use across different muscle groups.

Safety Information

It is crucial to follow general safety guidelines when using electric massagers. Avoid sensitive areas of the body and ensure the massager is not used near water. Always consult a healthcare professional if you have any pre-existing medical conditions or concerns.

Legal Disclaimer:

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Setup

1. **Unpack:** Carefully remove the massager and all accessories from the packaging.

2. **Inspect:** Check the device and power cord for any signs of damage. Do not use if damaged.
3. **Attach Massage Head:** Select the desired massage head attachment and firmly attach it to the massager's heads.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.



A close-up view of the VIKTOR JURGEN massager's dual heads and the various interchangeable attachments, demonstrating how they can be affixed for different massage types.

Operating Instructions

1. **Choose Attachment:** Select the desired massage head attachment based on your preference and the area to be massaged.
2. **Power On:** Turn on the massager using the ON/OFF switch located on the handle.

3. **Adjust Speed:** Use the customizable speed settings to adjust the intensity of the massage to your desired level. The massager can run up to 3,350 pulses per minute.
4. **Apply Massager:** Gently apply the massager to the desired body part.
5. **Move as Needed:** Move the massager slowly and steadily over the body part, allowing the percussion action to relieve muscle tension and pain.
6. **Power Off:** After use, turn off the massager and unplug it from the power outlet.



The VIKTOR JURGEN Handheld Back Massager being used on a leg, demonstrating its ergonomic design and ease of application for targeted muscle relief.

Maintenance

- **Cleaning:** Disconnect the massager from the power source before cleaning. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and moisture. Keep it out of reach of children.
- **Cord Care:** Do not wrap the power cord tightly around the device, as this can damage the cord.

Troubleshooting

Problem	Possible Cause	Solution
Massager does not turn on.	Not plugged in; power outlet not working; ON/OFF switch not engaged.	Ensure the power cord is securely plugged into a working outlet. Check the ON/OFF switch.
Weak massage intensity.	Speed setting is too low.	Adjust the speed control slider to a higher setting.
Unusual noise or vibration.	Loose massage head; internal issue.	Ensure massage heads are securely attached. If the issue persists, discontinue use and contact customer support.
Overheating.	Prolonged continuous use.	Allow the massager to cool down for at least 30 minutes before resuming use. The device has an overheat protection system.



An internal diagram highlighting the overheat protection system, ensuring safe operation during extended use.

Specifications

- **Model Number:** VJ016
- **Brand:** VIKTOR JURGEN
- **Power Source:** Corded Electric
- **Item Weight:** 3.5 Pounds (approximately 1.59 kg)
- **Product Dimensions:** 6.69 x 5.51 x 14.57 inches (approximately 17 x 14 x 37 cm)
- **Material:** Rubber
- **Manufacturer:** VIKTOR JURGEN
- **Pulses Per Minute:** Up to 3,350



A visual representation of the massager's customizable speed settings, highlighting its capability to deliver up to 3,350 pulses per minute for effective massage.

Warranty & Support

For warranty information or technical support, please contact VIKTOR JURGEN customer service. Refer to the product packaging or the official VIKTOR JURGEN website for contact details.

You can also visit the VIKTOR JURGEN Store on Amazon for more product information and support resources.

© 2023 VIKTOR JURGEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question