**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## ZdalaMit AKB72915244

# ZdalaMit AKB72915244 Replacement Remote Control User Manual

Brand: ZdalaMit | Model: AKB72915244

Introduction Setup Operating Instructions Maintenance Troubleshooting Specifications Support

## 1. Introduction

This manual provides instructions for the ZdalaMit AKB72915244 Replacement Remote Control. This remote is designed to function as a direct replacement for your original LG TV remote, offering seamless control without the need for complex programming.

### 1.1 Compatible LG TV Models

The AKB72915244 remote control is compatible with a wide range of LG LCD and LED TV models, including but not limited to:

- LD Series: 32LD420, 32LD450, 37LD450, 42LD450, 47LD450, 37LD450C, 42LD450C, 47LD450C, 32LD520, 42LD520, 47LD520, 32LD550, 42LD550, 46LD550, 52LD550, 55LD520, 55LD520C, 55LD630, 60LD550
- LE Series: 19LE5300, 22LE5300, 26LE5300, 32LE5300, 37LE5300, 42LE5300, 47LE5300, 55LE5300, 22LE5500, 26LE5500, 42LE5500, 55LE5500, 42LE7300, 47LE7300, 55LE7300, 55LE8500
- PJ/PT Series: 42PJ350, 50PJ340, 50PJ350, 42PJ350C, 42PJ350CUB, 42PJ350UB, 50PJ340UC, 50PJ350C, 50PJ350CUB, 50PJ350UB, 50PT350

If your specific model is not listed, please refer to the product packaging or contact customer support for compatibility verification.

## 2. Setup

### 2.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



*Image: Rear view of the remote control with the battery compartment open, illustrating correct AAA battery placement.*

### 2.2 Initial Use

No programming or pairing is required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your compatible LG TV.

## 3. Operating Instructions

The ZdalaMit AKB72915244 remote control provides all essential functions for operating your LG TV. Point the remote directly at your TV's infrared receiver for optimal performance.



*Image: Front view of the AKB72915244 remote control, displaying its button layout.*

### 3.1 Key Functions

- **POWER (Red Button):** Turns the TV on or off.
- **ENERGY SAVING:** Adjusts the TV's power consumption settings.
- **AV MODE / INPUT:** Selects video input sources (e.g., HDMI, AV).
- **Number Buttons (0-9):** Directly selects TV channels.
- **LIST:** Displays the channel list.
- **MARK / FAV:** Accesses favorite channels or marks content.
- **VOLUME (+/-):** Increases or decreases the volume.
- **MUTE:** Silences the TV audio.
- **CHANNEL (P PAGE ^/v):** Changes channels up or down.
- **GUIDE:** Displays the electronic program guide.
- **HOME:** Accesses the TV's main menu or smart features.
- **Q.MENU:** Opens the Quick Menu for common settings.
- **Navigation Pad (Up/Down/Left/Right/OK):** Navigates menus and confirms selections.
- **BACK / INFO / EXIT:** Returns to the previous screen, displays information, or exits menus.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services.
- **TEXT / T.OPT / SUBTITLE:** Accesses Teletext, Teletext options, or subtitle settings.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

## 4. Maintenance

### 4.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

### 4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

### 4.3 Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

## 5. Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions:

| Problem | Solution |
| --- | --- |

| Problem | Solution |
| --- | --- |
| Remote is not responding. | • Ensure batteries are inserted correctly with the correct polarity (+/-).<br>• Replace old batteries with new AAA alkaline batteries.<br>• Check for any obstructions between the remote and the TV's infrared sensor.<br>• Ensure you are within the effective range of the TV's sensor. |
| Specific buttons are not working. | • This remote is a direct replacement; ensure your TV model is listed as compatible.<br>• Some advanced functions might require the original TV remote or specific TV settings.<br>• Clean the remote's surface, especially around the unresponsive buttons, to remove any debris. |
| Remote works intermittently. | • Batteries may be low; replace them.<br>• Ensure a clear line of sight to the TV.<br>• Avoid strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the IR signal. |

## 6. Specifications

| Feature | Detail |
| --- | --- |
| Product Dimensions | 8 x 2 x 0.65 inches |
| Item Weight | 2 ounces |
| Batteries Required | 2 AAA batteries (not included) |
| Brand | ZdalaMit |
| Special Feature | Ergonomic design |
| Color | Black |
| Max Number of Supported Devices | 1 (Television) |
| Compatible Devices | Television |

## 7. Warranty and Support

This product is designed for reliable performance. While specific warranty details are not provided in this manual, if you have any questions, concerns, or require assistance with your ZdalaMit AKB72915244 remote control, please contact the

seller or manufacturer directly for support.

© 2025 ZdalaMit. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B01MR2KERD**

More documents and user manuals: **https://manuals.plus/**