Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FSR35-W

SoBuy FSR35-W Storage Bench Instruction Manual

Model: FSR35-W

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your SoBuy FSR35-W Storage Bench. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

Important: Do not exceed the load capacity of 100 kg (220.46 lbs) to ensure safe use and prevent damage to the product or injury.
Always ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.

Package Contents

Before assembly, verify that all components listed in the included hardware and parts list are present and undamaged. If any parts are missing or damaged, please contact customer support.



Image: The SoBuy FSR35-W Storage Bench, featuring a white frame, two cabinet doors, a central open shelf, and a removable grey seat cushion.

Setup and Assembly

The SoBuy FSR35-W Storage Bench requires self-assembly. Detailed instructions and all necessary hardware are included in the package. Please follow the step-by-step guide provided with your product for optimal assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your assembly guide to identify each component.
3. **Assemble Frame:** Begin by assembling the main frame of the bench according to the diagrams. Ensure all connections are secure but do not overtighten screws until the entire frame is aligned.
4. **Install Shelves and Doors:** Attach the internal shelves and then the cabinet doors. Adjust hinges as needed for proper door alignment.
5. **Attach Cushion:** Place the removable seat cushion on top of the bench.
6. **Final Tightening:** Once the entire bench is assembled and aligned, carefully tighten all screws.



Image: Diagram showing the dimensions of the SoBuy FSR35-W Storage Bench: 105cm (length), 35cm (width), and 43cm (height).

Operating Instructions

The SoBuy FSR35-W Storage Bench is designed for versatile use in hallways, living rooms, or bedrooms.

- **Seating:** The padded cushion provides a comfortable surface for sitting, ideal for putting on or taking off shoes.
- **Storage:** Utilize the two cabinet compartments with doors and the central open storage area for organizing shoes, accessories, or other items. The central shelf is adjustable to accommodate various item sizes.



Image: The SoBuy FSR35-W Storage Bench positioned in a hallway, demonstrating its use as both seating and storage for shoes and other items.



Image: The SoBuy FSR35-W Storage Bench in a hallway, showcasing its appearance with both cabinet doors closed.



Image: The SoBuy FSR35-W Storage Bench in a hallway, with one cabinet door open to reveal the interior storage space.



Image: A detailed view of one of the open cabinet doors, revealing the interior storage space, suitable for baskets or shoes.



Image: A close-up of the bench's grey cushion, with sunglasses and a book placed on it, demonstrating its use as a convenient surface.

Maintenance and Care

To maintain the appearance and longevity of your storage bench, follow these care instructions:

- **Cleaning:** Wipe the wooden surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cushion Care:** The polyester linen-like fabric cushion can be spot cleaned with a damp cloth and mild detergent if necessary. Ensure it is completely dry before use. The cushion is removable for easier cleaning or replacement.
- **Regular Checks:** Periodically inspect all screws and fittings to ensure they remain tight. Re-tighten as needed to maintain stability.



Image: A close-up view of the grey polyester linen-like fabric seat cushion, highlighting its texture and removable design.

Troubleshooting

If you encounter any issues with your SoBuy FSR35-W Storage Bench, please refer to the following common solutions:

- **Wobbly Bench:** Ensure all screws are fully tightened. If the bench still wobbles, check that it is placed on a level surface. Adjust furniture glides if applicable.
- **Doors Not Closing Properly:** Check the hinge alignment. Loosen the hinge screws slightly, adjust the door position, and then re-tighten. Ensure no obstructions are preventing the door from closing.
- **Scratches or Dents:** For minor cosmetic damage, touch-up paint or furniture markers matching the white finish can be used.



Image: A detailed view of the metal hinge mechanism on one of the cabinet doors, illustrating its construction.

Specifications

Feature	Detail
Model Number	FSR35-W
Color	White
Product Dimensions (L x W x H)	105 x 35 x 43 cm (41.34"L x 13.78"W x 16.93"H)
Weight	16.8 kg (37.04 lbs)
Load Capacity	100 kg (220.46 lbs)
Primary Material	MDF, Polyester linen-like fabric, Sponge

Frame Material	Engineered Wood
Assembly Required	Yes
Care Instructions	Wipe with Dry Cloth

Contact and Support

For further assistance, missing parts, or inquiries, please contact SoBuy customer support through your retailer or the official SoBuy website.

© 2025 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MRV4V56

More documents and user manuals: **https://manuals.plus/**