De'Longhi CTOV2003J-GR

De'Longhi ICONA Vintage Collection Pop-up Toaster CTOV2003J-GR User Manual

Model: CTOV2003J-GR

Introduction | Safety Instructions | Product Overview | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for purchasing the De'Longhi ICONA Vintage Collection Pop-up Toaster, model CTOV2003J-GR. This manual provides essential information for the safe and efficient use of your new appliance. Please read these instructions carefully before use and keep them for future reference.

2. Important Safety Instructions

- Read all instructions before using the toaster.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.
- Do not operate unattended.
- Bread may burn. Therefore, toasters must not be used near or below curtains and other combustible materials. They must be supervised.

3. Product Overview

The De'Longhi ICONA Vintage Collection Pop-up Toaster CTOV2003J-GR features a classic design with modern functionality. Familiarize yourself with its components:

- **Toasting Slots:** Two wide slots for various bread types.
- **Toasting Lever:** Lowers bread into the slots and initiates the toasting cycle.
- **Browning Control Dial:** Adjusts the desired level of toast browning from 1 (lightest) to 6 (darkest).
- **Function Buttons:**
  - **BAGEL:** Toasts the cut side of bagels while gently warming the outer side.
  - **DEFROST:** Defrosts and toasts frozen bread.
  - **REHEAT:** Warms previously toasted bread without further browning.
  - **CANCEL:** Stops the toasting cycle at any time.
- **Crumb Tray:** Removable tray located at the bottom for easy cleaning of crumbs.
- **Dust Cover:** A protective cover to keep the toasting slots clean when not in use.



Figure 1: Front view of the De'Longhi ICONA Vintage Collection Pop-up Toaster CTOV2003J-GR, showcasing its olive green finish, control dial, and function buttons.

4. Setup

1. **Unpack:** Carefully remove the toaster and all packaging materials. Ensure all components are present and undamaged.
2. **Placement:** Place the toaster on a stable, flat, heat-resistant surface, away from flammable materials such as curtains or walls. Ensure adequate ventilation around the appliance.
3. **First Use:** Before toasting bread for consumption, operate the toaster empty for a few cycles at the highest browning setting (6) to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal and will dissipate. Ensure the room is well-ventilated during this process.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

5.1 Basic Toasting

1. **Insert Bread:** Place one slice of bread into each toasting slot. The toaster can accommodate various bread thicknesses, from 10-slice to thick 4-slice bread.
2. **Select Browning:** Turn the browning control dial to your desired setting (1 for light, 6 for dark).
3. **Start Toasting:** Push the toasting lever down until it locks into place. The toaster will begin toasting, and the indicator light (if present) will illuminate.
4. **Retrieve Toast:** Once the toasting cycle is complete, the toast will automatically pop up. The toaster features an *Extra Lift* function, allowing the lever to be raised higher for easier removal of smaller items.



Figure 2: The browning control dial allows for stepless adjustment from light to dark, accommodating various bread types and thicknesses.



Figure 3: The extra lift mechanism allows the toast to be raised higher for convenient and safe retrieval.



Figure 4: Example of perfectly toasted bread, crispy on the outside and fluffy on the inside, achieved with the pop-up toasting function.

5.2 Using Function Buttons

- **BAGEL Function:** Insert bagels with the cut side facing inwards. Press the BAGEL button after pushing down the toasting lever. This function toasts the cut side while gently warming the outer side.
- **DEFROST Function:** Insert frozen bread. Press the DEFROST button after pushing down the toasting lever. This

function first defrosts the bread, then toasts it to your selected browning level.

- **REHEAT Function:** Insert previously toasted bread that has cooled. Press the REHEAT button after pushing down the toasting lever. This function warms the bread without further browning.
- **CANCEL Function:** To stop the toasting cycle at any time, simply press the CANCEL button. The toast will immediately pop up.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

1. **Always Unplug:** Before cleaning, ensure the toaster is unplugged from the power outlet and has completely cooled down.
2. **Clean Crumb Tray:** Pull out the removable crumb tray located at the bottom of the toaster. Dispose of crumbs and wipe the tray clean with a damp cloth. Dry thoroughly before reinserting.




Figure 5: The pull-out crumb tray simplifies cleaning and prevents crumb buildup.

3. **Clean Exterior:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or metal scouring pads, as these can scratch the surface.
4. **Do Not Immerse:** Never immerse the toaster in water or any other liquid.
5. **Dust Cover:** Use the provided dust cover to protect the toasting slots from dust and debris when the toaster is not in

use.



Figure 6: The included dust cover helps keep the toaster's slots clean and hygienic when not in operation.

7. Troubleshooting

If you encounter issues with your toaster, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the toaster is securely plugged into a working electrical outlet. Check your circuit breaker.
Bread is not toasting or toasts unevenly.	Browning control set too low; bread too thick/thin; crumb tray full.	Adjust the browning control to a higher setting. Ensure bread slices are evenly sized. Clean the crumb tray.
Bread is stuck in the toaster.	Oversized bread; foreign object.	**Unplug the toaster immediately.** Allow to cool. Gently remove the bread using non-metallic tongs. Never use metal utensils.
Smoke or burning smell.	Crumbs accumulated; food stuck; first use residue.	Press CANCEL, unplug, and allow to cool. Clean the crumb tray. If it's the first use, this is normal. If persistent, contact customer support.
Toast pops up too forcefully.	Normal operation for some models; no specific adjustment.	This can be a characteristic of pop-up toasters. Ensure the toaster is on a stable surface.

If the problem persists after attempting these solutions, please contact De'Longhi customer support for further assistance.

8. Specifications

Model Number	CTOV2003J-GR
Brand	De'Longhi
Product Dimensions (W x D x H)	7.68" x 12.99" x 8.27" (195 x 330 x 210 mm)
Weight	6.53 Pounds (approx. 2.96 kg)
Power Consumption	900 W
Burn Adjustment	Stepless from 1 to 6
Material	Stainless Steel
Color	Olive Green



Figure 7: Diagram illustrating the dimensions of the De'Longhi ICONA Vintage Collection Pop-up Toaster.

9. Warranty and Customer Support

De'Longhi products are manufactured to the highest quality standards. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official De'Longhi website.

For technical assistance, spare parts, or general inquiries, please contact De'Longhi customer support. Contact details can typically be found on the official De'Longhi website or in the documentation provided with your appliance.

Online Resources:

- **De'Longhi Official Website**
- **De'Longhi Amazon Store**

© 2023 De'Longhi. All rights reserved. Information in this manual is subject to change without notice.