Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AA59-00431A

ZdalaMit AA59-00431A / AA59-00434A Replacement Remote Control User Manual

For Samsung LCD LED Televisions

1. Introduction

This manual provides comprehensive instructions for the ZdalaMit AA59-00431A / AA59-00434A replacement remote control. This remote is designed to function as a direct replacement for various Samsung LCD and LED TV models, offering immediate usability without the need for complex programming or pairing procedures. Please read this manual thoroughly to ensure proper setup and operation.

2. Product Overview

The ZdalaMit AA59-00431A / AA59-00434A remote control is a dedicated replacement unit, replicating the functionality and button layout of the original Samsung remote. It is engineered for ease of use and compatibility with a range of Samsung television models.



Figure 1: Front view of the ZdalaMit AA59-00431A / AA59-00434A replacement remote control, showing all buttons and their labels. The remote is black with white and colored buttons, including power, channel, volume, number pad, and smart TV functions.

3. Setup: Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. **Open the Battery Compartment:** Locate the battery compartment cover on the back of the remote control. Slide the cover downwards or press the latch and lift to open it.
2. **Insert Batteries:** Insert two 1.5V AAA alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
3. **Close the Battery Compartment:** Replace the battery compartment cover by sliding it back into position until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with compatible Samsung TVs. No programming or pairing is required.



Figure 2: Back view of the remote control with the battery compartment open, illustrating the correct orientation for inserting two AAA batteries.

4. Operating Instructions

This remote control provides full functionality for your compatible Samsung TV. Refer to Figure 1 for button layout.

4.1 Basic Functions

- **POWER (Red Button):** Turns the TV on or off.
- **ON/OFF (Orange Button):** An alternative button for turning the TV on or off.
- **SOURCE:** Selects the input source (e.g., HDMI 1, AV, Component).
- **Number Buttons (0-9):** Directly enter channel numbers or other numerical inputs.
- **VOL (+/-):** Adjusts the volume level.
- **CH (Up/Down):** Changes the TV channel.
- **MUTE:** Mutes or unmutes the TV audio.
- **MENU:** Accesses the TV's main menu.
- **GUIDE:** Displays the electronic program guide (EPG).
- **INFO:** Displays information about the current program or input.
- **EXIT:** Exits the current menu or function.
- **RETURN:** Returns to the previous screen or menu.
- **Directional Pad (Up/Down/Left/Right) & ENTER:** Navigates through menus and confirms selections.

4.2 Advanced Functions

- **SMART HUB:** Accesses the Samsung Smart Hub for apps and online content.
- **TOOLS:** Provides quick access to common TV settings and options.
- **CH LIST:** Displays the channel list.
- **P.SIZE:** Adjusts the picture size/aspect ratio.
- **AD/SUBT:** Activates audio description or subtitles.
- **Color Buttons (A, B, C, D):** Used for specific functions within certain menus or applications, as indicated on-screen.
- **Playback Controls (Rewind, Play, Fast Forward, Stop, Pause, Record):** Controls media playback for compatible devices or content.

5. Compatible Samsung TV Models

This replacement remote control is compatible with a wide range of Samsung LCD and LED TV models, including but not limited to:

- AA59-00432A
- UA32D6400, UA40D6400, UA46D6400, UA55D6400
- UA32D6000, UA40D6000, UA46D6000, UA55D6000
- UA46D6600, UA55D6600
- PS51D6900, PS59D6900, PS59D8000
- PS51D8000FU, PS64D8000FU
- PS51D8000, PS64D8000
- PS51D8005, PS64D8005

If your original remote control model number is AA59-00431A or AA59-00434A, this replacement remote is designed to work seamlessly with your television.

6. Specifications

Model Numbers	AA59-00431A, AA59-00434A
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	6 x 2 x 0.6 inches (approximately)
Item Weight	0.81 ounces (without batteries)
Color	Black
Special Feature	Pre-programmed, no setup required
Compatible Devices	Samsung LCD LED Televisions

7. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Point the remote directly at the TV.
- **Specific Buttons Not Working:**
  - This may indicate a faulty button or low battery power. Try replacing batteries.
  - Ensure the TV is powered on and not in a menu where the button would be inactive.
- **Intermittent Operation:**
  - This often points to low battery power. Replace batteries.
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the IR signal.

8. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries promptly when the remote's performance declines. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

9. Warranty and Support

This product is a replacement remote control. Specific warranty details may vary depending on the retailer and purchase date. For any queries, technical assistance, or support regarding this product, please contact the seller directly through your purchase platform. They will be able to provide the most accurate and timely assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MZ5Z0CB

More documents and user manuals: **https://manuals.plus/**