EMB ES900BT

EMB ES900BT Portable Bluetooth Speaker User Manual

Model: ES900BT

1. Introduction

Thank you for choosing the EMB ES900BT Portable Bluetooth Speaker. This device is designed for high-quality audio playback and hands-free communication, featuring a water-resistant design for versatile use. Please read this manual carefully to ensure proper operation and maintenance of your speaker.



Figure 1.1: The EMB ES900BT Portable Bluetooth Speaker. This image displays the speaker's cylindrical shape and blue exterior with a black grille pattern.

2. Setup

2.1 Charging the Speaker

1. Locate the charging port on the speaker.
2. Connect the provided USB charging cable to the speaker's charging port and the other end to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate, typically red, during charging.
4. Charging time is approximately 2-3 hours. The indicator light will change or turn off when fully charged.

2.2 Powering On/Off

- To power on, press and hold the power button (usually marked with a ⏻ symbol) for a few seconds until you hear an audible prompt or see an indicator light.
- To power off, press and hold the power button again until the speaker shuts down.

2.3 Bluetooth Pairing

1. Ensure the speaker is powered on and within pairing mode (often indicated by a flashing blue LED). If not, briefly press the Bluetooth button or power button to initiate pairing mode.
2. On your mobile device (smartphone, tablet, computer), navigate to the Bluetooth settings.
3. Search for available devices. The speaker will appear as "EMB ES900BT" or a similar name.
4. Select the speaker from the list to connect. Once paired, you will hear a confirmation tone, and the LED indicator will typically turn solid blue.

2.4 Wired Connection (AUX)

- For devices without Bluetooth, connect a 3.5mm audio cable from your device's headphone jack to the AUX-in port on the speaker.
- The speaker should automatically switch to AUX mode.

3. Operating Instructions

3.1 Button Functions



Figure 3.1: Top view of the EMB ES900BT speaker, highlighting the control buttons. From left to right, these typically include Power, Play/Pause, Volume Down/Previous Track, and Volume Up/Next Track.

- **Power Button (⏻):** Press and hold to power on/off.
- **Play/Pause Button (▶❙❙):** Press once to play or pause music.
- **Volume Down** / **Previous Track (-):** Press once to decrease volume. Press and hold to go to the previous track.
- **Volume Up** / **Next Track (+):** Press once to increase volume. Press and hold to go to the next track.

3.2 Hands-Free Calling

- When a call comes in, the music will pause.
- Press the Play/Pause button once to answer the call.
- Press the Play/Pause button once again to end the call.
- Press and hold the Play/Pause button to reject an incoming call.

4. Maintenance

4.1 Water Resistance



Figure 4.1: The EMB ES900BT speaker shown with water splashing, illustrating its water-resistant capability. This feature allows for use in environments where it may be exposed to splashes, but not submersion.

The EMB ES900BT speaker is designed to be water-resistant, meaning it can withstand splashes and light rain. It is**not** designed to be submerged in water. Ensure all port covers are securely closed before exposing the speaker to moisture.

4.2 Cleaning and Storage

- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure the speaker is completely dry before charging or using it after exposure to water.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

- **Speaker does not power on:**
  Ensure the battery is charged. Connect the speaker to a power source and try again.
- **Cannot pair with Bluetooth device:**
  Ensure the speaker is in pairing mode. Turn off and on your device's Bluetooth. Move the speaker closer to your device. Clear previous Bluetooth connections on your device.
- **No sound or low volume:**
  Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired or connected via AUX.
- **Poor sound quality:**
  Move the speaker closer to your Bluetooth device to avoid interference. Ensure there are no obstructions between the speaker and the device.
- **Battery drains quickly:**
  Ensure the speaker is fully charged before use. Battery life can vary based on volume level and usage.

6. Specifications

Feature	Specification
Model Name	ES900BT
Brand	EMB
Connectivity Technology	Bluetooth
Speaker Driver	2 x 3W High Performance
Speaker Maximum Output Power	3 Watts
Power Source	Battery Powered
Battery Type	1000mAH Li-ion
Charging Time	2-3 Hours
Playing Time	Up to 8 Hours
Power Supply	DC5V +/- 0.5/500mA
Water Resistance	Yes (Water Resistant)
Item Weight	1.3 Pounds (0.59 kg)

Feature	Specification
Product Dimensions	6 x 2 x 2 inches (15.24 x 5.08 x 5.08 cm)
UPC	701160334836

7. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question