Wahl 9649P

Wahl Color Pro Cordless Rechargeable Hair Clipper & Trimmer User Manual

Model: 9649P | Brand: Wahl

Introduction

The Wahl Color Pro Cordless Clipper kit is designed for easy and convenient hair cutting and trimming at home. It features color-coded guide combs that simplify the process of selecting and remembering desired hair lengths. This manual provides essential information for the safe and effective use, maintenance, and care of your Wahl Color Pro Cordless Clipper.



Figure 1: Wahl Color Pro Cordless Clipper with its color-coded guide combs.

Safety Information

WARNING: Keep out of reach of children.

- Always unplug the appliance from the electrical outlet immediately after using.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Package Contents

Your Wahl Color Pro Cordless Clipper kit includes the following items:

- Wahl Color Pro Cordless Clipper with blade guard
- Complete set of color-coded attachment guards (various sizes)
- Haircutting accessories (e.g., combs, scissors, cleaning brush, blade oil)
- Power adapter/charger
- Full-color instruction manual
- Premium hard storage case



Figure 2: All included components of the Wahl Color Pro Cordless Clipper kit.

Setup

1. **Initial Charging:** Before first use, fully charge the clipper. Connect the power adapter to the clipper and plug it into an electrical outlet. The clipper can be used corded while charging, or cordless once charged.



Figure 3: Connecting the power cord for charging or corded use.

2. **Attaching Guide Combs:** Select the desired color-coded attachment guard based on the hair length you wish to achieve. Align the comb with the clipper blade and firmly snap it into place. The color key on the clipper body helps identify the correct comb for each length.



Figure 4: Attaching a color-coded guide comb.

Operating Instructions

1. **Powering On:** Press the power button to turn on the clipper.
2. **Hair Cutting:** For best results, start with a longer guide comb and gradually work down to shorter lengths if desired. Move the clipper against the direction of hair growth, using smooth, overlapping strokes.



Figure 5: Using the clipper for hair cutting.

3. **Adjusting Trim Length:** The color-coded system makes it easy to change lengths. Simply remove the current guide comb and attach a different one according to the desired length indicated by the color key on the clipper.
4. **Cordless Operation:** The clipper provides up to 60 minutes of cordless run time, offering flexibility and convenience for use anywhere.

Maintenance

1. **Cleaning Blades:** After each use, remove the blade set from the clipper. The stainless-steel blades are rinseable; simply run them under water to wash away excess clippings and trimmings. Ensure blades are dry before reattaching.



Figure 6: Cleaning the removable blades under water.

2. **Oiling Blades:** Periodically, apply a few drops of Wahl clipper oil (included in the kit) to the blades to ensure smooth operation and longevity. Apply oil while the clipper is running to distribute it evenly.
3. **Storage:** Store the clipper and all accessories in the provided premium hard storage case to protect them from damage and keep them organized.

Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted or not charged.	Charge the clipper fully. Ensure the power adapter is securely connected.
Clipper pulls hair or cuts poorly.	Blades are dull, dirty, or not oiled.	Clean and oil the blades. If problem persists, blades may need replacement.

Problem	Possible Cause	Solution
Guide comb does not attach securely.	Incorrect alignment or debris.	Ensure the comb is correctly aligned with the blade and snaps firmly into place. Check for any hair or debris obstructing the attachment points.
Charging indicator light remains red.	This model's indicator may not change color upon full charge.	Charge for the recommended duration (e.g., 60 minutes for full charge) or until sufficient run time is achieved.

Specifications

- **Model Number:** 9649P
- **Power Source:** Cordless/Rechargeable (1 Lithium Ion battery required)
- **Run Time:** Up to 60 minutes (cordless)
- **Blades:** Self-sharpening stainless-steel
- **Voltage:** Worldwide voltage (110 - 240V)
- **Product Dimensions:** 5 x 2 x 1 inches
- **Item Weight:** 1.4 Pounds
- **Color:** White/Blue
- **Manufacturer:** Wahl Clipper Corp
- **Country of Origin:** China
- **UPC:** 043917101712

Warranty and Support

Wahl products are designed for quality and durability. For any questions regarding your Wahl Color Pro Cordless Clipper, including warranty information or technical support, please contact Wahl customer service directly. You can often find contact details on the product packaging or by visiting the official Wahl website.
For additional resources and product tutorials, please visitwahlusa.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question