Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 4330249846

Instruction Manual

JustFine Replacement Remote Control

Model: 4330249846

1. Introduction

Thank you for choosing the JustFine Replacement Remote Control. This remote is designed as a high-quality, pre-programmed replacement for various Samsung TV models, including UN55B6000VF, BN59-00856A, LN32B650, LN32B530P7FUZA, LN52A650A1RXZL, LN40B540P8FXZC, and HL72A650C. It requires no additional programming; simply insert batteries to begin use.

2. Safety Information

- Do not expose the remote control to direct sunlight, high humidity, or extreme temperatures.
- Avoid dropping or subjecting the remote to strong impacts.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children.

3. Product Overview

The JustFine Replacement Remote Control features a standard layout for easy navigation and control of your compatible Samsung TV. Below are images illustrating the front and back of the remote.



Figure 3.1: Front view of the remote control. This image displays the full button layout, including the red power button at the top left, the numeric keypad, volume and channel controls, navigation pad, and various function buttons for TV operation.



Figure 3.2: Back view of the remote control. This image highlights the sleek, black design of the remote's rear casing and clearly shows the battery compartment cover located at the bottom.

4. Setup

This remote control is pre-programmed and requires no additional setup or coding. Simply install batteries to begin use.

4.1. Installing Batteries

1. Locate the battery compartment on the back of the remote control (refer to Figure 3.2).
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control.

5. Operating Instructions

Once batteries are installed, the remote control is ready for immediate use with your compatible Samsung TV. Point the remote directly at the TV's infrared receiver.

5.1. Basic Functions

- **Power (TV):** Press the **POWER** button to turn the TV on or off.
- **Volume Control:** Use the **VOL +/-** buttons to adjust the volume level.
- **Channel Control:** Use the **CH +/-** buttons to change channels.
- **Mute:** Press the **MUTE** button to silence the TV audio. Press again to restore.
- **Source/Input:** Press the **SOURCE** button to cycle through available input sources (HDMI, AV, etc.).
- **Number Pad:** Use the numeric buttons (0-9) to directly enter channel numbers.

5.2. Navigation and Menu

- **Directional Pad (Up/Down/Left/Right):** Use these buttons to navigate through on-screen menus and options.
- **Enter/OK:** Press the central button within the directional pad to confirm a selection.
- **Menu:** Access the TV's main menu.
- **Exit:** Exit the current menu or on-screen display.
- **Return:** Go back to the previous screen or channel.

5.3. Special Functions

- **Pre-CH:** Return to the previously viewed channel.
- **Tools:** Access quick settings or tools menu.
- **Info:** Display information about the current program or input.
- **Color Buttons (Red, Green, Yellow, Blue):** These buttons perform specific functions depending on the TV model or current on-screen content.

6. Maintenance

- Clean the remote control regularly with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical agents.
- Keep the remote control away from liquids.
- If the remote control becomes unresponsive, try replacing the batteries before troubleshooting further.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote not responding.	Obstruction between remote and TV.	Ensure a clear line of sight to the TV's IR receiver.
Remote not responding.	TV's IR receiver is faulty.	Test with another remote if available, or consult TV's manual.
Some buttons not working.	Specific button malfunction or TV incompatibility for that function.	Ensure the button is clean. While pre-programmed, some advanced functions may vary slightly across TV models.

8. Specifications

Feature	Detail
Brand	JustFine
Model Number	4330249846
Compatible Devices	Samsung Televisions (various models)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.72 ounces
Special Feature	Ergonomic design

9. Warranty and Support

This JustFine Replacement Remote Control is sold with a money-back guarantee and hassle-free return policy. A 30-day quality warranty is provided from the date of purchase.

9.1. Customer Support

For any problems or inquiries regarding your remote control, please contact us directly via email. Our customer support team is available to assist you with any issues you may encounter.

© 2025 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N1GCYIT

More documents and user manuals: **https://manuals.plus/**