Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MKJ32022835

ALLIMITY MKJ32022835 Replacement Remote Control User Manual

Model: MKJ32022835

Introduction

This manual provides instructions for the ALLIMITY MKJ32022835 replacement remote control. It is designed to function as a direct replacement for original LG remote controls, offering immediate usability without complex setup. Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.

Product Overview

The ALLIMITY MKJ32022835 is an infrared remote control designed for various LG television models. It features a standard layout for easy navigation and control of your television's functions.





This image displays the front view of the ALLIMITY MKJ32022835 remote control, showing all its buttons and their labels. The remote has a dark gray finish with clearly marked white and colored buttons.

Key Features

- Direct replacement, no programming required.
- Ergonomic design for comfortable handling.
- Infrared connectivity.
- Compatible with a wide range of LG TV models.

Setup

1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.

2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.

Note: This remote control does not require any programming or pairing. It is ready to use immediately after battery installation.

Operating Instructions

The remote control provides access to all standard functions of your compatible LG television.

Basic Functions

- **POWER:** Turns the TV on or off.
- **INPUT D/A / INPUT:** Selects the input source (e.g., HDMI, AV).
- **MODE TV / DVD / VCR:** Switches between TV, DVD, or VCR control modes (if applicable to your device).
- **VOL +/-:** Adjusts the volume level.
- **PR +/- (Program/Channel +/-):** Changes TV channels.
- **MUTE:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly select channels.
- **MENU:** Accesses the TV's main menu.
- **OK (Enter):** Confirms selections within menus.
- **Navigation Arrows (Up, Down, Left, Right):** Navigate through menus and options.
- **BACK / EXIT:** Returns to the previous screen or exits the current menu.
- **INFO / GUIDE:** Displays program information or the electronic program guide.
- **SIMPLINK:** Activates LG's HDMI-CEC feature for controlling connected devices.
- **TEXT:** Accesses teletext services.
- **RATIO:** Adjusts the screen aspect ratio.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Control playback of media (e.g., from a connected DVD player or USB device).
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services.
- **FAV:** Accesses favorite channels.
- **Q.VIEW:** Quick view of the previously watched channel.
- **UPDATE / INDEX / SLEEP / HOLD / TIME / REVEAL / SUBTITLE:** Advanced functions, refer to your TV's manual for specific usage.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.

- Ensure there are no obstructions between the remote control and the TV's infrared sensor.
- Make sure you are within the effective operating range (up to 10 meters).

- **Some buttons not working:**
  - Verify that the remote control is compatible with your specific LG TV model. Refer to the "Compatible Models" list in the Specifications section.
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.

Specifications

Feature	Detail
Brand	ALLIMITY
Model	MKJ32022835
Connectivity	Infrared
Special Feature	Ergonomic
Max Supported Devices	1
Number of Buttons	Approx. 20 main functional buttons
Max Range	10 Meters
Battery Type	AAA Alkaline (2 required)
UPC	606280075884
Compatible LG TV Models	22LB75, 26LB75, 26LC55, 32LB75, 32LB76, 32LC45, 32LC46, 32LC55, 37LC45, 37LC55, 37LF66, 37LF75, 42LC45, 42LC55, 42LF66, 42LF75, 42PC55, 47LF66, 50PC55, and many more LG TV models. Please refer to the product listing for a comprehensive list.

Warranty and Support

This product is a replacement remote control. For warranty information or technical support, please refer to the terms and conditions provided by the seller at the time of purchase. If you encounter any issues, please contact the seller directly for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N2T2RV4

More documents and user manuals: **https://manuals.plus/**