Nettech PN-17+AL

Nettech Universal Remote Control PN-17+AL Instruction Manual

Model: PN-17+AL

Introduction

This manual provides instructions for the setup, operation, and maintenance of your Nettech Universal Remote Control PN-17+AL. This remote is designed for use with Panasonic brand televisions, including Smart TV models. Please read this manual thoroughly before using the remote control.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back view of the remote control, illustrating the battery compartment and a label detailing potential programming options like "Three Digital Code" and "LEARN FUNCTION".

2. Initial Use

This Nettech remote control is pre-programmed for most Panasonic televisions. No complex setup is typically required for basic functions. Simply point the remote directly at your Panasonic TV and press the **POWER** button.

- Ensure there are no obstructions between the remote control and the TV's infrared receiver.

- For optimal performance, maintain a direct line of sight.

If the remote does not respond immediately, ensure batteries are correctly installed and have sufficient charge. Some advanced functions or specific TV models may require additional programming, which can often be found in your TV's original manual or through the remote's "LEARN FUNCTION" if available (refer to the label on the back of the remote for details on this feature).

Operating Instructions

Familiarize yourself with the buttons on your Nettech Universal Remote Control. Below is a general overview of common button functions:





Image: Front view of the remote control, displaying the layout and labels of all buttons.

Button	Function
POWER	Turns the TV on or off.
INPUT / TV / AV / SAP / SD/USB	Selects video input sources (e.g., HDMI, AV, USB).
MENU / INFO / GUIDE	Accesses the TV's main menu, displays information, or opens the program guide.
INTERNET	Direct access to Smart TV features or internet browser.
Navigation Pad (Up, Down, Left, Right, OK)	Navigates through menus and confirms selections.
RETURN / EXIT	Goes back to the previous screen or exits a menu.
VOL +/-	Adjusts the volume level.
CH +/-	Changes TV channels.
MUTE	Mutes or unmutes the TV audio.
Number Pad (0-9)	Direct channel entry.
Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Record)	Controls media playback on compatible devices (e.g., DVD player, USB media).

Maintenance

Cleaning the Remote Control

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

Battery Replacement

Replace the batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Ensure there is a clear line of sight between the remote's infrared emitter and the TV's receiver.
  - Move closer to the TV.
- **Some buttons not working or limited functionality:**
  - While this is a universal remote for Panasonic TVs, some highly specific or advanced functions of certain TV models may not be fully supported.
  - Ensure the remote is aimed directly at the TV.
  - If your TV has a "LEARN FUNCTION" or requires a specific code, refer to your TV's original manual or the label on the back of the remote for programming instructions.
- **Buttons feel sticky or unresponsive:**
  - This may indicate dirt or debris under the buttons. Clean the remote as described in the Maintenance section.
  - Ensure the remote has not been exposed to liquids.

Specifications

- **Brand:** Nettech
- **Model:** PN-17+AL
- **Compatible Devices:** Panasonic Televisions (including Smart TV models)
- **Connectivity Technology:** Infrared
- **Max Number of Supported Devices:** 1
- **Product Dimensions:** 3 x 3 x 3 inches (approximate)
- **Item Weight:** 3 ounces (approximate, without batteries)
- **Power Source:** 2 x AAA Batteries (not included)

Warranty and Support

This Nettech Universal Remote Control PN-17+AL comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.
For warranty claims, technical support, or further assistance, please contact your retailer or the Nettech customer service department. Please retain your proof of purchase for warranty validation.
Note: Warranty terms may vary based on region and retailer.

© 2023 Nettech. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question