Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RC-898M

ZdalaMit RC-898M Replacement Remote Control User Manual

For Onkyo AV Receiver Models: TX-NR646, TX-NR747, TX-NR545

Introduction

This manual provides instructions for the ZdalaMit RC-898M replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of specific Onkyo AV Receiver models. It requires no programming or pairing for initial use.



Image 1: Front view of the ZdalaMit RC-898M replacement remote control, showing all buttons and layout.

Compatibility

The ZdalaMit RC-898M remote control is compatible with the following Onkyo AV Receiver models:

- TX-NR646
- TX-NR747
- TX-NR545
- TXNR646
- TXNR747
- TXNR545

Important: Ensure your AV receiver model is listed above. This remote is not compatible with models not explicitly listed.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) 1.5V AA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Do not use rechargeable batteries. Only 1.5V AA alkaline batteries are recommended.



Image 2: Rear view of the remote control with the battery compartment open, showing where to insert two AA batteries.

Operating Instructions

Once batteries are installed, the ZdalaMit RC-898M remote control is ready for immediate use with compatible Onkyo AV Receivers. No programming or pairing is required.

Basic Functions:

- **Power Button:** Located at the top right, typically labeled "RECEIVER" or with a power symbol, to turn the AV receiver on or off.
- **Input Selector Buttons:** Buttons such as "BD/DVD", "CBL/SAT", "GAME", "PC", "CD", "TUNER", "NET", "BLUETOOTH", "PHONO" allow you to switch between different audio/video sources connected to your receiver.
- **Volume Control:** "VOL +" and "VOL -" buttons adjust the master volume of the receiver.
- **Muting:** The "MUTING" button temporarily silences the audio output.
- **Navigation Buttons:** A central directional pad (up, down, left, right) with an "ENTER" button is used for navigating menus on your receiver's display.
- **Menu Buttons:** "TOP MENU", "MENU", "SETUP", "HOME", "RETURN" provide access to various receiver settings and functions.
- **Playback Controls:** Buttons like "PLAY", "PAUSE", "STOP", "SKIP" (forward/backward), "SEARCH" are for controlling media playback.
- **Numeric Keypad:** Numbers 0-9, "+/- 10", and "CLR" are used for direct input or channel selection.

Note: This remote control cannot be programmed to operate a television or other devices. It is specifically designed for the listed Onkyo AV Receiver models.



Image 3: Angled view of the remote control, highlighting the ergonomic design and button layout.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Remote does not respond.	Ensure batteries are inserted correctly with proper polarity. Replace old batteries with new 1.5V AA alkaline batteries. Check if there is an obstruction between the remote and the AV receiver's infrared sensor. Ensure you are within the effective range of the receiver.
Certain functions do not work.	Verify that your AV receiver model is listed in the "Compatibility" section. This remote is designed for specific models. Confirm that the function you are trying to use is supported by your specific AV receiver model. This remote cannot be programmed for TV functions.
Remote works intermittently.	Batteries may be low. Replace them with new ones. Ensure a clear line of sight to the AV receiver.

Maintenance

- Keep the remote control dry. Liquids can damage the internal components.
- Avoid exposing the remote to extreme temperatures or direct sunlight.
- Clean the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Specifications

- **Model:** RC-898M
- **Power Supply:** 2 x 1.5V AA Alkaline Batteries (not included)
- **Dimensions:** Approximately 6 x 2 x 0.5 inches (15.24 x 5.08 x 1.27 cm)
- **Weight:** Approximately 3 ounces (85 grams) without batteries
- **Color:** Black
- **Special Feature:** Ergonomic design
- **Max Number of Supported Devices:** 1 (Onkyo AV Receiver)

Support

If you encounter any issues or have questions regarding your ZdalaMit RC-898M remote control that are not addressed in this manual, please contact the seller for assistance. Provide your product model number (RC-898M) and a detailed description of the issue when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N4KRRLW

More documents and user manuals: **https://manuals.plus/**