Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hampton Bay 7072-2RT

Hampton Bay 7072-2RT Twin Pack Outdoor Lantern User Manual

Model: 7072-2RT

Introduction

This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your new Hampton Bay 7072-2RT Twin Pack 1-Light Weathered Bronze Outdoor Lanterns. Please read this manual thoroughly before beginning installation or use and retain it for future reference.

Product Overview

The Hampton Bay 7072-2RT outdoor lanterns are designed to add classic American outdoor decor to your home with their deep weathered bronze finish and clear glass panels. They provide all-around illumination for porch areas and feature an opening at the bottom for easy bulb replacement.

Key Features:

- Clear glass with beveled edges and glass canopy in hexagon shape
- ETL listed for wet locations, ensuring durability in outdoor environments
- Weather resistant construction in a weathered bronze finish
- Uses up to one 100-watt medium base bulb per fixture (not included)

Package Contents:

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, do not attempt to install and contact customer support.

- Hampton Bay 7072-2RT 1-Light Outdoor Lantern (2 units)
- Mounting Hardware Kit (screws, wire nuts, mounting plate)
- Installation Instructions



Figure 1: Front view of the Hampton Bay 7072-2RT Twin Pack 1-Light Weathered Bronze Outdoor Lanterns.



Figure 2: Side view of a single Hampton Bay 7072-2RT outdoor lantern, highlighting the scroll arm and hexagonal glass design.

Setup and Installation

Safety Information:

- Always turn off power at the main circuit breaker or fuse box before beginning installation.
- Consult a qualified electrician if you are unsure about wiring procedures.
- Wear safety glasses and gloves during installation to prevent injury.
- Ensure the fixture is properly grounded according to local electrical codes.
- Do not exceed the maximum wattage specified for the bulb.

Tools Required:

- Phillips Head Screwdriver
- Flathead Screwdriver

- Wire Strippers
- Pliers
- Electrical Tape
- Ladder (if installing at height)

Installation Steps:

1. **1. Prepare the Installation Area:** Turn off the power to the junction box at the main circuit breaker. Use a voltage tester to confirm the power is off. Remove any existing light fixture from the junction box.
2. **2. Attach Mounting Bracket:** Secure the provided mounting bracket to the junction box using the screws included in the hardware kit. Ensure the bracket is firmly attached and level.
3. **3. Make Electrical Connections:** Carefully connect the fixture's wires to the house's electrical wires. Connect the black wire from the fixture to the black (hot) wire from the house. Connect the white wire from the fixture to the white (neutral) wire from the house. Connect the bare copper or green ground wire from the fixture to the house's ground wire or the ground screw on the mounting bracket. Secure all connections with wire nuts and wrap them with electrical tape for added insulation.
4. **4. Mount the Fixture:** Carefully tuck the wires into the junction box. Align the fixture with the mounting bracket and secure it using the provided screws. Ensure the fixture is flush against the mounting surface and no wires are pinched.
5. **5. Install Bulb:** Insert one 100-watt maximum medium base (E26) bulb (not included) into the socket. Do not overtighten the bulb. For energy efficiency, consider using LED or CFL bulbs.
6. **6. Restore Power:** Turn the power back on at the main circuit breaker and test the fixture to ensure it operates correctly.

Operating Instructions

The Hampton Bay 7072-2RT outdoor lantern operates via your home's standard electrical switch connected to the fixture's circuit.

- To turn the light **ON**, flip the connected wall switch to the 'ON' position.
- To turn the light **OFF**, flip the connected wall switch to the 'OFF' position.

For optimal performance and energy efficiency, ensure you use bulbs that are compatible with the fixture's specifications and your desired light output.

Maintenance

Cleaning:

- Always disconnect power to the fixture at the circuit breaker before cleaning.
- Wipe the fixture with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or polishes, as they may damage the finish or glass.
- Clean glass panels periodically to maintain optimal light output and appearance.

Bulb Replacement:

- Ensure power is off at the circuit breaker before replacing the bulb.
- Allow the old bulb to cool completely before touching it.
- Unscrew the old bulb counter-clockwise.

- Screw in a new 100-watt maximum medium base (E26) bulb clockwise.
- Restore power and test the fixture.

Weather Resistance:

This fixture is ETL listed for wet locations, indicating its suitability for direct exposure to rain and other outdoor elements. Periodically inspect the seals and connections for any signs of wear or damage to ensure continued weather resistance and prevent water intrusion.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Bulb is faulty or loose. Incorrect wiring.	Check the circuit breaker and ensure it is ON. Replace the bulb or tighten it securely. Verify all wiring connections are correct and secure (consult an electrician if needed).
Light flickers.	Loose bulb. Loose wiring connection. Incompatible dimmer switch (if applicable).	Tighten the bulb. Check and secure all wiring connections. Ensure the dimmer switch is compatible with the bulb type and fixture.
Fixture hums.	Incompatible dimmer switch. Loose components within the fixture.	Ensure the dimmer switch is compatible with the bulb type and fixture. Check for any loose parts or screws within the fixture.

Specifications

- **Model:** 7072-2RT
- **Brand:** Hampton Bay
- **Dimensions:** 18 x 16 x 10 inches (per fixture); 4 Pounds (total for twin pack)
- **Bulb Type:** Medium Base (E26)
- **Max Wattage:** 100 Watts per fixture
- **Finish:** Weathered Bronze
- **Glass:** Clear
- **Location Rating:** ETL Listed for Wet Locations
- **Power Source:** Hardwired

Warranty Information

For specific warranty details, please refer to the warranty card included with your purchase or visit the Hampton Bay section on The Home Depot's official website. Typically, Hampton Bay products are covered by a limited warranty against defects in materials and workmanship for a specified period from the date of purchase. This warranty generally does not cover damage resulting from improper installation, misuse, abuse, or natural disasters.

Support and Contact

If you require further assistance, have questions not covered in this manual, or need to report a missing/damaged part,

please contact Hampton Bay customer support.

- **Website:** Hampton Bay Official Website (via Home Depot)
- **Phone:** Refer to your product packaging or the official Hampton Bay website for the most current customer service contact numbers.

When contacting support, please have your model number (**7072-2RT**) and date of purchase ready to expedite assistance.

© 2024 Hampton Bay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N4OO396

More documents and user manuals: **https://manuals.plus/**