Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fotopro DIGI-3400

Fotopro Camera Tripod User Manual

Model: DIGI-3400

INTRODUCTION

The Fotopro Camera Tripod is a versatile and portable solution designed for photographers and videographers using various devices, including DSLRs, mirrorless cameras, smartphones, and action cameras. Its lightweight aluminum construction and compact design make it ideal for travel, while its stable flip-lock system and 3-way pan head ensure precise and steady shots in diverse environments.



Image: Fotopro Camera Tripod, showcasing its main components including the tripod, phone mount, and Bluetooth remote.

What's in the Box

Verify that all components are present in your package:

- Aluminum Tripod x 1
- Pan Head with Quick Release Plate x 1
- Bluetooth Remote x 1 (requires 1 CR123A battery, included)
- Phone Mount x 1
- Carrying Bag x 1



Image: All items included in the Fotopro tripod package: tripod, quick release plate, phone holder, Bluetooth remote, and carrying bag.

Setup Guide

1. **Unfold the Tripod Legs:** Gently extend the tripod legs by releasing the flip locks on each section. Adjust the height of each leg section as needed, then secure the flip locks firmly.



Image: Demonstrates how to unfold the tripod legs and secure the flip locks.

2. **Attach the Quick Release Plate:**
    - Slide the buckle beside the quick release plate to detach it from the pan head.
    - Connect your camera or device to the quick release plate using the 1/4" screw. Ensure it is securely tightened.
    - Reload the quick release plate onto the pan head until it clicks into place.



Image: Illustrates attaching the quick release plate to a camera body.

3. **Install Phone Mount (Optional):** If using a smartphone, attach the phone mount to the quick release plate or directly to the tripod's 1/4" screw. Insert your smartphone into the mount.
4. **Pair Bluetooth Remote:**
    - Ensure the CR123A battery is correctly installed in the remote.
    - Turn on the Bluetooth remote.
    - On your smartphone, go to Bluetooth settings and search for available devices. Select the Fotopro remote to pair.

Your browser does not support the video tag.

Video: A demonstration of setting up the Fotopro Camera Tripod DIGI-3400, including attaching a camera and adjusting the head.

Operating Instructions

Adjusting Height and Stability

- **Leg Extension:** Use the flip locks on each leg section to extend or retract the legs. Ensure all locks are securely

fastened before use to maintain stability. The tripod can be adjusted from 15 inches to 47 inches.

- **Center Column:** The center column can be raised for additional height. Use the crank handle to smoothly extend or retract it.
- **Non-slip Rubber Feet:** The tripod features non-slip rubber feet for enhanced stability on various surfaces.

Pan Head Operation

The 3-way pan head allows for precise camera positioning:

- **Horizontal Panning (360°):** Loosen the horizontal lock knob to rotate the camera 360 degrees for panoramic shots.
- **Vertical Tilting:** Use the pan handle to tilt the camera up or down. Secure the tilt lock knob once the desired angle is achieved.
- **Portrait/Landscape Orientation:** The quick release plate can be rotated 90 degrees to switch between portrait and landscape shooting modes.
- **Spirit Level:** Utilize the built-in spirit level to ensure your camera is perfectly horizontal.



Image: Demonstrates the tripod's capability for panoramic shooting and various angles including horizontal, vertical, overhead, and

elevation shooting.



Image: Close-up view illustrating the 360-degree horizontal rotation and 180-degree vertical adjustment capabilities of the tripod head.

Using the Bluetooth Remote

Once paired, the Bluetooth remote allows you to trigger your smartphone's camera shutter wirelessly, ideal for group photos or self-portraits.

Your browser does not support the video tag.

Video: Shows the use of the Fotopro Phone Tripod with Wireless Remote, demonstrating remote shutter control.

Compatibility

The tripod's standard 1/4" screw mount ensures broad compatibility with a wide range of devices:

- Digital Single-Lens Reflex (DSLR) Cameras
- Mirrorless Cameras

- Smartphones (with included phone mount)
- Action Cameras
- Digital Video (DV) Cameras
- Ring Lights



Image: Illustrates the wide compatibility of the Fotopro tripod with DSLR cameras, smartphones, action cameras, and ring lights.

Maintenance

- **Cleaning:** Wipe the tripod with a soft, damp cloth after each use, especially if used outdoors or in dusty/sandy environments. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Ensure the tripod is completely dry before folding and storing to prevent corrosion.
- **Storage:** Store the tripod in its carrying bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Lubrication:** Do not apply lubricants to the leg locks or pan head mechanisms unless specifically instructed by Fotopro support.

Troubleshooting

Problem	Possible Cause	Solution
Tripod is unstable.	Leg locks not fully engaged; uneven surface; overloaded.	Ensure all flip locks are securely fastened. Adjust leg lengths to compensate for uneven terrain. Do not exceed the maximum load capacity of 4.4 lbs.
Pan head movement is stiff or jerky.	Lock knobs are too tight; dirt/debris in mechanism.	Loosen the pan and tilt lock knobs. Clean the head area carefully.
Bluetooth remote not connecting.	Battery low/dead; remote not in pairing mode; phone Bluetooth off.	Replace the CR123A battery. Ensure the remote is turned on and in pairing mode. Verify Bluetooth is enabled on your smartphone.
Camera/phone not secure on quick release plate.	Screw not tightened; plate not fully seated.	Ensure the 1/4" screw is tightly fastened to your device. Confirm the quick release plate is fully clicked into the pan head.

Specifications

- **Model Name:** DIGI-3400
- **Material:** Aluminum, Rubber
- **Item Weight:** 1.25 pounds (0.57 kg)
- **Product Dimensions (Folded):** 2.5 x 2.5 x 14.9 inches (6.35 x 6.35 x 37.85 cm)
- **Maximum Height:** 47 Inches (119.38 cm)
- **Minimum Height:** 15 Inches (38.1 cm)
- **Weight Limit (Load Capacity):** 4.4 Pounds (2 kg)
- **Tripod Head Type:** 3-Way Pan Head
- **Compatible Devices:** DV, DSLR, Sports Cam, Smartphone
- **Special Features:** Lightweight, Portable, Adjustable, 360° Panoramic, Spirit Level
- **Bluetooth Remote Battery:** 1 x CR123A (included)



Image: Visual representation of the tripod's portability and key specifications like weight, max load, and folded height.

Warranty and Support

Fotopro products are manufactured with high-quality materials and undergo strict quality control. For warranty information, technical support, or service inquiries, please contact Fotopro customer service.

- **Manufacturer:** Fotopro (Guangdong) Image Industrial Co., Ltd
- **Manufacturer Email:** support@fotopro.com
- **EU Representative:** eVatmaster Consulting GmbH
- **EU Representative Email:** contact@evatmaster.com

Please retain your proof of purchase for warranty claims.



Image: Product packaging displaying manufacturer contact information and compliance marks.

© 2024 Fotopro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N562A19

More documents and user manuals: **https://manuals.plus/**