Nespresso EN80BCA

Nespresso Inissia Coffee Maker User Manual

Brand: Nespresso

Model: EN80BCA

Product Overview

The Nespresso Inissia Coffee Maker is a compact, lightweight, and user-friendly machine designed to deliver barista-style coffee with ease. Its simple one-touch operation and patented 19-bar extraction system ensure a perfect cup every time. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Inissia machine.





Figure 1: The Nespresso Inissia Coffee Maker, showcasing its sleek black design and compact form factor, ready to brew a fresh cup of espresso.

Setup and First Use

1. **Unboxing:** Carefully remove the machine and all components from the packaging. Ensure all included items are present: Nespresso Machine, User Manual, Welcome Folder, and Capsule Welcome Kit.
2. **Placement:** Place the machine on a stable, flat, and heat-resistant surface near a power outlet.
3. **Water Tank:** Fill the water tank with fresh, potable water. Do not use milk or other liquids.
4. **Power On:** Plug the machine into a grounded power outlet. Press either the Espresso or Lungo button to turn the machine on. The buttons will blink as the machine heats up.
5. **First Rinse:** Before first use, perform a rinse cycle. Place a container (at least 0.5L) under the coffee outlet. Press the Lungo button three times consecutively. This primes the pump and cleans the system. The water will flow through and the machine will stop automatically.

6. **Ready:** The machine is ready when the buttons stop blinking and glow steadily.

Operating Instructions

The Inissia machine offers two programmable cup sizes: Espresso and Lungo, allowing for a personalized coffee experience.



Figure 2: Key operational features of the Nespresso Inissia, highlighting its efficiency and convenience.

Brewing Coffee:

1. **Fill Water Tank:** Ensure the water tank is filled with fresh water.
2. **Insert Capsule:** Lift the lever completely and insert a Nespresso Original capsule into the capsule compartment. Close the lever firmly.
3. **Place Cup:** Place a cup under the coffee outlet. For larger cups, the drip tray can be folded up or removed.
4. **Select Coffee Size:**
   - Press the **Espresso button** (40 ml) for a short, intense coffee.

- Press the **Lungo button** (110 ml) for a longer coffee.



Figure 3: Visual representation of the Espresso (40ml) and Lungo (110ml) cup sizes.

5. **Brewing Process:** The machine will start brewing. The buttons will blink during brewing and become steady when complete.
6. **Eject Capsule:** After brewing, lift the lever to eject the used capsule into the integrated capsule container.

Energy Saving Mode:

The Inissia machine is designed with energy efficiency in mind. It automatically shuts off after 9 minutes of inactivity to conserve power. To reactivate the machine, simply press any coffee button.

Maintenance and Cleaning

Regular cleaning and maintenance ensure optimal performance and longevity of your Nespresso Inissia machine.

Daily Cleaning:

- **Drip Tray and Capsule Container:** Empty and rinse the drip tray and used capsule container daily. Wash them with warm water and a mild detergent.

- **Water Tank:** Empty and rinse the water tank daily. Refill with fresh water before each use.
- **Machine Exterior:** Wipe the machine's exterior with a soft, damp cloth. Do not use abrasive cleaning agents or immerse the machine in water.

Descaling:

Descaling is crucial to remove mineral deposits and maintain coffee quality. The frequency depends on water hardness and usage. Nespresso recommends descaling at least once a year, or more frequently in hard water areas.

1. Refer to the specific descaling instructions provided with your Nespresso descaling kit.
2. Ensure the machine is off and empty the water tank and capsule container.
3. Pour the Nespresso descaling solution into the water tank, then fill with water as per the descaling kit instructions.
4. Place a large container (at least 1L) under the coffee outlet.
5. Follow the descaling program steps, typically involving pressing and holding buttons to initiate the cycle.
6. After the descaling solution has run through, rinse the water tank thoroughly and fill with fresh water. Run two full water tanks through the machine to rinse it completely.

Troubleshooting

Problem	Possible Cause	Solution
No coffee flow, or very little coffee.	• Water tank empty. • Machine needs descaling. • Air bubble in the system.	• Fill water tank. • Perform descaling procedure. • Run a Lungo cycle without a capsule to clear air.
Coffee is not hot enough.	• Cold cup. • Machine not fully heated.	• Pre-heat cup with hot water. • Wait for buttons to stop blinking before brewing.
Water leaking from machine.	• Water tank not correctly positioned. • Used capsule stuck.	• Ensure water tank is firmly seated. • Open and close the lever to eject any stuck capsule.
Machine does not turn on.	• Not plugged in. • Power outage. • Automatic shut-off activated.	• Check power cord connection. • Check power supply. • Press any coffee button to reactivate.

Specifications



Figure 4: Compact design of the Nespresso Inissia, illustrating its small footprint with approximate dimensions.

Feature	Detail
Brand	Nespresso
Model Name	Nespresso Inissia (EN80BCA)
Color	Black/White
Product Dimensions (D x W x H)	12.64"D x 4.72"W x 9.06"H (approx. 32cm D x 12cm W x 23cm H)
Item Weight	5.29 pounds (approx. 2.4 kg)
Special Feature	Programmable
Coffee Maker Type	Espresso Machine
Style	Inissia

Feature	Detail
Specific Uses For Product	Espresso
Recommended Uses For Product	Home, Office
Included Components	Capsule Welcome Kit, Nespresso Machine, User Manual, Welcome Folder
Operation Mode	Fully Automatic
Voltage	120 Volts
Human Interface Input	Buttons
Coffee Input Type	Capsule
UPC	044387100809
Automatic Shut-off	After 9 minutes of inactivity
Heat-up Time	Approximately 25 seconds

Warranty and Support

Warranty Information:

Nespresso machines typically come with a limited warranty covering defects in materials and workmanship. Please refer to the specific warranty card included in your product packaging or visit the official Nespresso website for detailed terms and conditions, including warranty duration and coverage specifics for your region.

Customer Support:

For technical assistance, troubleshooting beyond this manual, or to order accessories and descaling kits, please contact Nespresso Customer Service. You can find contact information (phone numbers, email, or live chat) on the official Nespresso website or through the Nespresso app. When contacting support, please have your machine's model number (EN80BCA) and serial number ready.
Visit the official Nespresso Store for more information:Nespresso Store on Amazon

© 2023 Nespresso. All rights reserved. This manual is for informational purposes only.