Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AKB73575421

ZdalaMit AKB73575421 Replacement Remote Control User Manual for LG Sound Bars

Model: AKB73575421 | Brand: ZdalaMit

Introduction

This user manual provides instructions for the ZdalaMit AKB73575421 replacement remote control, designed for use with various LG Sound Bar models. This remote is pre-programmed and requires no additional setup beyond battery installation.

Compatible LG Sound Bar models include: **NB3520A, NB3520ANB, NB2420A, NB3250A, NB 3250A, NB3520A2, NB3250A, NB3530A, NB3532A, NB3530ANB, NB4530B**.

Setup

1. Battery Installation

The ZdalaMit AKB73575421 remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for use. No programming or pairing is required.




OPTICAL
FOLDER
VOL
MUTE
AUTO POWER
AV SYNC
INFO
REPEAT
SOUND EFFECT
AUTO VOLUME
WOOFER LEVEL
1
2
3
4
5
6
7
8
9
DRC
0
SLEEP
MUTE
VOL+
PR/CH
AV/INPUT
VOL−
PR/CH
TV

Figure 1: Front view of the ZdalaMit AKB73575421 Replacement Remote Control. This image shows the layout of all buttons, including power, volume, mute, function, optical, folder, playback controls, number pad, and TV controls.

Operating Instructions

This section details the functions of the buttons on your ZdalaMit AKB73575421 replacement remote control.

POWER ( ): Turns the LG Sound Bar system on or off.

FUNCTION: Cycles through available input functions (e.g., Optical, Bluetooth, USB).

OPTICAL: Directly selects the Optical input source.

FOLDER (/): Navigates through folders when playing media from a USB device.

VOL (+ / -): Adjusts the main volume level of the sound bar.

MUTE ( ): Mutes or unmutes the sound.

AUTO POWER: Activates or deactivates the auto power feature (if supported by the sound bar).

AV SYNC: Adjusts audio-video synchronization.

INFO: Displays information about the current status or track.

REPEAT: Toggles repeat playback modes (e.g., repeat one, repeat all).

Playback Controls (/ / / /)

- **(Previous)**: Skips to the previous track/file.
- **(Stop)**: Stops playback.
- **(Next)**: Skips to the next track/file.
- **(Fast Rewind)**: Rewinds playback.
- **(Fast Forward)**: Fast forwards playback.
- / **(Play/Pause)**: Plays or pauses playback.

SOUND EFFECT: Cycles through various sound effects or equalizer presets.

AUTO VOLUME: Activates or deactivates automatic volume leveling.

WOOFER LEVEL: Adjusts the subwoofer volume level.

Number Buttons (0-9): Used for direct track selection or other numerical inputs.

DRC (Dynamic Range Control): Adjusts the dynamic range of the audio.

SLEEP: Sets a sleep timer for the sound bar.

TV Controls (MUTE, VOL+, VOL-, PR/CH▲, PR/CH▼, AV/INPUT, TV POWER) These buttons are typically for basic control of a connected television. Their functionality may vary depending on the TV brand and model, and may require specific setup on the sound bar or TV.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials,

as these can damage the remote's surface or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

Troubleshooting

Remote Control Not Responding:

- Ensure batteries are inserted correctly with the correct polarity (+/-).
- Replace old batteries with new AAA alkaline batteries.
- Ensure there are no obstructions between the remote control and the sound bar's infrared receiver.
- Confirm you are within the effective range of the sound bar's IR receiver.

Specific Buttons Not Working:

- Verify that the sound bar is powered on and in the correct operating mode.
- For TV control buttons, ensure your TV is compatible and any necessary setup (usually on the sound bar or TV itself) has been performed.

Specifications

Feature	Detail
Model Number	AKB73575421
Brand	ZdalaMit
Compatibility	LG Sound Bar models: NB3520A, NB3520ANB, NB2420A, NB3250A, NB 3250A, NB3520A2, NB3250A, NB3530A, NB3532A, NB3530ANB, NB4530B
Power Supply	2 x AAA Alkaline Batteries (not included)
Special Feature	Pre-programmed, no pairing required
Color	Black
Product Dimensions	6.35 x 1.79 x 0.55 inches (16.13 x 4.55 x 1.40 cm)
Item Weight	2 ounces (56.7 grams)
Compatible Devices	Home Theater (specifically LG Sound Bars)




OPTICAL
FOLDER
VOL
MUTE
AUTO POWER
AV SYNC
INFO
REPEAT
SOUND EFFECT
AUTO VOLUME
WOOFER LEVEL
1
2
3
4
5
6
7
8
9
DRC
0
SLEEP
MUTE
VOL+
PR/CH
AV/INPUT
VOL−
PR/CH
TV

6.3 inch



Figure 2: Dimensions of the ZdalaMit AKB73575421 Replacement Remote Control, showing a length of 6.3 inches and a width of 1.77 inches.

Warranty and Support

As a replacement remote control, specific manufacturer warranty details from ZdalaMit are not provided. Please refer to the seller's return and warranty policy at the point of purchase for information regarding returns or defects. For operational issues, please consult the Troubleshooting section of this manual or the user manual for your specific LG Sound Bar model.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N5LZN7K

More documents and user manuals: **https://manuals.plus/**