Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BN59-00609A

ZdalaMit BN59-00609A Replacement Remote Control User Manual

For Samsung LCD LED Televisions

1. Introduction

This manual provides instructions for the ZdalaMit BN59-00609A Replacement Remote Control. This remote is designed to function as a direct replacement for original Samsung LCD LED TV remote models, offering seamless operation without the need for complex programming or pairing. Please read this manual carefully to ensure proper setup and use of your new remote control.

2. Product Overview

The ZdalaMit BN59-00609A is an ergonomic replacement remote control for various Samsung LCD LED TV models. It features a standard layout for easy navigation and control of your television's functions.



Figure 2.1: Front view of the ZdalaMit BN59-00609A remote control, displaying the power button, number pad, navigation controls, and function buttons.



Figure 2.2: Back view of the ZdalaMit BN59-00609A remote control, illustrating the battery compartment where two AAA batteries are inserted.

3. Setup

The ZdalaMit BN59-00609A remote control requires no programming or pairing. Simply install the batteries, and it will be ready for use with compatible Samsung TVs.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) 1.5V AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control and must be purchased separately.

4. Operating Instructions

Once batteries are installed, the remote control is ready to operate your compatible Samsung LCD LED TV. Point the remote directly at your television's infrared receiver.

4.1 Basic Functions

- **Power (Red Button):** Turns the TV on or off.
- **Number Pad (0-9):** Directly selects channels.
- **Volume Up/Down (+/-):** Adjusts the sound volume.
- **Channel Up/Down (CH +/-):** Changes the television channel.
- **Mute:** Silences the television audio.
- **Menu:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate through menus and confirm selections.
- **Source:** Changes the input source (e.g., HDMI, AV).
- **Exit:** Exits the current menu or function.

4.2 Compatible Samsung TV Models

This replacement remote control is compatible with a wide range of Samsung LCD LED TV models, including but not limited to:

- LA26R7, LA32R7, LA40R7, LA26R71BA
- LA32S8, LA37S8, LA40S8, LA46S8
- LE46S81B
- PS-42C62H, PS-50C62H, PS-42C91H
- PS42C9H, PS50C9H, PS50C91H

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** Replace batteries when the remote's response becomes sluggish or stops working. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you encounter issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new 1.5V AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm you are pointing the remote directly at the TV.
- **Limited Functionality:**
  - Verify that your TV model is listed in the compatible models section (Section 4.2). While designed for broad compatibility, some specific advanced functions may vary depending on the original TV model.

7. Specifications

Feature	Specification
Model Number	BN59-00609A
Brand	ZdalaMit
Compatible Devices	Samsung LCD LED Televisions
Power Supply	2 x 1.5V AAA Batteries (not included)
Product Dimensions	6 x 2 x 1 inches (approximately)
Item Weight	2 ounces (approximately)
Color	Black
Special Feature	Ergonomic design

8. Warranty and Support

For any questions, concerns, or support regarding your ZdalaMit BN59-00609A Replacement Remote Control, please contact the seller or manufacturer directly through your purchase platform. Specific warranty details may vary by retailer or region.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N5MAPWT

More documents and user manuals: **https://manuals.plus/**