Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Scangrip 03.5612

Scangrip 03.5612 Slim LED Work Light User Manual

Model: 03.5612

1. Introduction

Thank you for choosing the Scangrip 03.5612 Slim LED Work Light. This compact and powerful work light is designed for professional use, offering versatile illumination with its slim profile, magnetic base, and flexible head. Please read this manual carefully before using the product to ensure safe and optimal operation.





Figure 1: The Scangrip 03.5612 Slim LED Work Light in its compact, folded state, showcasing its durable blue casing and LED panel.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Do not look directly into the LED light when it is on, as it can cause eye damage.
- Keep the device away from water and other liquids.
- Do not operate the light if it appears damaged.
- Do not attempt to open or modify the device. There are no user-serviceable parts inside.
- Use only the charging cable provided or a compatible USB charger.
- Keep out of reach of children.
- Do not expose the battery to extreme temperatures or direct sunlight.

3. Package Contents

Please check the package for the following items:

- Scangrip 03.5612 Slim LED Work Light
- USB Charging Cable

- User Manual (this document)

Note: A USB power adapter is not included and must be supplied by the user.

4. Setup and Charging

4.1 Initial Charge

Before first use, fully charge the work light. This ensures optimal battery performance and longevity.

1. Locate the charging port on the device.
2. Connect the supplied USB charging cable to the work light.
3. Connect the other end of the USB cable to a suitable USB power adapter (e.g., a smartphone charger) or a powered USB port.
4. The charging indicator light will illuminate (typically red) during charging and change color (typically green) when fully charged.
5. A full charge typically takes approximately 4.5 hours.

5. Operating Instructions

5.1 Power On/Off and Light Modes

The Scangrip 03.5612 features multiple light functions:

- **Main Light (Work Light):** Press the power button once to activate the main LED panel. This provides broad illumination.
- **Spotlight (Top Light):** Press the power button again to switch to the spotlight located at the top of the unit. This provides focused illumination.
- **Power Off:** Press the power button a third time to turn off the light.

5.2 Flexible Head and Magnetic Base

The work light is designed for versatile positioning:

- **Adjustable Head:** The head of the light can be rotated and angled to direct illumination precisely where needed.
- **Magnetic Base:** The base of the unit contains a strong magnet, allowing it to be securely attached to metallic surfaces for hands-free operation.
- **Integrated Hook:** A retractable hook is also available for hanging the light in various locations.



Figure 2: A hand demonstrating the extended position of the Scangrip 03.5612, highlighting its slim design and adjustable head for precise lighting.



Figure 3: An individual using the Scangrip 03.5612 to illuminate the interior of a car, demonstrating its practical application in tight spaces.

6. Maintenance

6.1 Cleaning

To clean the work light, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the casing or LED lens.

6.2 Storage

When not in use for extended periods, store the work light in a cool, dry place. It is recommended to fully charge the battery every 3-6 months to maintain battery health.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the device fully.
Light is dim.	Low battery.	Charge the device fully.
Device not charging.	Faulty cable or power adapter.	Try a different USB cable or power adapter. Ensure connections are secure.
Light flickers.	Low battery or internal issue.	Charge the device. If problem persists, contact customer support.

8. Specifications

Model	03.5612
Light Source	LED
Light Output (Max)	500 lumens
Power Source	Rechargeable Lithium-Ion Battery
Battery Voltage	8 volts
Charging Time	Approx. 4.5 hours
Material	Metal
Color	Blue
Weight	0.15 kg
Special Features	Durable, Water Resistant, Magnetic Mount, Flexible Head

9. Warranty and Support

Scangrip products are manufactured to high-quality standards and come with a manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty information provided with your purchase or visit the official Scangrip website.

If you encounter any issues or have questions regarding your Scangrip 03.5612 Slim LED Work Light, please contact

your retailer or Scangrip customer support for assistance. You can find contact information on the official Scangrip website: www.scangrip.com

© 2024 Scangrip. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N7BOM56

More documents and user manuals: **https://manuals.plus/**