iJoy 45499

iJoy Beach Bomb IP66 Waterproof Bluetooth Speaker User Manual

Model: 45499

Introduction

Thank you for purchasing the iJoy Beach Bomb IP66 Waterproof Bluetooth Speaker. This portable and durable speaker is designed to deliver high-quality stereo sound with powerful bass, perfect for both indoor and outdoor environments. Its IP66 waterproof rating ensures it can withstand splashes, rain, and even submersion, making it ideal for beach parties, poolside relaxation, or shower use. This manual will guide you through the setup, operation, and maintenance of your new speaker.

Package Contents

Please check the box for the following items:

- iJoy Beach Bomb Bluetooth Speaker
- USB to Micro USB Charging Cable
- 3.5mm Audio Cable
- Strap Hook
- User Manual



Image: All items included in the iJoy Beach Bomb package, including the speaker, charging cable, audio cable, strap hook, and user manual.

Controls and Ports

Familiarize yourself with the buttons and ports on your iJoy Beach Bomb speaker:

Top Panel Controls:



Image: Top view of the speaker showing the control buttons: On/Off, Previous, Next, Volume Down, Volume Up, and Play/Answer Call/End Call.

- **ON/OFF Button:** Press and hold to power the speaker on or off.
- **PREVIOUS Button:** Press to go to the previous track.
- **NEXT Button:** Press to go to the next track.
- **VOLUME DOWN Button:** Press to decrease the volume.
- **VOLUME UP Button:** Press to increase the volume.
- **PLAY/ANSWER CALL/END CALL Button:** Press to play or pause music. Press to answer an incoming call, or press again to end a call.

Rear Ports (under protective cover):



Image: Rear view of the speaker showing the protected ports: Reset, AUX In, and DC 5V charging port.

- **RESET:** A small pinhole for resetting the device if it becomes unresponsive.
- **AUX IN:** 3.5mm audio input for connecting non-Bluetooth devices.
- **DC 5V:** Micro USB charging port.

Setup

1. Charging the Speaker

Before first use, fully charge your iJoy Beach Bomb speaker. Open the protective cover on the rear of the speaker to access the DC 5V port. Connect the provided Micro USB cable to the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate. Once fully charged (approximately 2 hours), the light will turn off or change color, depending on the model. A full charge provides up to 6 hours of playback time.

2. Powering On/Off

To turn the speaker **ON**, press and hold the **ON/OFF** button on the top panel until you hear an audible prompt or see an indicator light. To turn the speaker **OFF**, press and hold the **ON/OFF** button again until the prompt or light indicates it's off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (it will usually enter this mode automatically when powered on for the first time or if no device is connected). You may hear a prompt indicating it's ready to pair.
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for new devices.

3. Select "iJoy Beach Bomb" from the list of available devices.
4. Once successfully paired, the speaker will provide an audible confirmation. You can now play audio from your device through the speaker.

4. AUX Connection

For devices without Bluetooth, or to conserve battery, you can use the 3.5mm audio cable. Open the protective cover on the rear of the speaker. Connect one end of the provided 3.5mm audio cable to the **AUX IN** port on the speaker and the other end to the headphone jack of your audio device. The speaker will automatically switch to AUX mode.

Operating Instructions

Music Playback

- **Play/Pause:** Press the **PLAY/ANSWER CALL/END CALL** button to play or pause the current track.
- **Next Track:** Press the **NEXT** button to skip to the next song.
- **Previous Track:** Press the **PREVIOUS** button to go back to the beginning of the current song or to the previous song.
- **Volume Control:** Press the **VOLUME UP** button to increase volume and the **VOLUME DOWN** button to decrease volume.

Call Management (Bluetooth Mode)

When connected via Bluetooth, the built-in microphone allows for hands-free calling:

- **Answer Call:** When an incoming call rings, press the **PLAY/ANSWER CALL/END CALL** button to answer.
- **End Call:** During a call, press the **PLAY/ANSWER CALL/END CALL** button to end the conversation.
- **Reject Call:** Press and hold the **PLAY/ANSWER CALL/END CALL** button to reject an incoming call.

Maintenance

To ensure the longevity and optimal performance of your iJoy Beach Bomb speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** Always ensure the protective cover for the charging and AUX ports is securely closed when using the speaker near water or in wet conditions to maintain its IP66 waterproof rating.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use.

Troubleshooting

If you encounter any issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided USB cable.
No sound from speaker.	Volume is too low or muted. Device not connected.	Increase speaker and device volume. Ensure Bluetooth is connected or AUX cable is properly inserted.
Bluetooth pairing fails.	Speaker not in pairing mode. Device Bluetooth off. Too far from speaker.	Ensure speaker is on and in pairing mode. Turn device Bluetooth off and on. Move device closer to speaker (within 30 feet).
Sound quality is poor or distorted.	Device volume too high. Interference.	Lower the volume on your device. Move speaker away from other electronic devices that may cause interference.
Speaker is unresponsive.	Software glitch.	Use a thin object (like a paperclip) to press the**RESET** button located under the protective cover on the rear of the speaker.

Specifications

- **Model Name:** IJOY BEACH BOMB indigo
- **Model Number:** 45499
- **Brand:** iJoy
- **Color:** Indigo
- **Controller Type:** Button
- **Connectivity Technology:** Bluetooth
- **Special Features:** Bluetooth, Built-in Microphone
- **Waterproof Rating:** IP66
- **Battery Life:** Up to 6 hours
- **Max Speaker Output Power:** 5 Watts
- **Material:** Plastic, Rubber
- **Mounting Type:** Table Mount
- **Dimensions:** 22.2 x 12.1 x 6.4 cm (8.74 x 4.76 x 2.52 inches)
- **Weight:** 222.26 grams (0.49 pounds)
- **Recommended Uses:** Indoor, Outdoor, Pool, Beach
- **Compatible Devices:** Universal

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or

contact iJoy customer service directly. Keep your proof of purchase for any warranty claims.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question