Ariete 0155CR

Ariete Vintage Toaster 155BEIGE User Manual

Model: 0155CR | Brand: Ariete

1. Introduction

This manual provides essential information for the safe and efficient operation of your Ariete Vintage Toaster 155BEIGE. Please read these instructions carefully before using the appliance and retain them for future reference.



Figure 1: The Ariete Vintage Toaster 155BEIGE, showcasing its classic design and two toasting slots.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off",

then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a risk of fire or electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.
- Do not operate unattended.



Figure 2: The toaster features tempered walls, ensuring the exterior remains cool to the touch during operation for enhanced safety.

3. Product Overview

Familiarize yourself with the components of your Ariete Vintage Toaster:

1. **Toasting Slots:** Two wide slots for various bread types.
2. **Carriage Lever:** Lowers bread into the toasting slots and initiates the toasting cycle.
3. **Browning Control Dial:** Adjusts the desired level of toast browning (settings 1-6).
4. **STOP Button:** Immediately cancels the toasting cycle.
5. **DEFROST Button:** Defrosts and toasts frozen bread.
6. **REHEAT Button:** Reheats previously toasted bread without further browning.
7. **Crumb Tray:** Collects crumbs for easy cleaning.
8. **Warming Rack (Optional/Accessory):** For warming pastries or rolls.



Figure 3: Detailed view of the toaster's control panel, highlighting the browning dial and function buttons.

4. Setup

Before first use, follow these steps:

- **Unpacking:** Remove all packaging materials and labels from the toaster.
- **Placement:** Place the toaster on a stable, heat-resistant, and non-flammable surface, away from curtains or other flammable materials. Ensure adequate ventilation around the appliance.
- **First Use (Burn-off):** It is recommended to operate the toaster empty for a few minutes on the highest browning setting (6) to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal and will dissipate. Ensure the area is well-ventilated.
- **Power Connection:** Plug the power cord into a suitable 230 Volt AC electrical outlet.



Figure 4: Proper placement of the toaster on a kitchen counter, ensuring stability and ventilation.

5. Operating Instructions

5.1 Toasting Bread

1. Insert slices of bread into the toasting slots.
2. Select your desired browning level using the **Browning Control Dial** (1 for light, 6 for dark).
3. Press the **Carriage Lever** down until it locks into place. The toasting cycle will begin.
4. When the desired browning is achieved, the toast will automatically pop up, and the toaster will switch off.
5. To stop the toasting cycle at any time, press the **STOP Button**.

5.2 Defrosting Frozen Bread

1. Insert frozen bread slices into the toasting slots.
2. Select your desired browning level using the **Browning Control Dial**.
3. Press the **Carriage Lever** down.
4. Press the **DEFROST Button**. The indicator light will illuminate. The toaster will first defrost the bread, then toast it to the selected browning level.

5.3 Reheating Toast

1. Insert previously toasted bread into the toasting slots.
2. Press the **Carriage Lever** down.
3. Press the **REHEAT Button**. The indicator light will illuminate. The toaster will gently warm the bread without further browning.



Figure 5: The toaster can be used with an optional warming rack for heating various baked goods.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

- **Always unplug the toaster** from the power outlet and allow it to cool completely before cleaning.
- **Crumb Tray:** Pull out the crumb tray located at the bottom of the toaster. Empty the crumbs and wipe the tray clean with a damp cloth. Reinsert the tray securely.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the finish.
- **Interior:** Never insert any objects into the toasting slots to clean them. If food becomes lodged, unplug the toaster and carefully turn it upside down to dislodge the food.
- Do not immerse the toaster in water or any other liquid.



Figure 6: The removable crumb tray simplifies cleaning and prevents crumb buildup.

7. Troubleshooting

If you encounter issues with your toaster, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure plug is firmly in outlet; check circuit breaker; test outlet with another appliance.
Bread does not toast evenly.	Uneven bread thickness; crumb buildup.	Use bread of uniform thickness; clean crumb tray regularly.
Smoke or burning smell.	Food lodged in slots; excessive crumbs; first use burn-off.	Unplug and remove food/crumbs; ensure good ventilation during first use.
Carriage lever does not stay down.	Toaster not plugged in; internal malfunction.	Ensure toaster is plugged in; if problem persists, contact customer support.

8. Specifications

Feature	Detail
Brand	Ariete
Model Number	0155CR
Color	Vintage Beige

Feature	Detail
Material	Stainless Steel
Dimensions (L x W x H)	30 x 19 x 20 cm
Weight	980 grams
Power	810 Watts
Voltage	230 Volts
Number of Slots	2
Browning Levels	6
Special Features	Variable browning control, Defrost function, Reheat function, Stop function, Removable crumb tray, Tempered walls

9. Warranty and Support

Ariete products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Ariete website. For technical support, spare parts, or service inquiries, please contact Ariete customer service through their official channels.
Please retain your proof of purchase for warranty claims.

© 2024 Ariete. All rights reserved.
For more information, visit www.ariete.net

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question