Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AA59-00602A-ZDLMT

ZdalaMit AA59-00602A Replacement Remote Control User Manual

Model: AA59-00602A-ZDLMT

Introduction

This user manual provides detailed instructions for the ZdalaMit AA59-00602A Replacement Remote Control. This remote is designed to be compatible with various Samsung HDTV LED Smart TV models, offering a straightforward and effective solution for your television control needs.
The AA59-00602A remote control requires no programming or pairing, making it ready for use immediately after battery installation.

Setup and Battery Installation

To begin using your ZdalaMit AA59-00602A Replacement Remote Control, you will need to install two AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery Compartment of the Remote Control. This image shows the rear of the remote with the battery cover detached, revealing the two slots for AAA batteries.

Once the batteries are installed, the remote control is ready for immediate use with compatible Samsung TV models. No programming or pairing is required.

Operating Instructions

The ZdalaMit AA59-00602A remote control is designed to function identically to the original Samsung remote, providing intuitive control over your television's features.



Figure 2: Front View of the Remote Control. This image displays the full button layout of the AA59-00602A remote control.

Basic Functions:

- **Power Button ( )**: Turns the TV on or off.
- **Number Buttons (0-9)**: Directly select channels.

- **Volume Up/Down (+/-)**: Adjusts the television's volume.
- **Channel Up/Down (▲/▼)**: Changes the television channel.
- **Mute ( )**: Mutes or unmutes the television audio.
- **Source**: Selects input sources (HDMI, AV, Component, etc.).
- **Menu**: Accesses the TV's main menu.
- **Tools**: Provides quick access to common functions and settings.
- **Info**: Displays information about the current program or input.
- **Exit**: Exits the current menu or function.
- **Return**: Returns to the previous screen or menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter)**: Navigate through menus and confirm selections.

Advanced Functions:

- **TTX/MIX**: Teletext functions.
- **PRE-CH**: Returns to the previously viewed channel.
- **CH LIST**: Displays the channel list.
- **GUIDE**: Accesses the electronic program guide (EPG).
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV model and current application (e.g., Smart TV apps, teletext).
- **E-Manual**: Accesses the TV's built-in electronic manual.
- **P.SIZE**: Adjusts picture size/aspect ratio.
- **AD/SUBT.**: Audio Description / Subtitle control.
- **Media Playback Controls (Play, Pause, Stop, Fast Forward, Rewind)**: Control media playback from connected devices or Smart TV apps.

Compatible Samsung TV Models:

This remote control is compatible with a wide range of Samsung TV models, including but not limited to:

- UE19ES4000
- UE22ES5000
- UE22ES5000W
- UE26EH4000W
- UE32EH4000
- UE32EH4000K
- UE32EH4000W
- UE32EH4003
- UE32EH4003W
- UE32EH5200
- UE37EH5000K
- UE39EH5003W
- UE40EH5000
- UE40EH5000K
- UE46EH5000
- UE46EH5000K
- UE60EH6000K

- PS43E450
- PS51E450
- PS51E530

Maintenance

- **Cleaning**: Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement**: Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device. Store in a cool, dry place.
- **Avoid Exposure**: Do not expose the remote control to direct sunlight, high temperatures, humidity, or extreme cold. Avoid dropping the remote or subjecting it to strong impacts.

Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	Batteries are dead or incorrectly installed.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity (+/-).
Remote control range is poor.	Weak batteries; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries. Ensure there are no objects blocking the line of sight between the remote and the TV's infrared sensor. Clean the TV's IR sensor if dusty.
Specific buttons are not responding.	Button malfunction; TV model incompatibility for specific advanced functions.	Ensure the remote is pointed directly at the TV. Verify your TV model is listed as compatible. If the issue persists for basic functions, the remote may be faulty.
TV does not respond to remote at all.	TV is off or unplugged; TV's IR sensor is faulty.	Ensure the TV is powered on. Test with another remote if available to determine if the issue is with the TV or the remote.

Specifications

Feature	Detail
Model Number	AA59-00602A-ZDLMT
Brand	ZdalaMit
Compatible Devices	Samsung HDTV LED Smart TVs (specific models listed in Operating Instructions)
Power Supply	2 x AAA Alkaline Batteries (not included)
Color	Black
Product Dimensions	4 x 1 x 2 inches (approximate)

Feature	Detail
Item Weight	2 ounces (approximate)
Special Feature	Ergonomic design
Max Number of Supported Devices	1 (direct replacement)
Date First Available	January 6, 2017

Support and Contact Information

For any queries, issues, or further assistance regarding your ZdalaMit AA59-00602A Replacement Remote Control, please contact the seller or manufacturer directly.
Note: Warranty information is not explicitly provided with this product. Please refer to your purchase documentation or contact the seller for details regarding returns or warranty claims.
Manufacturer: ZdalaMit Factory

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N9NV2BP

More documents and user manuals: **https://manuals.plus/**