Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 10-Count 9-ft Multicolor Edison LED String Lights

Holiday Living 10-Count 9-ft Multicolor Edison LED String Lights User Manual

Model: 10-Count 9-ft Multi-Function Multicolor Edison LED String Lights

Introduction

Thank you for choosing the Holiday Living 10-Count 9-ft Multi-Function Multicolor Edison LED Battery-Operated Indoor/Outdoor Christmas String Lights. This manual provides important information regarding the safe installation, operation, and maintenance of your new string lights. Please read these instructions thoroughly before use and retain them for future reference.

Safety Information

- Always follow basic safety precautions when using electrical products.
- Do not immerse the battery box in water. The lights are weather-resistant, but the battery box should be protected from excessive moisture.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the product is not used for an extended period.
- Keep batteries out of reach of children.
- Ensure all connections are secure before operation.

Package Contents

Please check the package contents to ensure all items are present:

- 1 x Holiday Living 10-Count 9-ft Multi-Function Multicolor Edison LED String Lights
- 1 x Battery Box (integrated with the string lights)

Note: 3 'D' batteries are required for operation and are **not included** in the package.

Setup

1. Battery Installation

1. Locate the battery box on the string lights.
2. Open the battery compartment cover.
3. Insert 3 new 'D' batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.

4. Securely close the battery compartment cover.

Image: Diagram showing how to open the battery compartment and insert batteries.

Description: This image would illustrate the process of opening the battery box, identifying the positive and negative terminals, and correctly inserting three 'D' size batteries. It would show the battery box typically located near the lead wire of the string lights.

2. Placement

- These string lights are suitable for both indoor and outdoor use.
- For outdoor use, ensure the battery box is placed in a location protected from direct heavy rain or snow to prolong its lifespan, although the unit is weather-resistant.
- Unroll the string lights carefully to avoid tangling.
- Hang or drape the lights in your desired location. The total length is 10 feet, including 9 feet with lights and a 12-inch lead wire.

Operating Instructions

The string lights feature a multi-function control button, typically located on the battery box, or can be controlled via a remote (if included with your specific model).

Using the Control Button

Press the button repeatedly to cycle through the available functions:

1. **OFF:** Lights are turned off.
2. **CASCADING:** Lights display a dynamic cascading effect.
3. **4-HOUR TIMER:** Lights will stay on for 4 hours, then turn off for 20 hours, and repeat the cycle.
4. **6-HOUR TIMER:** Lights will stay on for 6 hours, then turn off for 18 hours, and repeat the cycle.
5. **8-HOUR TIMER:** Lights will stay on for 8 hours, then turn off for 16 hours, and repeat the cycle.

To select a function, stop pressing the button when your desired mode is active. The timer function will activate from the moment you select it.

Image: Close-up of the battery box showing the control button and its location.

Description: This image would provide a clear view of the battery compartment, highlighting the power/mode button that cycles through the various light functions and timer settings.

Maintenance

Cleaning

- Ensure the lights are off and batteries are removed before cleaning.
- Wipe the lights and battery box with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Battery Replacement

- When lights dim or stop working, it's time to replace the batteries.
- Follow the battery installation steps outlined in the 'Setup' section.
- Always replace all three 'D' batteries at the same time with new ones.

Storage

- Before storing, remove the batteries from the battery box.
- Carefully coil the string lights to prevent tangling.

- Store the lights in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	1. Batteries are dead or inserted incorrectly. 2. Battery box is not properly closed. 3. Unit is in 'OFF' mode.	1. Replace batteries with new 'D' batteries, ensuring correct polarity. 2. Ensure battery compartment cover is securely closed. 3. Press the control button to cycle to a different function.
Lights are dim.	Batteries are low.	Replace all batteries with new 'D' batteries.
Timer function not working as expected.	Timer was activated at an unintended time.	To reset the timer, turn the lights OFF and then select the desired timer mode again at the time you wish the cycle to begin.

Specifications

Feature	Detail
Brand	Holiday Living
Light Type	LED (Edison style)
Number of Lights	10-Count
Total Length	10 feet (9 feet lighted length + 12-inch lead wire)
Light Color	Multicolor
Functions	OFF, Cascading, 4-hour Timer, 6-hour Timer, 8-hour Timer
Power Source	Battery Operated (3 x 'D' batteries, not included)
Usage	Indoor / Outdoor
Weather Resistance	Weather-resistant
Control Method	On-board button (Remote Control mentioned in specifications, but not detailed in product description for this model)

Warranty and Support

Holiday Living products are manufactured to high-quality standards. For specific warranty information, please refer to the packaging or contact the retailer where the product was purchased. If you encounter any issues or have questions not covered in this manual, please contact Holiday Living customer support through their official website or the contact information provided on the product packaging.

© 2023 Holiday Living. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N9O3K4U

More documents and user manuals: **https://manuals.plus/**