Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 27890BO-T

Holiday Living 10-Count Frosted Gold Edison LED String Lights User Manual

Model: 27890BO-T

Introduction

Thank you for choosing the Holiday Living 10-Count Frosted Gold Edison LED String Lights. This manual provides essential information for the safe and efficient use of your new string lights. Please read these instructions thoroughly before installation and operation, and retain them for future reference.

Important Safety Information

- **Battery Safety:** Requires three (3) "D" batteries (not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity (+ and -). Remove batteries if the product is not used for an extended period.
- **Indoor/Outdoor Use:** These lights are designed for both indoor and outdoor use. Ensure the battery compartment is securely closed when used outdoors to maintain weather resistance.
- **Placement:** Do not hang lights in a manner that could damage the wire insulation. Avoid placing lights near heat sources or in areas with excessive moisture.
- **LED Bulbs:** The LED bulbs are non-replaceable. Do not attempt to remove or modify the bulbs.
- **Cleaning:** Disconnect power (remove batteries) before cleaning. Use a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

Package Contents

- 1 x Holiday Living 10-Count Frosted Gold Edison LED String Lights (Model: 27890BO-T)
- 1 x Instruction Manual



Image: The 10-count string lights feature frosted gold Edison-style LED bulbs, providing a warm white glow.

Setup Instructions

1. Battery Installation

1. Locate the battery compartment on the string light unit.
2. Open the battery compartment cover.
3. Insert three (3) "D" size batteries (not included) into the compartment, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Securely close the battery compartment cover to ensure weather resistance.

2. Placement

These string lights are suitable for both indoor and outdoor decoration. The total length is 10 feet, including 9 feet with lights and a 12-inch lead wire. Position the lights in your desired location, ensuring the battery compartment is protected from direct heavy rain if used outdoors, despite its weather-resistant design.

Operating Instructions

The Holiday Living LED String Lights feature a multi-function control button, typically located on the battery compartment. Press this button repeatedly to cycle through the available functions:

- **OFF:** Lights are turned off.
- **CASCADING:** Lights display a dynamic, flowing effect.
- **4-HOUR TIMER:** Lights will stay on for 4 hours, then turn off automatically for 20 hours, and repeat the cycle.
- **6-HOUR TIMER:** Lights will stay on for 6 hours, then turn off automatically for 18 hours, and repeat the cycle.
- **8-HOUR TIMER:** Lights will stay on for 8 hours, then turn off automatically for 16 hours, and repeat the cycle.

Select the desired function by pressing the button until the lights display the chosen mode.

Care and Maintenance

- **Cleaning:** To clean the lights, ensure batteries are removed. Gently wipe the bulbs and wires with a soft, dry, or slightly damp cloth. Do not immerse the lights or battery compartment in water.
- **Storage:** When not in use, especially during off-season, remove the batteries to prevent leakage. Store the string lights in a cool, dry place, away from direct sunlight and extreme temperatures. Coil the string neatly to prevent tangling and damage to the wires.
- **Battery Replacement:** Replace all three "D" batteries simultaneously when the lights dim or cease to function.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	◦ Batteries are dead or low. ◦ Batteries are inserted incorrectly. ◦ Battery compartment not closed properly.	◦ Replace with new "D" batteries. ◦ Check and correct battery polarity. ◦ Ensure the battery compartment cover is fully sealed.
Lights are dim.	◦ Batteries are low.	◦ Replace all batteries with new "D" batteries.
Timer function not working as expected.	◦ Incorrect timer mode selected. ◦ Batteries are low.	◦ Cycle through functions to re-select the desired timer mode. ◦ Replace all batteries with new "D" batteries.

Product Specifications

- **Model:** 27890BO-T
- **Brand:** Holiday Living
- **Light Type:** LED
- **Bulb Style:** Frosted Gold Edison
- **Number of Lights:** 10-Count
- **Total Length:** 10 Feet (9 feet with lights, 12-inch lead wire)
- **Functions:** 5 (Off, Cascading, 4-Hour Timer, 6-Hour Timer, 8-Hour Timer)
- **Power Source:** Battery-Operated
- **Batteries Required:** 3 x "D" batteries (not included)
- **Indoor/Outdoor Usage:** Yes
- **Weather Resistance:** Yes
- **Estimated Burn Hours:** 240 hours (varies by battery brand)
- **UPC:** 886778278908

Warranty Information

This Holiday Living product is covered by a **Year Limited Warranty**. Please refer to the original product packaging or contact customer support for specific terms and conditions of the warranty.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact the distributor:
Distributed by: F.G. Sourcing, Inc.
Website: www.fgsourcing.com
Phone: 1-866-446-7859
Please have your model number (27890BO-T) and UPC (886778278908) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01N9O3SEI

More documents and user manuals: **https://manuals.plus/**