Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit 4330256045

ZdalaMit VR2 Replacement TV Remote Control User Manual

Model: 4330256045

Introduction

This manual provides comprehensive instructions for the ZdalaMit VR2 Replacement TV Remote Control. This remote is designed to function as a direct replacement for original Vizio TV remotes, requiring no programming or pairing. Simply install batteries, and it is ready for use.

Product Overview



Figure 1: Front view of the ZdalaMit VR2 Replacement TV Remote Control.

The ZdalaMit VR2 remote control features a standard layout for Vizio televisions, including power, input selection, channel, volume, menu navigation, and numerical buttons.

Setup

Battery Installation

The remote control requires two (2) 1.5V AA alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Note: No programming or pairing is required for this replacement remote control. It is ready for use immediately after battery installation.

Operating Instructions

Basic Functions

- **Power Button:** Turns the TV on or off.
- **Input/Source Buttons (TV, AV, COMP, HDMI):** Selects the desired input source for your television.
- **Volume Up/Down (VOL +/-):** Adjusts the audio volume.
- **Channel Up/Down (CH +/-):** Changes the television channel.
- **Mute Button:** Mutes or unmutes the television audio.
- **Menu Button:** Accesses the TV's on-screen menu.
- **Navigation Buttons (Up, Down, Left, Right, OK/Select):** Navigates through menu options.
- **Number Buttons (0-9):** Directly enters channel numbers.
- **Last Button:** Returns to the previously viewed channel.
- **Guide Button:** Displays the program guide (if supported by your TV and service).

Compatible Vizio TV Models

This remote control is compatible with the following Vizio TV models:

- VP322HDTV10A
- VECO320L
- VP422
- VL370M
- VO420E
- VL260M
  VL320M
- VO320E
- VO370M
- VP322
- VP323HDTV10A
- VECO320LHDTV
- VP422HDTV10A
- VECO320L1A
- VX240M
- VW37LHDTV30A
- VW37LHDTV40A

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.

- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure the remote is pointed directly at the TV's sensor.
- **Some buttons not working:**
  - This remote is designed for specific Vizio TV models. Verify your TV model is listed under "Compatible Vizio TV Models."
  - Clean the remote control, especially around the unresponsive buttons, to remove any debris.

Specifications

Model Number	4330256045
Brand	ZdalaMit
Power Supply	2 x 1.5V AA Alkaline Batteries
Product Dimensions	7.34 x 1.99 x 0.55 inches
Item Weight	0.798 ounces
Compatible Devices	Vizio Televisions (specific models listed above)

Package Contents

- 1 x ZdalaMit VR2 Replacement TV Remote Control

Note: Batteries and additional instructions are not included in the package.

Support

If you encounter any issues or have questions regarding your ZdalaMit VR2 Replacement TV Remote Control, please contact the seller for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NA08YSJ

More documents and user manuals: **https://manuals.plus/**