Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine f58fc24d-02bb-4dd3-8256-9199c9df3cb5

JustFine Replacement Remote Control User Manual

Model: f58fc24d-02bb-4dd3-8256-9199c9df3cb5

1. Introduction

This manual provides instructions for the JustFine replacement remote control, designed for use with various Samsung TV models. This remote is pre-programmed and does not require additional setup beyond battery installation.

Compatible Samsung TV Models: UN46B6000VF, PN50B550T2F, LN40A540, PN63A650, PN50A760T1FX, LN55B640R3FXZA, LN55B640R3FXZC.

2. Product Overview

The JustFine replacement remote control features a standard layout for easy operation of compatible Samsung televisions. Key functions include power, volume, channel selection, input source, and navigation controls.



Figure 2.1: Front view of the remote control. This image displays the ergonomic design and the arrangement of all functional buttons, including the power button at the top left, numerical keys, volume and channel controls, and the central navigation pad.

Button Functions:

- **POWER:** Turns the television on or off.
- **ON/OFF:** (If present) Alternative power control.
- **Number Pad (0-9):** Direct channel input.
- **VOL +/-:** Adjusts volume level.
- **CH +/-:** Changes television channels.
- **MUTE:** Silences television audio.
- **SOURCE:** Selects input source (HDMI, AV, etc.).
- **Navigation Pad (Up, Down, Left, Right, Enter):** Navigates menus and confirms selections.
- **MENU/SETTINGS:** Accesses TV menu or settings.
- **EXIT:** Exits current menu or function.
- **INFO:** Displays program information.
- **BACK/RETURN:** Returns to the previous screen or channel.
- **Color Buttons (Red, Green, Yellow, Blue):** Access specific functions within certain TV applications or menus.

3. Setup

This remote control is pre-programmed for compatible Samsung TVs and does not require any additional programming. Simply install batteries to begin use.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch to open it.
3. Insert two new AAA batteries (not included) according to the polarity indicators (+ and -) inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3.1: Back view of the remote control. This image highlights the battery compartment, which is where two AAA batteries should be inserted for operation.

Note: *Batteries are not included with the remote control. Ensure correct battery polarity during installation.*

4. Operating Instructions

After installing batteries, the remote control is ready for immediate use with your compatible Samsung TV. Point the remote directly at the television's infrared receiver.

- **Power On/Off:** Press the **POWER** button once to turn the TV on or off.
- **Volume Adjustment:** Use the **VOL +** button to increase volume and **VOL -** to decrease volume.
- **Channel Change:** Use the **CH +** button to go to the next channel and **CH -** to go to the previous channel.
- **Direct Channel Input:** Use the number pad (0-9) to enter a specific channel number.
- **Mute Audio:** Press the **MUTE** button to temporarily silence the TV audio. Press again to restore.
- **Select Input Source:** Press the **SOURCE** button to cycle through available input sources (e.g., HDMI1, HDMI2, AV). Use the navigation buttons to select and the **ENTER** button to confirm.
- **Menu Navigation:** Use the directional arrows (Up, Down, Left, Right) to navigate through TV menus and the **ENTER** button to select options.

5. Maintenance

Battery Replacement:

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new ones of the same type (AAA).

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the remote's finish or internal components.

6. Troubleshooting

- **Remote not responding:**
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Check if the batteries are inserted correctly according to polarity (+/-).
  - Replace old batteries with new ones.
  - Verify that the remote is pointed directly at the TV.
- **Some buttons not working:**
  - This remote is pre-programmed and cannot be reprogrammed. If specific buttons are unresponsive after checking batteries, the remote may be faulty.

7. Specifications

Brand	JustFine
Model Number	f58fc24d-02bb-4dd3-8256-9199c9df3cb5
Compatible Devices	Samsung Televisions (Specific models listed in Introduction)

Max Number of Supported Devices	1
Color	Black
Special Feature	Ergonomic
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.72 ounces
Date First Available	November 19, 2016

8. Warranty and Support

This product is sold with a 30-day quality warranty and a money-back guarantee, allowing for hassle-free returns.

For any issues or support inquiries, please contact the seller directly via email.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NA7XTQR

More documents and user manuals: **https://manuals.plus/**