Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

One For All URC7145

One For All Evolve 4 Universal Remote Control

Model: URC7145

Introduction

The One For All Evolve 4 Universal Remote Control (Model URC7145) is designed to simplify your home entertainment experience by allowing you to control up to four different devices with a single remote. This remote is pre-programmed to work with a wide range of brands and includes features optimized for Smart TVs, as well as convenient activity modes like 'Watch TV' and 'Watch Movie' for seamless control across multiple devices.



Image: Angled view of the One For All Evolve 4 Universal Remote Control, showcasing its ergonomic design and button layout.

Setup

1. Battery Installation

The One For All Evolve 4 remote requires 2 AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the

compartment.

4. Slide the battery cover back into place until it clicks securely.

2. Programming Your Devices

The Evolve 4 remote can control up to four devices: TV, STB (Set-Top Box), BLU (Blu-ray/DVD Player), and AUD (Audio device). It is designed to work with all brands. There are typically two main methods for programming:

A. SimpleSet (Code Entry)

This method uses pre-programmed codes for popular brands. Refer to the included quick setup guide for specific brand codes. If your device is not listed or the code does not work, proceed to the Learning Function.

B. Learning Function

The learning function allows the Evolve 4 remote to copy functions directly from your original remote control. This is useful for devices not covered by SimpleSet or for specific functions you wish to customize.

- Place the Evolve 4 remote and your original remote on a flat surface, facing each other, about 1-2 inches apart.
- Press and hold the 'MAGIC' button on the Evolve 4 remote until the LED blinks twice and stays lit.
- Press the device key (TV, STB, BLU, or AUD) you wish to program. The LED will blink once and stay lit.
- Press the button on the Evolve 4 remote that you want to teach a function to (e.g., 'POWER'). The LED will blink rapidly.
- Press and hold the corresponding button on your original remote (e.g., 'POWER') until the Evolve 4's LED blinks twice, indicating successful learning.
- Repeat for all desired buttons. Press the 'MAGIC' button to exit learning mode.



Image: Front view of the One For All Evolve 4 Universal Remote Control, highlighting the device selection buttons (TV, STB, BLU, AUD) and the 'MAGIC' button for programming.

Operating the Remote

Once programmed, the Evolve 4 remote provides intuitive control over your devices.

1. Device Selection

To control a specific device, press the corresponding device key at the top of the remote:**TV**, **STB**, **BLU**, or **AUD**. The remote will then send commands to the selected device.

2. Basic Functions

- **Power (Red Button):** Turns the selected device on or off.
- **Volume (+/-):** Adjusts the volume of the selected audio device (often the TV or Soundbar).
- **Channel (CH +/-):** Changes channels on the selected TV or Set-Top Box.
- **Number Keys (0-9):** For direct channel entry or other numerical inputs.
- **Navigation (Arrow Keys & OK):** For menu navigation and selection.

3. Activity Modes

The Evolve 4 features two convenient activity modes that allow seamless control of multiple devices without switching modes:

- **Watch TV:** In this mode, channel keys typically operate your Set-Top Box, while volume keys control your TV or Soundbar.
- **Watch Movie:** This mode is optimized for movie viewing, often directing commands to your Blu-ray/DVD player and audio system simultaneously.

4. Smart TV Optimization

The keypad is optimized for controlling Smart Televisions, providing easy access to smart features and apps.





Image: The One For All Evolve 4 remote positioned on a white table in front of a television, demonstrating its use in a typical home entertainment setup.

Maintenance

Proper care will ensure the longevity of your One For All Evolve 4 remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the LED indicator behaves erratically. Always replace both batteries at the same time with new AAA batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your One For All Evolve 4 remote, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
  - Ensure there are no obstructions between the remote and the device's infrared receiver.
  - Verify that you have selected the correct device mode (TV, STB, BLU, AUD).
- **Device Not Responding to Commands:**
  - Re-program the device using the SimpleSet code entry or the Learning Function.
  - Ensure your original remote is working correctly if using the Learning Function.

- **Specific Buttons Not Working After Learning:**
  - Repeat the learning process for the problematic button, ensuring a strong signal from the original remote.
  - Ensure the original remote's battery is not low during the learning process.

For further assistance, please refer to the comprehensive online manual or contact One For All customer support.

Specifications

Feature	Detail
Brand	One For All
Model	URC7145
Manufacturer	One For All
Model Year	2016
Part Number	URC7145
Compatible Devices	Television, Set-Top Box, Blu-ray/DVD Player, Audio Device
Special Features	Universal, Learnable, Activity Modes
Battery Description	AAA
Batteries Required	Yes (2 AAA batteries)
Batteries Included	No
Connector Type	Infrared
Product Dimensions	2 x 7 x 25 cm; 300 g
ASIN	B01NA9M3V4
Colour	Black
Max Number of Supported Devices	4

Warranty and Support

For information regarding product warranty, please refer to the documentation included with your purchase or visit the official One For All website. For technical support, troubleshooting assistance, or further inquiries, please contact One For All customer service through their official channels.

© 2024 One For All. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NA9M3V4

More documents and user manuals: **https://manuals.plus/**