Nintendo HACAFSSKA

Nintendo Switch Pro Controller User Manual

Model: HACAFSSKA

Introduction

The Nintendo Switch Pro Controller is designed to enhance your gaming experience on the Nintendo Switch console. It offers a traditional controller feel with advanced features such as motion controls, HD rumble, and built-in amiibo functionality. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Pro Controller.



Image: The Nintendo Switch Pro Controller in its retail packaging, showcasing the product as it appears when purchased.

Setup

Charging the Controller

The Nintendo Switch Pro Controller comes with a USB-C to USB-A charging cable. To charge the controller, connect the USB-C end of the cable to the controller's USB-C port and the USB-A end to a Nintendo Switch Dock or a compatible USB charging adapter (not included). The charging indicator lights on the controller will illuminate during charging and turn off when fully charged.

Pairing with Nintendo Switch

There are two primary methods to pair your Pro Controller with the Nintendo Switch console:

1. **Wired Pairing:** Connect the Pro Controller to the Nintendo Switch Dock using the included USB-C to USB-A charging cable. Ensure the Nintendo Switch console is docked. The controller will automatically pair with the console.

2. **Wireless Pairing:** From the HOME Menu on your Nintendo Switch, select 'Controllers' > 'Change Grip/Order'. While on this screen, press and hold the SYNC Button on the top of the Pro Controller for at least one second. The player indicator lights on the bottom of the controller will flash and then remain solid once pairing is complete.



Image: Front view of the Nintendo Switch Pro Controller, showing the buttons and joysticks.

Operating the Controller

Button Layout and Functions

- **Left Stick:** Used for movement and navigation.
- **Right Stick:** Used for camera control and other in-game actions.
- **A/B/X/Y Buttons:** Action buttons for various in-game commands.
- **+ (Plus) Button:** Typically used for pausing or opening menus.
- **- (Minus) Button:** Typically used for opening maps or secondary menus.
- **D-Pad:** Directional input, often used for menu navigation or specific actions.

- **L/R Buttons:** Shoulder buttons for various in-game functions.
- **ZL/ZR Buttons:** Trigger buttons for various in-game functions.
- **HOME Button:** Returns to the HOME Menu.
- **Capture Button:** Takes screenshots or video clips of gameplay.

Special Features

- **Motion Controls:** The controller includes internal gyroscopes and accelerometers for motion-based gameplay.
- **HD Rumble:** Provides nuanced and realistic vibration feedback during gameplay.
- **amiibo Functionality:** The NFC touchpoint on the controller allows you to tap compatible amiibo figures to receive in-game bonuses or unlock content.



Image: The Nintendo Switch Pro Controller demonstrating amiibo functionality with a Mario amiibo figure.

Maintenance

To ensure the longevity and optimal performance of your Nintendo Switch Pro Controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** While the controller uses an internal rechargeable battery, avoid completely draining the battery frequently. Charge it regularly to maintain battery health. If storing for an extended period, charge it at least once every six months.
- **Handle with Care:** Avoid dropping the controller or subjecting it to strong impacts, as this can damage internal components.

Troubleshooting

If you encounter issues with your Nintendo Switch Pro Controller, try the following solutions:

- **Controller Not Connecting:** Ensure the controller is charged. Try re-pairing the controller using both wired and wireless methods described in the 'Setup' section. Make sure the Nintendo Switch console's system software is up to date.
- **Buttons or Joysticks Unresponsive:** Check for any physical obstructions. If the issue persists, try recalibrating the joysticks and motion controls through the Nintendo Switch system settings ('System Settings' > 'Controllers and Sensors').
- **Charging Issues:** Verify that the charging cable is securely connected to both the controller and the power source.

Try a different USB port on the dock or a different compatible USB charging adapter.

- **Interference:** Ensure there are no large metal objects or other wireless devices causing interference between the controller and the console.

For more detailed troubleshooting or persistent issues, please refer to the official Nintendo support website or the comprehensive user guide available as a PDF: Nintendo Switch Pro Controller User Guide (PDF).

Specifications

Feature	Detail
Model Number	HACAFSSKA
Dimensions	2.6 x 6.1 x 6.18 inches
Weight	8.8 ounces
Battery	1 D battery (included, rechargeable)
Connectivity	Bluetooth 3.0, USB-C
Release Date	March 3, 2017

Warranty and Support

The Nintendo Switch Pro Controller is covered by Nintendo's standard warranty. For specific warranty terms and conditions, please refer to the documentation included with your product or visit the official Nintendo support website. For technical assistance, product registration, or to find authorized service centers, please visit www.nintendo.com or contact Nintendo customer support.

© 2025 Nintendo. All rights reserved. Nintendo Switch is a trademark of Nintendo.