Vivitar 110EF

Vivitar 110EF Pocket Camera Instruction Manual

Model: 110EF

Introduction

Thank you for choosing the Vivitar 110EF Pocket Camera. This compact and easy-to-use camera is designed for capturing everyday moments with simplicity. Featuring a focus-free lens and a built-in electronic flash, it is ideal for various lighting conditions. Please read this manual carefully to ensure proper operation and care of your camera.

Setup

1. Inserting Batteries

The Vivitar 110EF requires two (2) AA alkaline batteries (not included) for operation, primarily for the electronic flash. Ensure batteries are inserted with correct polarity (+/-) as indicated inside the battery compartment.





Image: The Vivitar 110EF Pocket Camera in its original blister packaging. The packaging highlights key features such as 'Focus Free', 'Electronic Flash', 'Uses 110 cartridge film', and 'Uses 2 AA alkaline batteries (not included)'. The camera itself is visible through the clear plastic, showcasing its compact, black design.

2. Loading 110 Cartridge Film

Open the film compartment door, typically located on the back or side of the camera. Insert a 110 cartridge film into the compartment, ensuring it is seated correctly. Close the film compartment door securely. The camera is now ready for use.

Operating

1. Taking Photographs

Point the camera at your subject. Since the camera is **Focus Free**, there is no need to adjust focus. Press the shutter button firmly to take a picture. Advance the film after each shot, usually by turning a thumb wheel or lever, to prepare for the next exposure.

2. Using the Electronic Flash

The Vivitar 110EF features a built-in **Electronic Flash** for low-light conditions. To activate the flash, slide the flash switch or button to the 'ON' position. Wait for the flash ready light (if present) to illuminate, indicating the flash is charged and ready to fire. For best results, ensure your subject is within the effective range of the flash.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if the camera will not be used for an extended period to prevent leakage.
- **Film Handling:** Always load and unload film in subdued light to prevent accidental exposure.

Troubleshooting

Problem	Possible Cause	Solution
Flash not firing	Low or dead batteries; Flash not charged; Flash switch off.	Replace batteries; Wait for flash ready light; Turn flash switch on.
Film not advancing	Film improperly loaded; Film jammed; End of film roll.	Re-load film correctly; Gently check for obstructions; Replace with new film cartridge.
Pictures are blurry	Camera movement during exposure; Subject too close/far for fixed focus.	Hold camera steady; Ensure subject is within optimal fixed-focus range (typically 4 feet to infinity).

Specifications

Model: 110EF (063120-W)

Film Type: 110 Cartridge Film

Lens: Focus Free

Flash: Electronic Flash (Built-in)

Batteries: 2 x AA Alkaline (not included)

Dimensions (Package): 9.2 x 4.9 x 3.9 inches

Weight (Item): 15.2 ounces

UPC: 019643631205

Manufacturer: Vivitar Corporation

Warranty and Support

The Vivitar 110EF Pocket Camera comes with a **One Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support or warranty service, please contact Vivitar Corporation directly. Contact information can typically be found on the manufacturer's official website or product packaging. When contacting support, please have your model number (110EF) and UPC (019643631205) available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question