Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi KBOV1200J-AZ

De'Longhi ICONA Vintage Collection Electric Kettle User Manual

Model: KBOV1200J-AZ

Introduction

Welcome to your new De'Longhi ICONA Vintage Collection Electric Kettle. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before using the kettle.
- Do not immerse the power cord, plugs, or the kettle itself in water or other liquids.
- Close supervision is necessary when the kettle is used by or near children.
- Unplug the kettle from the outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use the kettle only on a flat, stable, and heat-resistant surface.
- Do not place the kettle on or near a hot gas or electric burner, or in a heated oven.
- Always fill the kettle with water before turning it on. Do not operate the kettle empty.
- Do not fill the kettle above the MAX line (1.0L) to avoid boiling water overflowing.
- Avoid contact with hot surfaces. Use handles or knobs.
- This appliance is intended for household use only. Do not use outdoors.

Product Overview

Familiarize yourself with the components and features of your De'Longhi Electric Kettle.



This image shows the De'Longhi ICONA Vintage Collection Electric Kettle in Azzurro Blue, featuring its classic design, handle, spout, and power base.



This image highlights the kettle's 1.0L capacity, indicated by a graphic showing the maximum fill level.



This image illustrates the physical dimensions of the kettle, showing a width of 210mm and a height of 235mm, providing a clear understanding of its size.

Key Components:

- **Lid:** Removable lid for easy filling and cleaning.
- **Handle:** Ergonomically designed for comfortable pouring.
- **Water Level Indicator:** Transparent gauge to easily monitor water volume.
- **Spout:** Designed for precise pouring.
- **Removable Filter:** Located in the spout to prevent limescale from entering your cup.
- **Power Switch:** On/off switch with indicator light.
- **Power Base:** Cordless base with 360-degree rotation and cord storage.



This image highlights the kettle's wide opening for easy filling and cleaning, the removable filter located inside the spout for preventing limescale, and the transparent water level indicator with markings for easy monitoring of water volume (MAX, 0.75L, 0.5L).



This image displays the kettle's power base, which includes a convenient cord holder for tidy storage when not in use. The base allows the kettle to be placed on it from any angle, offering 360-degree rotation for ease of use.

Setup

Follow these steps for the initial setup of your electric kettle:

1. Unpack the kettle and all accessories from the packaging.
2. Place the power base on a flat, stable, and heat-resistant surface.
3. Ensure the power cord is fully unwound from the cord storage area located under the base.
4. Before first use, fill the kettle with cold water to the MAX level. Boil the water, then discard it. Repeat this process twice to remove any manufacturing residues or dust.

Operating Instructions

Using your De'Longhi Electric Kettle is simple:

1. Fill the kettle with the desired amount of fresh cold water. Do not fill below the MIN mark or above the MAX mark (1.0L).
2. Close the lid securely, ensuring it is properly seated.
3. Place the kettle firmly on the power base.
4. Plug the power cord into a suitable electrical outlet (100V, 50/60Hz).
5. Press the power switch down. The indicator light will illuminate, indicating that the kettle is heating.
6. The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
7. Carefully lift the kettle from the base and pour the hot water.
8. If you need to stop the boiling process before it completes, simply lift the kettle from the base or manually switch off the power.

Special Features:

- **Automatic Power Off:** The kettle automatically turns off when the water reaches boiling point, ensuring safety and energy efficiency.
- **Boil-Dry Protection:** The kettle is equipped with a safety feature that automatically shuts it off if it is accidentally switched on without water or with insufficient water. If this occurs, allow the kettle to cool down for a few minutes before refilling with cold water and resuming operation.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your kettle.

General Cleaning

1. Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
3. The removable filter can be rinsed under running water. If necessary, use a soft brush to remove any deposits. Ensure it is dry before reinserting.
4. Do not immerse the kettle or its power base in water or any other liquid.

Descaling

Limescale buildup can affect performance and taste. Descale your kettle regularly, especially in hard water areas.

1. Fill the kettle with a mixture of white vinegar and water (1:2 ratio) or a commercial descaling solution designed for kettles.
2. Bring the mixture to a boil.
3. Allow the mixture to soak in the kettle for at least 30 minutes, or longer for heavy buildup.
4. Empty the kettle and rinse thoroughly with fresh water several times to remove all descaling solution.

5. Boil fresh water in the kettle and discard it twice to remove any residual taste or odor from the descaling process.

Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Kettle does not heat.	Not plugged in; Power switch not pressed; No power at outlet.	Check if the plug is securely inserted into the outlet. Press the power switch down. Check your household circuit breaker.
Kettle switches off before boiling.	Excessive limescale buildup; Boil-dry protection activated.	Descale the kettle as per the maintenance instructions. If boil-dry protection activated, allow the kettle to cool down for 10-15 minutes before refilling with cold water.
Water tastes strange or has an odor.	First use residue; Residue from descaling solution.	Boil and discard fresh water several times. Ensure thorough rinsing after descaling.
Lid does not close properly.	Obstruction or misalignment.	Check for any obstruction around the lid rim and remove it. Ensure the lid is aligned correctly before closing.

Specifications

Technical details of your De'Longhi ICONA Vintage Collection Electric Kettle:

Feature	Detail
Brand	De'Longhi
Model	KBOV1200J-AZ
Capacity	1.0 Liter (approximately 33.8 fl oz)
Voltage/Frequency	100 V (50/60 Hz)
Power Consumption	1200 W
Product Dimensions (L x W x H)	9.1" x 9.1" x 9.8" (210mm x 165mm x 235mm)
Item Weight	1.1 kg (2.4 lbs)
Material	Stainless Steel
Special Features	Automatic power off, Boil-dry protection, Removable filter
Cable Length	1.3 Meters

Feature	Detail
Country of Manufacture	China

Warranty and Support

Your De'Longhi Electric Kettle comes with a**1-Year Warranty** from the date of purchase, covering manufacturing defects under normal household use.
For warranty claims, technical support, or to inquire about replacement parts, please contact De'Longhi customer service through their official channels.
Visit the official De'Longhi website for more information and support resources:www.delonghi.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NBJ6HX9

More documents and user manuals: **https://manuals.plus/**