Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RC-863M

ZdalaMit RC-863M Replacement Remote Control Instruction Manual

Model: RC-863M | Brand: ZdalaMit

Introduction

This manual provides instructions for the ZdalaMit RC-863M replacement remote control. This remote is designed to function as a direct replacement for specific Onkyo AV Receiver models without requiring any programming or pairing. Simply insert batteries to begin operation.

Compatible Onkyo AV Receiver Models:

- HT-S5600
- HT-R2295
- HT-R592
- HTS5600
- HTR2295
- HTR592

Setup: Battery Installation

The RC-863M remote control requires two (2) 1.5V AA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and lift it off to open.
3. Insert two (2) AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with batteries inserted.

Important: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

Operating Instructions

The ZdalaMit RC-863M remote control is designed for immediate use with compatible Onkyo AV Receivers. No programming or setup is required beyond battery installation.

1. **Power On/Off:** Press the **ON/STANDBY** button (typically orange) to power your Onkyo AV Receiver on or off.
2. **Input Selection:** Use the input selector buttons (e.g., **DVD**, **VCR/DVR**, **CBL/SAT**, **CD**, **GAME**, **AUX**, **AM**, **FM**) to switch between different audio/video sources connected to your receiver.
3. **Volume Control:** Adjust the volume using the **VOL +** and **VOL -** buttons.
4. **Muting:** Press the **MUTING** button to temporarily silence the audio. Press again to restore sound.
5. **Navigation:** Use the directional arrow buttons (**UP**, **DOWN**, **LEFT**, **RIGHT**) and the **ENTER** button for menu navigation and selection.
6. **Menu Access:** Buttons like **SETUP**, **AUDIO**, **RETURN**, **TOP MENU**, and **MENU** provide access to various receiver functions and settings.
7. **Playback Controls:** Standard playback buttons (**PLAY**, **PAUSE**, **STOP**, **FAST FORWARD**, **REWIND**, **SKIP**) are available for controlling media playback.
8. **Numeric Keypad:** Use the numeric buttons (0-9) for direct channel input or other numerical selections.



Figure 2: Front view of the RC-863M remote control.

For detailed functionality of specific buttons, refer to your Onkyo AV Receiver's original instruction manual.

Product Overview

The RC-863M remote control features a comprehensive layout designed for intuitive control of your Onkyo AV Receiver. Below is a general overview of the remote's key areas and buttons.



Figure 3: Detailed view of the RC-863M remote control buttons.

Key Button Functions:

- **ON/STANDBY:** Power on/off for the receiver.
- **ZONE 2:** Controls secondary audio zone.
- **SOURCE:** Cycles through input sources.

- **REMOTE MODE/INPUT SELECTOR:** Buttons for specific inputs (e.g., DVD, CBL/SAT, CD, GAME, AUX, AM, FM).
- **TV/INPUT:** Controls TV power and input.
- **DISPLAY:** Changes display information on the receiver.
- **VOL +/-:** Adjusts master volume.
- **MUTING:** Mutes/unmutes audio.
- **GUIDE/TOP MENU, PREV CH/MENU:** Navigation and menu access.
- **SETUP, AUDIO, RETURN:** Access receiver settings and functions.
- **ENTER:** Confirms selections.
- **Playback Controls:** Play, Pause, Stop, Fast Forward, Rewind, Skip.
- **LISTENING MODE:** Selects audio listening modes (e.g., MOVIE/TV, MUSIC, GAME, STEREO).
- **SEARCH, REPEAT, RANDOM, PLAY MODE:** Media playback options.
- **Numeric Keypad (0-9, +10, CLR):** Direct input.
- **D.TUN, DIMMER, SLEEP:** Additional functions.

Specifications

Model Number	RC-863M
Brand	ZdalaMit
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Product Dimensions	7.5 x 2 x 0.6 inches (approximately)
Item Weight	3.04 ounces (approximately)
Color	Black
Compatible Devices	Onkyo AV Receiver Home Theater Systems (HT-S5600, HT-R2295, HT-R592, etc.)

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AA alkaline batteries.
  - Check for any obstructions between the remote control and the AV receiver's infrared sensor.
  - Verify that the remote is pointed directly at the receiver.
- **Specific functions not working:**
  - Confirm that your Onkyo AV Receiver model is listed as compatible.
  - Some advanced functions may require specific settings on your receiver; consult your receiver's original manual.

Video Demonstration

The following video demonstrates the functionality and battery installation for a similar Onkyo replacement remote control. While the model shown (RC-709M) may differ slightly in button layout from the RC-863M, the general principles of operation and battery setup are applicable.

Your browser does not support the video tag.

Video 1: Demonstration of an Onkyo replacement remote control (RC-709M), showing button layout and battery installation. This video is provided by the seller and is relevant for understanding general remote control operation.

Warranty and Support

For any queries or support regarding your ZdalaMit RC-863M replacement remote control, please contact the seller directly through the platform where the purchase was made. Specific warranty details may vary and are typically provided by the seller at the time of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question