Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AA59-00637A

ZdalaMit AA59-00637A Replacement Remote Control User Manual

Model: AA59-00637A

Introduction

This manual provides instructions for the ZdalaMit AA59-00637A Replacement Remote Control, designed for various Samsung Smart 3D LCD LED TV models, offering immediate usability without complex setup procedures.
Compatible Samsung TV Models include:

- PN51E8000, PN51E8000GF, PN51E8000GFXZA
- PN60E8000, PN60E8000GF, PN60E8000GFXZA
- PN64E8000GF, PN64E8000GFXZA
- UN46ES7500, UN46ES7500F, UN46ES7500FX, UN46ES7500FXZA, UN46ES7500FX/ZA
- UN46ES7550F, UN46ES7550FXZA
- UN46ES8000, UN46ES8000F, UN46ES8000FXZA
- UN55ES7500, UN55ES7500F, UN55ES7500FXZA, UN55ES7500FX/ZA
- UN55ES7550, UN55ES7550F, UN55ES7550FXZA
- UN55ES8000, UN55ES8000F, UN55ES8000FXZA
- UN60ES7500, UN60ES7500F, UN60ES7500FXZA, UN60ES7500FX/ZA
- UN60ES7550F, UN60ES7550FXZA
- UN60ES8000, UN60ES8000F, UN60ES8000FXZA
- UN65ES8000, UN65ES8000F, UN65ES8000FXZA
- UN75ES9000, UN75ES9000F, UN75ES9000FXZA



Image: Front view of the ZdalaMit AA59-00637A Replacement Remote Control.

Setup

The ZdalaMit AA59-00637A remote control requires no programming or pairing. Simply install the batteries, and it will be ready for immediate use with your compatible Samsung TV.

1. **Open the Battery Compartment:** Locate the battery compartment cover on the back of the remote control. Slide the cover downwards or press the latch and lift to open it.
2. **Insert Batteries:** Insert two (2) AAA Alkaline batteries into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment.
3. **Close the Battery Compartment:** Replace the battery compartment cover by sliding it back into place until it clicks securely.
4. **Test the Remote:** Point the remote control towards your Samsung TV and press the Power button to confirm functionality.



Image: Rear view of the remote control with the battery compartment open, showing where to insert two AAA batteries.

Operating Instructions

Once batteries are correctly installed, the remote control is ready for use. Point the remote directly at your Samsung TV's infrared (IR) receiver. The remote functions are identical to the original Samsung remote control it replaces.

- **Power Button:** Turns the TV on or off.

- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down:** Adjusts the TV volume.
- **Channel Up/Down:** Changes TV channels sequentially.
- **Navigation Pad (Up/Down/Left/Right/Enter):** Used to navigate menus and select options.
- **Smart Hub/Menu Buttons:** Accesses the TV's smart features and settings menu.
- *Other buttons correspond to their labeled functions on the remote.*

Maintenance

- **Battery Replacement:** Replace batteries when the remote's response becomes inconsistent or stops functioning. Always replace both batteries simultaneously with new AAA Alkaline batteries.
- **Cleaning:** To clean the remote control, use a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Check battery orientation. Replace both AAA batteries with new ones.
Remote functions intermittently.	Weak batteries or obstruction between remote and TV.	Replace batteries. Ensure a clear line of sight to the TV's IR receiver. Remove any objects blocking the signal.
Specific buttons not working.	Button stuck or internal fault.	Gently press the button multiple times. If the issue persists, contact customer support.

Specifications

Model Number: AA59-00637A

Brand: ZdalaMit

Product Dimensions: 9.13 x 1.79 x 0.55 inches (23.19 x 4.55 x 1.4 cm)

Item Weight: 2 ounces (56.7 grams)

Power Supply: 2 x 1.5V AAA Alkaline Battery (not included)

Compatible Devices: Samsung Televisions

Special Feature: Ergonomic design

Color: Black

Support

For any further questions, technical assistance, or troubleshooting not covered in this manual, please contact the seller or manufacturer directly. Refer to your purchase documentation for contact information.
Note: This product is a replacement remote and does not typically come with a separate manufacturer's warranty beyond standard retail return policies.

© 2026 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NCS02QT

More documents and user manuals: **https://manuals.plus/**