360 Lighting 17F34

360 Lighting Abba Floor Lamp Model 17F34 Instruction Manual

Brand: 360 Lighting | Model: 17F34

1. Safety Instructions

- Always disconnect the power supply before cleaning, changing light bulbs, or performing any maintenance.
- Do not use this lamp in wet locations or near water.
- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- Use only light bulbs of the specified wattage and type to avoid overheating.
- Keep flammable materials away from the light source.
- This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

2. Package Contents

Please check that all parts are present before beginning assembly. If any parts are missing or damaged, do not attempt to assemble the product.

- Lamp Base (1)
- Lamp Pole Sections (Multiple, pre-assembled or screw-together)
- Lamp Shade (1)
- Shade Finial (1)
- Pull Chains (2)
- Hardware Pack (if applicable for assembly)

3. Assembly Instructions

Follow these steps to assemble your 360 Lighting Abba Floor Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.

2. **Assemble Lamp Pole:** If the lamp pole comes in sections, carefully screw them together clockwise until secure. Ensure the electrical cord is not twisted or pinched during this process.
3. **Attach Pole to Base:** Securely attach the assembled lamp pole to the lamp base. Twist clockwise until firmly tightened.
4. **Install Lamp Shade:** Place the light gray satin tapered drum shade onto the lamp harp (if present) or directly onto the lamp socket assembly. Secure it with the shade finial by screwing it clockwise onto the top of the lamp.
5. **Insert Light Bulbs:** Screw two standard-medium base (E26) light bulbs (not included) into the lamp sockets. Do not exceed 75 watts per bulb.
6. **Connect Pull Chains:** Attach the two pull chains to the switches located on the lamp sockets.





Image 1: Lamp Dimensions. The lamp stands 66 inches high overall. The base is 12 inches wide. The shade measures 14 inches across the top, 16 inches across the bottom, and is 11 inches high.



Image 2: Lamp Base. This image shows the sleek brushed nickel finish of the lamp's metal base, which provides stability.



Image 3: Pull Chains. This image highlights the twin on-off pull chains, designed for convenient control of the lamp's two light sources.

4. Operating Instructions

To operate your 360 Lighting Abba Floor Lamp:

1. **Plug In:** Insert the 8-foot long power cord into a standard 120V AC wall outlet.
2. **Turn On/Off:** Use the twin pull chains to turn the light bulbs on or off. Each pull chain controls one bulb, allowing for flexible lighting control.
3. **Bulb Replacement:** This lamp uses two standard-medium base (E26) light bulbs. It is compatible with LED, incandescent, or CFL bulbs, with a maximum wattage of 75 watts per bulb. Ensure the lamp is unplugged before replacing bulbs.

Helpful Videos:

Your browser does not support the video tag.

Video 1: 360 Lighting Brand Overview. This short video provides a general overview of 360 Lighting products, showcasing various designs and features.

Your browser does not support the video tag.

Video 2: Floor Lamp Type Guide. This video explains different types of floor lamps and their uses, helping you understand the versatility of your lamp.

Your browser does not support the video tag.

Video 3: Floor Lamp Height Guide. This video provides guidance on selecting the appropriate floor lamp height for your space to ensure optimal lighting and comfort.

5. Maintenance

- **Cleaning:** To clean the lamp, ensure it is unplugged. Wipe the brushed nickel finish with a soft, dry cloth. For the fabric shade, use a lint roller or a soft brush to remove dust. Do not use abrasive cleaners or polishes, as they may damage the finish.
- **Bulb Replacement:** Always unplug the lamp before replacing bulbs. Allow old bulbs to cool completely before removal. Screw in new E26 base bulbs, ensuring they do not exceed 75 watts.

6. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not light up.	Lamp not plugged in. Light bulb is loose or burnt out. Power outlet is not functioning.	Ensure the power cord is securely plugged into a working outlet. Tighten or replace the light bulb(s). Test the outlet with another appliance or check your circuit breaker.
Light flickers.	Light bulb is loose. Incorrect bulb wattage. Faulty bulb.	Tighten the light bulb. Ensure the bulb wattage does not exceed 75 watts. Replace the light bulb.

7. Specifications

Overall Height	66 inches (167.6 cm)
Base Diameter	12 inches (30.5 cm)
Shade Dimensions	14 inches (top) x 16 inches (bottom) x 11 inches (height)
Item Weight	14.1 pounds (6.4 kg)
Finish Type	Brushed Nickel
Base Material	Metal
Shade Material	Polyester (Light Gray Satin)
Bulb Base	E26 (Standard-Medium)
Max Wattage	75 watts per bulb (x2)
Switch Type	Twin Pull Chain
Power Source	Corded Electric
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor
Model Number	17F34
UPC	886305109149

8. Warranty and Support

For warranty information or technical support, please refer to the retailer's policy or contact 360 Lighting customer service. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question