PAGARIA L837BT

PAGARIA L837BT Portable Multimedia FM/MP3 Player User Manual

Model: L837BT

1. Introduction

The PAGARIA L837BT is a versatile portable multimedia player designed for audio entertainment. It features FM radio, MP3 playback via USB and TF card, Bluetooth connectivity for wireless audio streaming and hands-free calling, a clock function, and an integrated torch. This manual provides detailed instructions for setting up, operating, and maintaining your device.

2. Package Contents

Please check the box for the following items:

- 1 x PAGARIA L837BT Player
- 1 x Rechargeable Battery (18650 type)
- 1 x USB Charging Cable
- 1 x User Manual (this document)

3. Product Overview

Familiarize yourself with the various parts of your PAGARIA L837BT player.



Figure 3.1: Front View. This image displays the front of the PAGARIA L837BT player, featuring the speaker grille on the left, an LCD display in the center, and a numeric keypad along with function buttons on the right. The telescopic antenna is extended upwards from the top right.



Figure 3.2: Side View with Ports. This angled view highlights the right side of the device, revealing the Micro USB charging port, a 3.5mm headphone jack, and the power switch. The front display and control buttons are also visible.



Figure 3.3: Media Ports. This image shows the left side of the player, featuring a standard USB-A port for flash drives and a TF (Micro SD) card slot for memory cards. The base of the telescopic antenna is also visible.



Figure 3.4: Battery Compartment. The rear view of the device with the battery cover removed, illustrating the slot for the removable 18650 lithium-ion battery. Battery specifications are printed on the battery itself.

4. Setup

4.1. Battery Installation

1. Locate the battery compartment on the back of the device (refer to Figure 3.4).
2. Slide the battery cover open.
3. Insert the provided 18650 rechargeable battery, ensuring the polarity (+/-) matches the indicators inside the compartment.
4. Close the battery cover securely.

4.2. Charging the Battery

1. Connect the small end of the USB charging cable to the Micro USB port on the side of the player.
2. Connect the larger end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator on the display will illuminate. Allow approximately 3-4 hours for a full charge.

4. Disconnect the charging cable once fully charged.

4.3. Powering On/Off

- To power on, slide the power switch located on the side of the device to the "ON" position. The LCD display will light up.
- To power off, slide the power switch to the "OFF" position.

5. Operating Instructions

5.1. General Controls

- **Mode (M) Button:** Press to switch between FM Radio, Bluetooth, USB, and TF Card modes.
- **Play/Pause (►/\) Button:** Press to play or pause audio. In FM mode, long press to auto-scan and save stations.
- **Previous/Volume Down (◀◀/V-) Button:** Short press for previous track/station. Long press to decrease volume.
- **Next/Volume Up (▶▶/V+) Button:** Short press for next track/station. Long press to increase volume.
- **Numeric Keypad (0-9):** Used for direct frequency input in FM mode or track selection in MP3 mode.

5.2. FM Radio Operation

1. Extend the telescopic antenna for optimal reception.
2. Press the **Mode (M)** button until "FM" appears on the display.
3. **Auto-Scan and Save:** Long press the **Play/Pause (►/\)** button. The player will automatically scan for available FM stations and save them.
4. **Manual Tuning:** Use the **Previous/Volume Down (◀◀/V-)** and **Next/Volume Up (▶▶/V+)** buttons to fine-tune frequencies.
5. **Direct Frequency Input:** Use the numeric keypad to enter the desired FM frequency (e.g., 94.3) and press the **Play/Pause (►/\)** button to confirm.

5.3. Bluetooth Mode

1. Press the **Mode (M)** button until "BT" appears on the display. The device will enter pairing mode, indicated by a flashing Bluetooth icon.
2. On your smartphone or other Bluetooth-enabled device, enable Bluetooth and search for available devices.
3. Select "L837BT" from the list of devices. Once paired, the Bluetooth icon on the player's display will stop flashing.
4. You can now play audio from your connected device through the PAGARIA L837BT.
5. **Hands-Free Calling:** When a call comes in, press the **Play/Pause (►/\)** button to answer or end the call.

5.4. USB/TF Card Playback

1. Insert a USB flash drive or a TF (Micro SD) card containing MP3 audio files into the respective port (refer to Figure 3.3).
2. The player will automatically switch to USB or TF card mode and begin playing the first track. If it does not, press the **Mode (M)** button to select the correct mode.
3. Use the **Previous/Volume Down (◀◀/V-)** and **Next/Volume Up (▶▶/V+)** buttons to navigate tracks.
4. Press the **Play/Pause (►/\)** button to pause or resume playback.
5. Use the numeric keypad to directly select a track number.

5.5. Clock Function

- When the device is powered on, it defaults to clock mode if no other media is playing.
- To set the time, long press the **Mode (M)** button while in clock mode. The hour digits will flash.
- Use the **Previous/Volume Down (◀◀/V-)** and **Next/Volume Up (▶▶/V+)** buttons to adjust the hour.
- Press the **Mode (M)** button again to switch to minute adjustment. Adjust minutes using the volume buttons.
- Press the **Mode (M)** button one more time to save the time setting.

5.6. Torch Function

- The device includes a small LED torch. Locate the torch button, usually on the side or top of the device.
- Press the torch button once to turn the torch on.
- Press it again to turn the torch off.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods. Store in a cool, dry place.
- **Storage:** When not in use for a long time, store the player in a dry environment away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Battery is low or not installed correctly.	Charge the battery. Ensure the battery is inserted with correct polarity.
No sound.	Volume is too low or muted.	Increase the volume using the V+ button.
Poor FM reception.	Antenna not extended or weak signal.	Fully extend the telescopic antenna. Try repositioning the device. Perform an auto-scan.
Bluetooth not connecting.	Device not in pairing mode or too far from source.	Ensure the player is in Bluetooth mode and discoverable. Keep devices within 10 meters. Restart both devices.
USB/TF card not playing.	Incorrect file format or card not inserted properly.	Ensure files are in MP3 format. Reinsert the USB drive/TF card. Check if the card is damaged.

8. Specifications

Model	L837BT
Brand	PAGARIA
Connectivity	Bluetooth 4.0, USB, TF Card
Audio Output	3 Watts
Speaker Size	40mm
FM Frequency Range	Up to 108 MHz
Supported Media	MP3 (via USB/TF Card)
TF Card Support	Up to 32GB
Battery Type	18650 Lithium-ion
Battery Capacity	1800mAh
Playback Time	Up to 6 hours (approx.)

Standby Time	Up to 20 hours (approx.)
Special Features	Built-in Mic for calling, Clock Function, Torch Function, LCD Display
Dimensions	19.56 x 7.62 x 4.83 cm
Weight	260 g
Material	Rubber finish

9. Warranty and Support

Specific warranty details for the PAGARIA L837BT are not provided in this manual. For warranty claims, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact PAGARIA customer service directly through their official website or contact information provided at the time of purchase.

© 2023 PAGARIA. All rights reserved.
Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question